

## Remington Confidential

- Push the safe to the “fire” position, be sure that the barrel is far enough within the port hole so that the muzzle will stay in the port when the rifle recoils. If there is any question, re-adjust the jack into a better position.
- With the lid on the belly protector closed, fire the first round in the chamber, listen for any off-sounds, and be alert for any other unusual behavior.
- Open the bolt; eject the spent round, note any extraction or ejection problems.
- Close the bolt to load the first round from the magazine into the chamber, note any feeding or stemming problems.
- Continue to fire the remaining rounds in the magazine until the last round is fired.
- Push the Safety to “On Safe” position, the safety will be pushed to the fire position at the start of every five round trial and will be pushed to the On Safe position at the end of every five round trial. It is important not only from a safety point of view but action of the safety lever on the trigger assembly side-plate needs to be determined.
- After firing twenty rounds (1 box of ammo) the rifle will be checked carefully for the presence of any live ammunition and if empty will be removed from the test jack and placed in the cooling rack. The safety will be in the “On Safe” position and the bolt will be unlocked and fully open at all times. Compressed air may be used, if necessary to cool the inside of the chamber area if the rifle is excessively hot from firing.
- All malfunctions will be recorded on the data sheets.

Data Required:

- Rifle serial number
- Tester's name
- Date of test firing
- The TLW#
- The ammunition used for the test with the ammo code number of the rounds actually used.
- Any malfunctions noted or other unusual items of note.

TLW0010AB - Basic Shoulder Function Test:

To get an early picture of the product's functional capability from the perspective of the customer, a 10 round per rifle shoulder function test will be conducted to evaluate the potential for feeding problems. These