

|                |                                    |             |
|----------------|------------------------------------|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>9766</b> |
|                | <b>Total Rejected:</b>             | <b>212</b>  |
|                | <b>Overall Reject Rate:</b>        | <b>2.17</b> |

**Proof**

|           |     |     |     |     |   |     |   |     |      |
|-----------|-----|-----|-----|-----|---|-----|---|-----|------|
| Shot:     | 326 | 415 | 706 | 207 |   | 79  |   | 23  | 5290 |
| Rejected: | 1   | 0   | 0   | 0   | 0 | 0   | 0 | 0   | 1    |
| Percent:  | 0.3 | 0.0 | 0.0 | 0.0 |   | 0.0 |   | 0.0 | 0.0  |

**Test**

|           |      |     |     |     |   |     |   |      |      |
|-----------|------|-----|-----|-----|---|-----|---|------|------|
| Shot:     | 338  | 320 | 699 | 245 |   | 85  |   | 35   | 5289 |
| Rejected: | 83   | 28  | 48  | 5   | 4 | 0   | 0 | 11   | 8    |
| Percent:  | 24.6 | 8.8 | 6.9 | 2.0 |   | 0.0 |   | 31.4 | 0.2  |

**Target**

|           |   |     |   |   |   |   |   |   |     |
|-----------|---|-----|---|---|---|---|---|---|-----|
| Shot:     |   | 5   |   |   |   |   |   |   | 6   |
| Rejected: | 0 | 0   | 0 | 0 | 0 | 0 | 0 | 0 | 0   |
| Percent:  |   | 0.0 |   |   |   |   |   |   | 0.0 |

| CODE  | MALFUNCTION INDEX                        | 1187 Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga |
|-------|--|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| AB    | Action binds                             | 1                 |              |              |              |              |              |              |               | 1           |
| ASFB  | Action spring follower binds             |                   |              |              |              |              |              |              |               |             |
| BABS  | Bulge at body shoulder                   |                   |              |              |              |              |              |              |               |             |
| BAC   | Burr at chamber                          |                   |              |              |              |              |              |              |               |             |
| BB    | Bolt binds/catches                       |                   |              |              |              |              |              |              |               |             |
| BCOE  | Bolt catches on ejector                  |                   |              |              |              |              |              |              |               |             |
| BC    | Blows cases                              |                   |              |              |              |              |              |              |               |             |
| BLOP  | Bar lock or disconnecter out of position |                   |              |              |              |              |              |              |               | 2           |
| BSCO  | Barrel support came out                  |                   |              |              |              |              |              |              |               |             |
| CBS-F | Shells catch on bbl support-feeding      |                   |              |              |              |              |              |              |               |             |
| CBS-L | Shells catch on bbl support-loading      |                   |              |              |              |              |              |              |               |             |
| CC    | Carrier catches on shells,mag,receiver   | 3                 | 1            |              |              |              |              |              |               |             |
| CD    | Case dented                              |                   |              |              |              |              |              |              |               |             |
| CH    | Closes hard                              |                   |              |              |              |              |              |              |               |             |
| CHAB  | Carrier hits action bar                  |                   |              |              |              |              |              |              |               |             |
| CLM   | Can't load magazine                      |                   |              |              |              |              |              |              |               | 1           |
| CO    | Cut-off                                  |                   |              |              |              |              |              |              |               |             |
| CR    | Cuts rim                                 |                   |              |              |              |              |              |              |               |             |
| CS    | Cases swell                              |                   |              |              |              |              |              |              |               |             |

| CODE | MALFUNCTION INDEX                    | 1187 Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga |
|------|--------------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| CTOG | Chamber torn or gouged               |                   |              |              |              |              |              |              |               |             |
| CTP  | Creepy trigger pull                  |                   |              |              |              |              |              |              |               |             |
| CWSB | Cams wrong side of action bar        |                   |              |              |              |              |              |              |               |             |
| DBB  | Doesn't blow back                    | 3                 | 2            | 26           | 4            | 4            |              |              | 3             |             |
| DCS  | Double click in safety switch        |                   |              |              |              |              |              |              |               |             |
| DCT  | Double click in trigger              |                   |              |              |              |              |              |              |               |             |
| DCU  | Doesn't close-up                     |                   |              |              |              |              |              |              |               |             |
| DE   | Doesn't eject                        | 2                 |              | 3            |              |              |              |              |               |             |
| DEL  | Doesn't eject live round             |                   |              |              |              |              |              |              |               |             |
| DFU  | Doesn't feed up                      | 2                 | 6            |              | 1            |              |              |              |               |             |
| DLO  | Doesn't lock open (after last shell) | 1                 |              |              |              |              |              |              |               |             |
| DLU  | Doesn't lock-up                      |                   |              |              |              |              |              |              |               |             |
| DS   | Dead safe                            | 1                 |              |              |              |              |              |              |               |             |
| DSM  | Drops shell-magazine                 | 3                 | 2            |              |              |              |              |              |               | 1           |
| DTL  | Doesn't trip latch                   |                   |              |              |              |              |              |              |               |             |
| DX   | Doesn't extract                      |                   |              |              |              |              |              |              |               |             |
| DXL  | Doesn't extract live round           |                   |              |              |              |              |              |              |               |             |
| EDS  | Extractor drops shell                |                   |              |              |              |              |              |              | 5             |             |
| ESB  | Ejector sticks back                  |                   |              |              |              |              |              |              |               |             |
| ESS  | Extractor stems shell                |                   |              |              |              |              |              |              |               |             |
| FA   | Fires automatically                  |                   |              |              |              |              |              |              |               |             |
| FB   | Follower binds                       |                   |              |              |              |              |              |              |               | 1           |
| FC   | Fails to connect                     |                   |              |              |              |              |              |              |               |             |
| FCB  | Fore-end cracked or broken           |                   |              |              |              |              |              |              |               |             |
| FD   | Follows-down                         |                   |              |              |              |              |              |              |               |             |
| FF   | Fails to fire                        | 1                 |              | 1            |              |              |              |              |               |             |
| FFM  | Fails to feed from magazine          | 6                 | 6            | 1            |              |              |              |              | 2             | 1           |
| FFP  | Flat firing pin                      |                   |              |              |              |              |              |              |               |             |
| FOS  | Fires on safe                        |                   |              |              |              |              |              |              |               |             |
| FSR  | Fires when safe is released          |                   |              |              |              |              |              |              |               |             |

| CODE | MALFUNCTION INDEX                 | 1187 Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga |
|------|-----------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| GCSQ | Gas cyl. shot off                 |                   |              |              |              |              |              |              |               |             |
| GRSO | Guide ring shot off               |                   |              |              |              |              |              |              |               |             |
| HPA  | High pressure ammo                |                   |              |              |              |              |              |              |               |             |
| HUE  | Hard under extractor              | 1                 | 4            |              |              |              |              |              | 1             |             |
| ILOP | Int. latch out of position        | 2                 |              |              |              |              |              |              |               |             |
| ILRM | Int. latch ret. Missing           | 1                 |              | 1            |              |              |              |              |               |             |
| ILSB | Int. latch stud broken            |                   |              |              |              |              |              |              |               |             |
| ILSP | Int. latch spring out of position |                   |              |              |              |              |              |              |               |             |
| JL   | Jumps latch                       | 4                 | 1            |              |              |              |              |              |               |             |
| JO   | Jars off                          |                   |              |              |              |              |              |              |               |             |
| LB   | Light blow                        |                   |              |              |              |              |              |              |               |             |
| MCSO | Magazine cap shot off             |                   |              |              |              |              |              |              |               |             |
| MCW  | Magazine capacity wrong           |                   |              | 2            |              |              |              |              |               |             |
| MFA  | Misfires (ammo)                   |                   |              |              |              |              |              |              |               |             |
| MFOP | Magazine follower out of position |                   |              |              |              |              |              |              |               |             |
| MLH  | Magazine loads hard               |                   |              | 1            |              |              |              |              |               |             |
| OH   | Opens hard                        |                   |              |              |              |              |              |              |               |             |
| PH   | Pulls hard                        |                   |              |              |              |              |              |              |               |             |
| PSI  | Proof stamp illegible             |                   |              |              |              |              |              |              |               |             |
| PSM  | Proof stamp missing               |                   |              |              |              |              |              |              |               |             |
| RBOC | Rings and bulges on case          |                   |              |              |              |              |              |              |               |             |
| RDW  | (Action) release doesn't work     | 3                 | 3            | 8            |              |              |              |              |               |             |
| RIC  | Rings in chamber                  |                   |              |              |              |              |              |              |               |             |
| SBC  | Stems bottom chambers             | 29                | 2            |              |              |              |              |              |               |             |
| SBCL | Shell binds carrier latch         |                   |              |              |              |              |              |              |               |             |
| SBE  | Stems bbl extension               |                   |              |              |              |              |              |              |               |             |
| SCB  | Stock cracked or broken           |                   |              |              |              |              |              |              |               | 1           |
| SCX  | Shell catches                     |                   |              |              |              |              |              |              |               |             |
| SHI  | Short indent                      |                   |              |              |              |              |              |              |               |             |
| SIC  | Stems in chamber                  | 1                 |              |              |              |              |              |              |               |             |

| CODE   | MALFUNCTION INDEX              | 1187 Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga |
|--------|--------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| SL     | shaves lead                    |                   |              |              |              |              |              |              |               |             |
| SLC    | Stems left side of chamber     | 14                |              |              |              |              |              |              |               |             |
| SMOC   | Stretch marks on case          |                   |              |              |              |              |              |              |               |             |
| SRC    | Stems right side of chamber    |                   |              |              |              |              |              |              |               |             |
| SRIC   | Specific rings in chamber      |                   |              |              |              |              |              |              |               |             |
| SSC    | shell stems carrier            |                   |              |              |              |              |              |              |               |             |
| STC    | Stems top chamber              | 5                 | 1            | 5            |              |              |              |              |               |             |
| SWE    | Safety switch works too easily |                   |              |              |              |              |              |              |               |             |
| SWH    | Safety switch works too hard   |                   |              |              |              |              |              |              |               |             |
| SWW    | Safety ewitxh won't work       |                   |              |              |              |              |              |              |               |             |
| TD     | Tips down                      |                   |              |              |              |              |              |              |               |             |
| TU     | Tips up                        |                   |              |              |              |              |              |              |               |             |
| TWP    | Trigger won't pull             |                   |              |              |              |              |              |              |               |             |
| TWR    | Trigger won't retract          |                   |              |              |              |              |              |              |               |             |
| UNCN-T | Uncoded                        |                   |              |              |              |              |              |              |               |             |
| XH     | Extracts hard                  |                   |              |              |              |              |              |              |               |             |
| XHB    | Extractor hits bbl             |                   |              |              |              |              |              |              |               |             |
|        |                                |                   |              |              |              |              |              |              |               |             |
| HI     | High                           |                   |              |              |              |              |              |              |               |             |
| LO     | Low                            |                   |              |              |              |              |              |              |               |             |
| LEFT   | Left                           |                   |              |              |              |              |              |              |               |             |
| RIGHT  | Right                          |                   |              |              |              |              |              |              |               |             |
| DG     | Doesn't Group                  |                   |              |              |              |              |              |              |               |             |
| FSST   | Front sight tipped             |                   |              |              |              |              |              |              |               |             |
| RSTT   | Rear sight tipped              |                   |              |              |              |              |              |              |               |             |
| RSBR   | Rear sight base raised         |                   |              |              |              |              |              |              |               |             |
| FSTR   | Front sight raised             |                   |              |              |              |              |              |              |               |             |
| FSTL   | Front sight loose              |                   |              |              |              |              |              |              |               |             |
| RSTL   | Rear sight loose               |                   |              |              |              |              |              |              |               |             |
| MGPT-G | Missing parts at target        |                   |              |              |              |              |              |              |               |             |



| CODE   | MALFUNCTION INDEX                 | 1187 Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga |
|--------|-----------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| UNCN-G | Uncoded nonconformity at target   |                   |              |              |              |              |              |              |               |             |
| AI-P   | Assembly incomplete at proof      |                   |              |              |              |              |              |              |               |             |
| BC-P   | Blows cases at proof              |                   |              |              |              |              |              |              |               |             |
| BEB-P  | Barrel extension broken at proof  |                   |              |              |              |              |              |              |               |             |
| BLP-P  | Blanked primer at proof           |                   |              |              |              |              |              |              |               |             |
| BP-P   | Blown primer at proof             |                   |              |              |              |              |              |              |               |             |
| BS-P   | Barrel split at proof             |                   |              |              |              |              |              |              |               |             |
| DLOS-P | Doesn't lock over shells at proof |                   |              |              |              |              |              |              |               |             |
| ESB-P  | Ejector sticks back at proof      |                   |              |              |              |              |              |              |               |             |
| FCB-P  | Fore-end cracked at proof         |                   |              |              |              |              |              |              |               |             |
| FESO-P | Fore-end shot off at proof        |                   |              |              |              |              |              |              |               |             |
| FF-P   | Fails to fire at proof            | 1                 |              |              |              |              |              |              |               | 1           |
| GCSO-P | Gas cylinder shot off at proof    |                   |              |              |              |              |              |              |               |             |
| GRSO-P | Guide ring shot off at proof      |                   |              |              |              |              |              |              |               |             |
| MCSO-P | Magazine cap shot off at proof    |                   |              |              |              |              |              |              |               |             |
| MSI-P  | Magnaflux stamp illegible on bbl  |                   |              |              |              |              |              |              |               |             |
| MSM-P  | Magnaflux stamp missing on bbl    |                   |              |              |              |              |              |              |               |             |
| PP-P   | Pierced primer at proof           |                   |              |              |              |              |              |              |               |             |
| SCB-P  | Stock cracked or broken at proof  |                   |              |              |              |              |              |              |               |             |
| UNCM-P | Uncoded proof malfunctions        |                   |              |              |              |              |              |              |               |             |

| Month:      |          |                     |        |      |               |     |       | total         | Auto<br>Total | Pump<br>Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|---------------|
|             |          |                     |        |      |               |     |       |               |               |               |
|             | 584      |                     | 1792   |      | 350           |     | 9772  | 1756          | 7666          |               |
| 0           | 0        | 0                   | 2      | 0    | 0             | 0   | 4     | 1             | 3             |               |
|             | 0.0      |                     | 0.1    |      | 0.0           |     | 0.041 | 0.057         | 0.039         |               |
|             | 584      |                     | 1789   |      | 378           |     | 9762  | 1722          | 7662          |               |
| 0           | 2        | 0                   | 5      | 0    | 3             | 0   | 197   | 179           | 15            |               |
|             | 0.3      |                     | 0.3    |      | 0.8           |     | 2.02  | 10.39         | 0.20          |               |
|             |          |                     |        |      | 233           |     | 244   | 5             | 6             |               |
| 0           | 0        | 0                   | 0      | 0    | 11            | 0   | 11    | 0             | 0             |               |
|             |          |                     |        |      | 4.7           |     | 4.51  | 0.00          | 0.00          |               |
| 870<br>16Ga | 870 20Ga | 870 light<br>weight | 870 SM | SP10 | 870<br>Police | O/U | total | Auto<br>Total | Pump<br>Total |               |
|             |          |                     | 3      |      |               |     | 5     | 1             | 4             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 2     | 0             | 2             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 4     | 4             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             | 1        |                     | 1      |      |               |     | 3     | 0             | 3             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |               |


| 870<br>16Ga | 870 20Ga | 870 light<br>weight | 870 SM | SP10 | 870<br>Police | O/U | total | Auto<br>Total | Pump<br>Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 42    | 42            | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 5     | 5             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 9     | 9             | 0             |
|             |          |                     |        |      |               |     | 1     | 1             | 0             |
|             |          |                     |        |      | 3             |     | 3     | 0             | 0             |
|             |          |                     |        |      |               |     | 1     | 1             | 0             |
|             |          |                     |        |      |               |     | 6     | 5             | 1             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 5     | 5             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 1     | 0             | 1             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 2     | 2             | 0             |
|             |          |                     | 1      |      |               |     | 17    | 15            | 2             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |

| 870<br>16Ga | 870 20Ga | 870 light<br>weight | 870 SM | SP10 | 870<br>Police | O/U | total | Auto<br>Total | Pump<br>Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 6     | 6             | 0             |
|             |          |                     |        |      |               |     | 2     | 2             | 0             |
|             |          |                     |        |      |               |     | 2     | 2             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 5     | 5             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 2     | 2             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 1     | 1             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 14    | 14            | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 31    | 31            | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 1     | 0             | 1             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 0     | 0             | 0             |
|             |          |                     |        |      |               |     | 1     | 1             | 0             |






Gallery Top Faults for Pump Shotguns - Current month through:



[illegible][illegible]




# Gallery Top Faults for Autoloading Shotguns - Current month through:



[illegible]

ILE00054600

# Gallery Top Faults for Police Shotguns - Current month through:



|                         | CH | CHAB | CLM | CO |
|-------------------------|----|------|-----|----|
| Closes hard             |    |      |     |    |
| Carrier hits action bar |    |      |     |    |
| Can't load magazine     |    |      |     |    |
| Cut-off                 |    |      |     |    |

through:

|                         |
|-------------------------|
| Closes hard             |
| Carrier hits action bar |
| Can't load magazine     |
| Cut-off                 |
| CH                      |
| CHAB                    |
| CLM                     |
| CO                      |

ILE00054602

|       |  |   |
|-------|--|---|
| AB    | Action binds                             | 3 |
| BLOP  | Bar lock or disconnecter out of position | 2 |
| CLM   | Can't load magazine                      | 2 |
| FFM   | Fails to feed from magazine              | 2 |
| DSM   | Drops shell-magazine                     | 1 |
| FB    | Follower binds                           | 1 |
| SCB   | Stock cracked or broken                  | 1 |
| FF-P  | Fails to fire at proof                   | 1 |
| SCB-P | Stock cracked or broken at proof         | 1 |
| ASFB  | Action spring follower binds             | 0 |
| BABS  | Bulge at body shoulder                   | 0 |
| BAC   | Burr at chamber                          | 0 |
| BB    | Bolt binds/catches                       | 0 |
| BCOE  | Bolt catches on ejector                  | 0 |
| BC    | Blows cases                              | 0 |
| BSCO  | Barrel support came out                  | 0 |
| CBS-F | Shells catch on bbl support-feeding      | 0 |
| CBS-L | Shells catch on bbl support-loading      | 0 |
| CC    | Carrier catches on shells,mag,receiver   | 0 |
| CD    | Case dented                              | 0 |
| CH    | Closes hard                              | 0 |
| CHAB  | Carrier hits action bar                  | 0 |
| CO    | Cut-off                                  | 0 |
| CR    | Cuts rim                                 | 0 |
| CS    | Cases swell                              | 0 |
| CTOG  | Chamber torn or gouged                   | 0 |
| CTP   | Creepy trigger pull                      | 0 |
| CWSB  | Cams wrong side of action bar            | 0 |
| DBB   | Doesn't blow back                        | 0 |
| DCS   | Double click in safety switch            | 0 |
| DCT   | Double click in trigger                  | 0 |
| DCU   | Doesn't close-up                         | 0 |
| DE    | Doesn't eject                            | 0 |
| DEL   | Doesn't eject live round                 | 0 |
| DFU   | Doesn't feed up                          | 0 |
| DLO   | Doesn't lock open (after last shell)     | 0 |
| DLU   | Doesn't lock-up                          | 0 |
| DS    | Dead safe                                | 0 |
| DTL   | Doesn't trip latch                       | 0 |
| DX    | Doesn't extract                          | 0 |
| DXL   | Doesn't extract live round               | 0 |
| EDS   | Extractor drops shell                    | 0 |
| ESB   | Ejector sticks back                      | 0 |
| ESS   | Extractor stems shell                    | 0 |
| FA    | Fires automatically                      | 0 |
| FC    | Fails to connect                         | 0 |
| FCB   | Fore-end cracked or broken               | 0 |
| FD    | Follows down                             | 0 |
| FF    | Fails to fire                            | 0 |
| FFP   | Flat firing pin                          | 0 |
| FOS   | Fires on safe                            | 0 |

|        |                                   |   |
|--------|-----------------------------------|---|
| FSR    | Fires when safe is released       | 0 |
| GCSO   | Gas cyl shot off                  | 0 |
| GRSO   | Guide ring shot off               | 0 |
| HPA    | High pressure ammo                | 0 |
| HUE    | Hard under extractor              | 0 |
| ILOP   | Int. latch out of position        | 0 |
| ILRM   | Int. latch ret. Missing           | 0 |
| ILSB   | Int. latch stud broken            | 0 |
| ILSP   | Int. latch spring out of position | 0 |
| JL     | Jumps latch                       | 0 |
| JO     | Jars off                          | 0 |
| LB     | Light blow                        | 0 |
| MCSO   | Magazine cap shot off             | 0 |
| MCW    | Magazine capacity wrong           | 0 |
| MFA    | Misfires (ammo)                   | 0 |
| MFOP   | Magazine follower out of position | 0 |
| MLH    | Magazine loads hard               | 0 |
| OH     | Opens hard                        | 0 |
| PH     | Pulls hard                        | 0 |
| PSI    | Proof stamp illegible             | 0 |
| PSM    | Proof stamp missing               | 0 |
| RBOC   | Rings and bulges on case          | 0 |
| RDW    | (Action) release doesn't work     | 0 |
| RIC    | Rings in chamber                  | 0 |
| SBC    | Stems bottom chambers             | 0 |
| SBCL   | Shell binds carrier latch         | 0 |
| SBE    | Stems bbl extension               | 0 |
| SCX    | Shell catches                     | 0 |
| SHI    | Short indent                      | 0 |
| SIC    | Stems in chamber                  | 0 |
| SL     | shaves lead                       | 0 |
| SLC    | Stems left side of chamber        | 0 |
| SMOC   | Stretch marks on case             | 0 |
| SRC    | Stems right side of chamber       | 0 |
| SRIC   | Specific rings in chamber         | 0 |
| SSC    | shell stems carrier               | 0 |
| STC    | Stems top chamber                 | 0 |
| SWE    | Safety switch works too easily    | 0 |
| SWH    | Safety switch works too hard      | 0 |
| SWW    | Safety switch won't work          | 0 |
| TD     | Tips down                         | 0 |
| TU     | Tips up                           | 0 |
| TWP    | Trigger won't pull                | 0 |
| TWR    | Trigger won't retract             | 0 |
| UNCN-T | Uncoded                           | 0 |
| XH     | Extracts hard                     | 0 |
| XHB    | Extractor hits bbl                | 0 |
|        |                                   | 0 |
| HI     | High                              | 0 |
| LO     | Low                               | 0 |
| LEFT   | Left                              | 0 |

|        |                                   |   |
|--------|-----------------------------------|---|
| RIGHT  | Right                             | 0 |
| DG     | Doesn't Group                     | 0 |
| FSST   | Front sight tipped                | 0 |
| RSTT   | Rear sight tipped                 | 0 |
| RSBR   | Rear sight base raised            | 0 |
| FSTR   | Front sight raised                | 0 |
| FSTL   | Front sight loose                 | 0 |
| RSTL   | Rear sight loose                  | 0 |
| MGPT-G | Missing parts at target           | 0 |
| UNCN-G | Uncoded nonconformity at target   | 0 |
| AI-P   | Assembly incomplete at proof      | 0 |
| BC-P   | Blows cases at proof              | 0 |
| BEB-P  | Barrel extension broken at proof  | 0 |
| BLP-P  | Blanked primer at proof           | 0 |
| BP-P   | Blown primer at proof             | 0 |
| BS-P   | Barrel split at proof             | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P  | Ejector sticks back at proof      | 0 |
| FCB-P  | Fore-end cracked at proof         | 0 |
| FESO-P | Fore-end shot off at proof        | 0 |
| GCSO-P | Gas cylinder shot off at proof    | 0 |
| GRSO-P | Guide ring shot off at proof      | 0 |
| MCSO-P | Magazine cap shot off at proof    | 0 |
| MSI-P  | Magnaflux stamp illegible on bbl  | 0 |
| MSM-P  | Magnaflux stamp missing on bbl    | 0 |
| PP-P   | Pierced primer at proof           | 0 |
| UNCM-P | Uncoded proof malfunctions        | 0 |
|        |                                   |   |

|       |  |    |
|-------|--|----|
| DBB   | Doesn't blow back                        | 41 |
| SBC   | Stems bottom chambers                    | 19 |
| FFM   | Fails to feed from magazine              | 12 |
| RDW   | (Action) release doesn't work            | 11 |
| STC   | Stems top chamber                        | 11 |
| DFU   | Doesn't feed up                          | 8  |
| HUE   | Hard under extractor                     | 6  |
| EDS   | Extractor drops shell                    | 5  |
| SLC   | Stems left side of chamber               | 5  |
| DE    | Doesn't eject                            | 4  |
| CC    | Carrier catches on shells,mag,receiver   | 3  |
| JL    | Jumps latch                              | 3  |
| DSM   | Drops shell-magazine                     | 2  |
| MCW   | Magazine capacity wrong                  | 2  |
| DS    | Dead safe                                | 1  |
| FF    | Fails to fire                            | 1  |
| ILRM  | Int. latch ret. Missing                  | 1  |
| MLH   | Magazine loads hard                      | 1  |
| FF-P  | Fails to fire at proof                   | 1  |
| AB    | Action binds                             | 0  |
| ASFB  | Action spring follower binds             | 0  |
| BABS  | Bulge at body shoulder                   | 0  |
| BAC   | Burr at chamber                          | 0  |
| BB    | Bolt binds/catches                       | 0  |
| BCOE  | Bolt catches on ejector                  | 0  |
| BC    | Blows cases                              | 0  |
| BLOP  | Bar lock or disconnecter out of position | 0  |
| BSCO  | Barrel support came out                  | 0  |
| CBS-F | Shells catch on bbl support-feeding      | 0  |
| CBS-L | Shells catch on bbl support-loading      | 0  |
| CD    | Case dented                              | 0  |
| CH    | Closes hard                              | 0  |
| CHAB  | Carrier hits action bar                  | 0  |
| CLM   | Can't load magazine                      | 0  |
| CO    | Cut-off                                  | 0  |
| CR    | Cuts rim                                 | 0  |
| CS    | Cases swell                              | 0  |
| CTOG  | Chamber torn or gouged                   | 0  |
| CTP   | Creepy trigger pull                      | 0  |
| CWSB  | Cams wrong side of action bar            | 0  |
| DCS   | Double click in safety switch            | 0  |
| DCT   | Double click in trigger                  | 0  |
| DCU   | Doesn't close-up                         | 0  |
| DEL   | Doesn't eject live round                 | 0  |
| DLO   | Doesn't lock open (after last shell)     | 0  |
| DLU   | Doesn't lock-up                          | 0  |
| DTL   | Doesn't trip latch                       | 0  |
| DX    | Doesn't extract                          | 0  |
| DXL   | Doesn't extract live round               | 0  |
| ESB   | Ejector sticks back                      | 0  |
| ESS   | Extractor stems shell                    | 0  |



|        |                                   |   |
|--------|-----------------------------------|---|
| FA     | Fires automatically               | 0 |
| FB     | Follower binds                    | 0 |
| FC     | Fails to connect                  | 0 |
| FCB    | Fore-end cracked or broken        | 0 |
| FD     | Follows-down                      | 0 |
| FFP    | Flat firing pin                   | 0 |
| FOS    | Fires on safe                     | 0 |
| FSR    | Fires when safe is released       | 0 |
| GCSO   | Gas cyl shot off                  | 0 |
| GRSO   | Guide ring shot off               | 0 |
| HPA    | High pressure ammo                | 0 |
| ILOP   | Int. latch out of position        | 0 |
| ILSB   | Int. latch stud broken            | 0 |
| ILSP   | Int. latch spring out of position | 0 |
| JO     | Jars off                          | 0 |
| LB     | Light blow                        | 0 |
| MCSO   | Magazine cap shot off             | 0 |
| MFA    | Misfires (ammo)                   | 0 |
| MFOP   | Magazine follower out of position | 0 |
| OH     | Opens hard                        | 0 |
| PH     | Pulls hard                        | 0 |
| PSI    | Proof stamp illegible             | 0 |
| PSM    | Proof stamp missing               | 0 |
| RBOC   | Rings and bulges on case          | 0 |
| RIC    | Rings in chamber                  | 0 |
| SBCL   | Shell binds carrier latch         | 0 |
| SBE    | Stems bbl extension               | 0 |
| SCB    | Stock cracked or broken           | 0 |
| SCX    | Shell catches                     | 0 |
| SHI    | Short indent                      | 0 |
| SIC    | Stems in chamber                  | 0 |
| SL     | shaves lead                       | 0 |
| SMOC   | Stretch marks on case             | 0 |
| SRC    | Stems right side of chamber       | 0 |
| SRIC   | Specific rings in chamber         | 0 |
| SSC    | shell stems carrier               | 0 |
| SWE    | Safety switch works too easily    | 0 |
| SWH    | Safety switch works too hard      | 0 |
| SWW    | Safety switch won't work          | 0 |
| TD     | Tips down                         | 0 |
| TU     | Tips up                           | 0 |
| TWP    | Trigger won't pull                | 0 |
| TWR    | Trigger won't retract             | 0 |
| UNCN-T | Uncoded                           | 0 |
| XH     | Extracts hard                     | 0 |
| XHB    | Extractor hits bbl                | 0 |
| HI     | High                              | 0 |
| LO     | Low                               | 0 |
| LEFT   | Left                              | 0 |
| RIGHT  | Right                             | 0 |
| DG     | Doesn't Group                     | 0 |

|        |                                   |   |
|--------|-----------------------------------|---|
| FSST   | Front sight tipped                | 0 |
| RSTT   | Rear sight tipped                 | 0 |
| RSBR   | Rear sight base raised            | 0 |
| FSTR   | Front sight raised                | 0 |
| FSTL   | Front sight loose                 | 0 |
| RSTL   | Rear sight loose                  | 0 |
| MGPT-G | Missing parts at target           | 0 |
| UNCN-G | Uncoded nonconformity at target   | 0 |
| AI-P   | Assembly incomplete at proof      | 0 |
| BC-P   | Blows cases at proof              | 0 |
| BEB-P  | Barrel extension broken at proof  | 0 |
| BLP-P  | Blanked primer at proof           | 0 |
| BP-P   | Blown primer at proof             | 0 |
| BS-P   | Barrel split at proof             | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P  | Ejector sticks back at proof      | 0 |
| FCB-P  | Fore-end cracked at proof         | 0 |
| FESO-P | Fore-end shot off at proof        | 0 |
| GCSO-P | Gas cylinder shot off at proof    | 0 |
| GRSO-P | Guide ring shot off at proof      | 0 |
| MCSO-P | Magazine cap shot off at proof    | 0 |
| MSI-P  | Magnaflux stamp illegible on bbl  | 0 |
| MSM-P  | Magnaflux stamp missing on bbl    | 0 |
| PP-P   | Pierced primer at proof           | 0 |
| SCB-P  | Stock cracked or broken at proof  | 0 |
| UNCM-P | Uncoded proof malfunctions        | 0 |
|        |                                   |   |
|        |                                   |   |

|       |  |   |
|-------|--|---|
| RIGHT | Right                                    | 6 |
| DLU   | Doesn't lock-up                          | 3 |
| LO    | Low                                      | 1 |
| AB    | Action binds                             | 0 |
| ASFB  | Action spring follower binds             | 0 |
| BABS  | Bulge at body shoulder                   | 0 |
| BAC   | Burr at chamber                          | 0 |
| BB    | Bolt binds/catches                       | 0 |
| BCOE  | Bolt catches on ejector                  | 0 |
| BC    | Blows cases                              | 0 |
| BLOP  | Bar lock or disconnecter out of position | 0 |
| BSCO  | Barrel support came out                  | 0 |
| CBS-F | Shells catch on bbl support-feeding      | 0 |
| CBS-L | Shells catch on bbl support-loading      | 0 |
| CC    | Carrier catches on shells,mag,receiver   | 0 |
| CD    | Case dented                              | 0 |
| CH    | Closes hard                              | 0 |
| CHAB  | Carrier hits action bar                  | 0 |
| CLM   | Can't load magazine                      | 0 |
| CO    | Cut-off                                  | 0 |
| CR    | Cuts rim                                 | 0 |
| CS    | Cases swell                              | 0 |
| CTOG  | Chamber torn or gouged                   | 0 |
| CTP   | Creepy trigger pull                      | 0 |
| CWSB  | Cams wrong side of action bar            | 0 |
| DBB   | Doesn't blow back                        | 0 |
| DCS   | Double click in safety switch            | 0 |
| DCT   | Double click in trigger                  | 0 |
| DCU   | Doesn't close-up                         | 0 |
| DE    | Doesn't eject                            | 0 |
| DEL   | Doesn't eject live round                 | 0 |
| DFU   | Doesn't feed up                          | 0 |
| DLO   | Doesn't lock open (after last shell)     | 0 |
| DS    | Dead safe                                | 0 |
| DSM   | Drops shell-magazine                     | 0 |
| DTL   | Doesn't trip latch                       | 0 |
| DX    | Doesn't extract                          | 0 |
| DXL   | Doesn't extract live round               | 0 |
| EDS   | Extractor drops shell                    | 0 |
| ESB   | Ejector sticks back                      | 0 |
| ESS   | Extractor stems shell                    | 0 |
| FA    | Fires automatically                      | 0 |
| FB    | Follower binds                           | 0 |
| FC    | Fails to connect                         | 0 |
| FCB   | Fore-end cracked or broken               | 0 |
| FD    | Follows-down                             | 0 |
| FF    | Fails to fire                            | 0 |
| FFM   | Fails to feed from magazine              | 0 |
| FFP   | Flat firing pin                          | 0 |
| FOS   | Fires on safe                            | 0 |
| FSR   | Fires when safe is released              | 0 |

|        |                                   |   |
|--------|-----------------------------------|---|
| GCSO   | Gas cyl shot off                  | 0 |
| GRSO   | Guide ring shot off               | 0 |
| HPA    | High pressure ammo                | 0 |
| HUE    | Hard under extractor              | 0 |
| ILOP   | Int. latch out of position        | 0 |
| ILRM   | Int. latch ret. Missing           | 0 |
| ILSB   | Int. latch stud broken            | 0 |
| ILSP   | Int. latch spring out of position | 0 |
| JL     | Jumps latch                       | 0 |
| JO     | Jars off                          | 0 |
| LB     | Light blow                        | 0 |
| MCSO   | Magazine cap shot off             | 0 |
| MCW    | Magazine capacity wrong           | 0 |
| MFA    | Misfires (ammo)                   | 0 |
| MFOP   | Magazine follower out of position | 0 |
| MLH    | Magazine loads hard               | 0 |
| OH     | Opens hard                        | 0 |
| PH     | Pulls hard                        | 0 |
| PSI    | Proof stamp illegible             | 0 |
| PSM    | Proof stamp missing               | 0 |
| RBOC   | Rings and bulges on case          | 0 |
| RDW    | (Action) release doesn't work     | 0 |
| RIC    | Rings in chamber                  | 0 |
| SBC    | Stems bottom chambers             | 0 |
| SBCL   | Shell binds carrier latch         | 0 |
| SBE    | Stems bbl extension               | 0 |
| SCB    | Stock cracked or broken           | 0 |
| SCX    | Shell catches                     | 0 |
| SHI    | Short indent                      | 0 |
| SIC    | Stems in chamber                  | 0 |
| SL     | shaves lead                       | 0 |
| SLC    | Stems left side of chamber        | 0 |
| SMOC   | Stretch marks on case             | 0 |
| SRC    | Stems right side of chamber       | 0 |
| SRIC   | Specific rings in chamber         | 0 |
| SSC    | shell stems carrier               | 0 |
| STC    | Stems top chamber                 | 0 |
| SWE    | Safety switch works too easily    | 0 |
| SWH    | Safety switch works too hard      | 0 |
| SWW    | Safety switch won't work          | 0 |
| TD     | Tips down                         | 0 |
| TU     | Tips up                           | 0 |
| TWP    | Trigger won't pull                | 0 |
| TWR    | Trigger won't retract             | 0 |
| UNCN-T | Uncoded                           | 0 |
| XH     | Extracts hard                     | 0 |
| XHB    | Extractor hits bbl                | 0 |
| HI     | High                              | 0 |
| LEFT   | Left                              | 0 |
| DG     | Doesn't Group                     | 0 |
| FSST   | Front sight tipped                | 0 |

|        |                                   |   |
|--------|-----------------------------------|---|
| RSTT   | Rear sight tipped                 | 0 |
| RSBR   | Rear sight base raised            | 0 |
| FSTR   | Front sight raised                | 0 |
| FSTL   | Front sight loose                 | 0 |
| RSTL   | Rear sight loose                  | 0 |
| MGPT-G | Missing parts at target           | 0 |
| UNCN-G | Uncoded nonconformity at target   | 0 |
|        |                                   | 0 |
| AI-P   | Assembly incomplete at proof      | 0 |
| BC-P   | Blows cases at proof              | 0 |
| BEB-P  | Barrel extension broken at proof  | 0 |
| BLP-P  | Blanked primer at proof           | 0 |
| BP-P   | Blown primer at proof             | 0 |
| BS-P   | Barrel split at proof             | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P  | Ejector sticks back at proof      | 0 |
| FCB-P  | Fore-end cracked at proof         | 0 |
| FESO-P | Fore-end shot off at proof        | 0 |
| FF-P   | Fails to fire at proof            | 0 |
| GCSO-P | Gas cylinder shot off at proof    | 0 |
| GRSO-P | Guide ring shot off at proof      | 0 |
| MCSO-P | Magazine cap shot off at proof    | 0 |
| MSI-P  | Magnaflux stamp illegible on bbl  | 0 |
| MSM-P  | Magnaflux stamp missing on bbl    | 0 |
| PP-P   | Pierced primer at proof           | 0 |
| SCB-P  | Stock cracked or broken at proof  | 0 |
| UNCM-P | Uncoded proof malfunctions        | 0 |
|        |                                   | 0 |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

| CODE | MALFUNCTION INDEX                    | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|------|--------------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| CHAB | Carrier hits action bar              |                      |              |              |              |              |              |              |               |             |             |
| CLM  | Can't load magazine                  |                      |              |              |              |              |              |              |               |             |             |
| CO   | Cut-off                              |                      |              |              |              |              |              |              |               |             |             |
| CR   | Cuts rim                             |                      |              |              |              |              |              |              |               |             |             |
| CS   | Cases swell                          |                      |              |              |              |              |              |              |               |             |             |
| CTOG | Chamber torn or gouged               |                      |              |              |              |              |              |              |               |             |             |
| CTP  | Creepy trigger pull                  |                      |              |              |              |              |              |              |               |             |             |
| CWSB | Cams wrong side of action bar        |                      |              |              |              |              |              |              |               |             |             |
| DBB  | Doesn't blow back                    |                      |              |              |              |              |              |              |               |             |             |
| DCS  | Double click in safety switch        |                      |              |              |              |              |              |              |               |             |             |
| DCT  | Double click in trigger              |                      |              |              |              |              |              |              |               |             |             |
| DCU  | Doesn't close-up                     |                      |              |              |              |              |              |              |               |             |             |
| DE   | Doesn't eject                        |                      |              |              |              |              |              |              |               |             |             |
| DEL  | Doesn't eject live round             |                      |              |              |              |              |              |              |               |             |             |
| DFU  | Doesn't feed up                      |                      |              |              |              |              |              |              |               |             |             |
| DLO  | Doesn't lock open (after last shell) |                      |              |              |              |              |              |              |               |             |             |
| DLU  | Doesn't lock-up                      |                      |              |              |              |              |              |              |               |             |             |
| DS   | Dead safe                            |                      |              |              |              |              |              |              |               |             |             |
| DSM  | Drops shell-magazine                 |                      |              |              |              |              |              |              |               |             |             |
| DTL  | Doesn't trip latch                   |                      |              |              |              |              |              |              |               |             |             |
| DX   | Doesn't extract                      |                      |              |              |              |              |              |              |               |             |             |
| DXL  | Doesn't extract live round           |                      |              |              |              |              |              |              |               |             |             |
| EDS  | Extractor drops shell                |                      |              |              |              |              |              |              |               |             |             |
| ESB  | Ejector sticks back                  |                      |              |              |              |              |              |              |               |             |             |
| ESS  | Extractor stems shell                |                      |              |              |              |              |              |              |               |             |             |

| CODE | MALFUNCTION INDEX                 | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|------|-----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| FA   | Fires automatically               |                      |              |              |              |              |              |              |               |             |             |
| FB   | Follower binds                    |                      |              |              |              |              |              |              |               |             |             |
| FC   | Fails to connect                  |                      |              |              |              |              |              |              |               |             |             |
| FCB  | Fore-end cracked or broken        |                      |              |              |              |              |              |              |               |             |             |
| FD   | Follows-down                      |                      |              |              |              |              |              |              |               |             |             |
| FF   | Fails to fire                     |                      |              |              |              |              |              |              |               |             |             |
| FFM  | Fails to feed from magazine       |                      |              |              |              |              |              |              |               |             |             |
| FFP  | Flat firing pin                   |                      |              |              |              |              |              |              |               |             |             |
| FOS  | Fires on safe                     |                      |              |              |              |              |              |              |               |             |             |
| FSR  | Fires when safe is released       |                      |              |              |              |              |              |              |               |             |             |
| GCSO | Gas cyl shot off                  |                      |              |              |              |              |              |              |               |             |             |
| GRSO | Guide ring shot off               |                      |              |              |              |              |              |              |               |             |             |
| HPA  | High pressure ammo                |                      |              |              |              |              |              |              |               |             |             |
| HUE  | Hard under extractor              |                      |              |              |              |              |              |              |               |             |             |
| ILOP | Int. latch out of position        |                      |              |              |              |              |              |              |               |             |             |
| ILRM | Int. latch ret. Missing           |                      |              |              |              |              |              |              |               |             |             |
| ILSB | Int. latch stud broken            |                      |              |              |              |              |              |              |               |             |             |
| ILSP | Int. latch spring out of position |                      |              |              |              |              |              |              |               |             |             |
| JL   | Jumps latch                       |                      |              |              |              |              |              |              |               |             |             |
| JO   | Jars off                          |                      |              |              |              |              |              |              |               |             |             |
| LB   | Light blow                        |                      |              |              |              |              |              |              |               |             |             |
| MCSO | Magazine cap shot off             |                      |              |              |              |              |              |              |               |             |             |
| MCW  | Magazine capacity wrong           |                      |              |              |              |              |              |              |               |             |             |
| MFA  | Misfires (ammo)                   |                      |              |              |              |              |              |              |               |             |             |
| MFOP | Magazine follower out of position |                      |              |              |              |              |              |              |               |             |             |



| CODE | MALFUNCTION INDEX              | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|------|--------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| MLH  | Magazine loads hard            |                      |              |              |              |              |              |              |               |             |             |
| OH   | Opens hard                     |                      |              |              |              |              |              |              |               |             |             |
| PH   | Pulls hard                     |                      |              |              |              |              |              |              |               |             |             |
| PSI  | Proof stamp illegible          |                      |              |              |              |              |              |              |               |             |             |
| PSM  | Proof stamp missing            |                      |              |              |              |              |              |              |               |             |             |
| RBOC | Rings and bulges on case       |                      |              |              |              |              |              |              |               |             |             |
| RDW  | (Action) release doesn't work  |                      |              |              |              |              |              |              |               |             |             |
| RIC  | Rings in chamber               |                      |              |              |              |              |              |              |               |             |             |
| SBC  | Stems bottom chambers          |                      |              |              |              |              |              |              |               |             |             |
| SBCL | Shell binds carrier latch      |                      |              |              |              |              |              |              |               |             |             |
| SBE  | Stems bbl extension            |                      |              |              |              |              |              |              |               |             |             |
| SCB  | Stock cracked or broken        |                      |              |              |              |              |              |              |               |             |             |
| SCX  | Shell catches                  |                      |              |              |              |              |              |              |               |             |             |
| SHI  | Short indent                   |                      |              |              |              |              |              |              |               |             |             |
| SIC  | Stems in chamber               |                      |              |              |              |              |              |              |               |             |             |
| SL   | shaves lead                    |                      |              |              |              |              |              |              |               |             |             |
| SLC  | Stems left side of chamber     |                      |              |              |              |              |              |              |               |             |             |
| SMOC | Stretch marks on case          |                      |              |              |              |              |              |              |               |             |             |
| SRC  | Stems right side of chamber    |                      |              |              |              |              |              |              |               |             |             |
| SRIC | Specific rings in chamber      |                      |              |              |              |              |              |              |               |             |             |
| SSC  | shell stems carrier            |                      |              |              |              |              |              |              |               |             |             |
| STC  | Stems top chamber              |                      |              |              |              |              |              |              |               |             |             |
| SWE  | Safety switch works too easily |                      |              |              |              |              |              |              |               |             |             |
| SWH  | Safety switch works too hard   |                      |              |              |              |              |              |              |               |             |             |
| SWW  | Safety ewitxh won't work       |                      |              |              |              |              |              |              |               |             |             |

| CODE   | MALFUNCTION INDEX                | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|--------|----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| TD     | Tips down                        |                      |              |              |              |              |              |              |               |             |             |
| TU     | Tips up                          |                      |              |              |              |              |              |              |               |             |             |
| TWP    | Trigger won't pull               |                      |              |              |              |              |              |              |               |             |             |
| TWR    | Trigger won't retract            |                      |              |              |              |              |              |              |               |             |             |
| UNCN-T | Uncoded                          |                      |              |              |              |              |              |              |               |             |             |
| XH     | Extracts hard                    |                      |              |              |              |              |              |              |               |             |             |
| XHB    | Extractor hits bbl               |                      |              |              |              |              |              |              |               |             |             |
|        |                                  |                      |              |              |              |              |              |              |               |             |             |
| HI     | High                             |                      |              |              |              |              |              |              |               |             |             |
| LO     | Low                              |                      |              |              |              |              |              |              |               |             |             |
| LEFT   | Left                             |                      |              |              |              |              |              |              |               |             |             |
| RIGHT  | Right                            |                      |              |              |              |              |              |              |               |             |             |
| DG     | Doesn't Group                    |                      |              |              |              |              |              |              |               |             |             |
| FSST   | Front sight tipped               |                      |              |              |              |              |              |              |               |             |             |
| RSTT   | Rear sight tipped                |                      |              |              |              |              |              |              |               |             |             |
| RSBR   | Rear sight base raised           |                      |              |              |              |              |              |              |               |             |             |
| FSTR   | Front sight raised               |                      |              |              |              |              |              |              |               |             |             |
| FSTL   | Front sight loose                |                      |              |              |              |              |              |              |               |             |             |
| RSTL   | Rear sight loose                 |                      |              |              |              |              |              |              |               |             |             |
| MGPT-G | Missing parts at target          |                      |              |              |              |              |              |              |               |             |             |
| UNCN-G | Uncoded nonconformity at target  |                      |              |              |              |              |              |              |               |             |             |
|        |                                  |                      |              |              |              |              |              |              |               |             |             |
| AI-P   | Assembly incomplete at proof     |                      |              |              |              |              |              |              |               |             |             |
| BC-P   | Blows cases at proof             |                      |              |              |              |              |              |              |               |             |             |
| BEB-P  | Barrel extension broken at proof |                      |              |              |              |              |              |              |               |             |             |

| CODE   | MALFUNCTION INDEX                 | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|--------|-----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| BLP-P  | Blanked primer at proof           |                      |              |              |              |              |              |              |               |             |             |
| BP-P   | Blown primer at proof             |                      |              |              |              |              |              |              |               |             |             |
| BS-P   | Barrel split at proof             |                      |              |              |              |              |              |              |               |             |             |
| DLOS-P | Doesn't lock over shells at proof |                      |              |              |              |              |              |              |               |             |             |
| ESB-P  | Ejector sticks back at proof      |                      |              |              |              |              |              |              |               |             |             |
| FCB-P  | Fore-end cracked at proof         |                      |              |              |              |              |              |              |               |             |             |
| FESO-P | Fore-end shot off at proof        |                      |              |              |              |              |              |              |               |             |             |
| FF-P   | Fails to fire at proof            |                      |              |              |              |              |              |              |               |             |             |
| GCSO-P | Gas cylinder shot off at proof    |                      |              |              |              |              |              |              |               |             |             |
| GRSO-P | Guide ring shot off at proof      |                      |              |              |              |              |              |              |               |             |             |
| MCSO-P | Magazine cap shot off at proof    |                      |              |              |              |              |              |              |               |             |             |
| MSI-P  | Magnaflux stamp illegible on bbl  |                      |              |              |              |              |              |              |               |             |             |
| MSM-P  | Magnaflux stamp missing on bbl    |                      |              |              |              |              |              |              |               |             |             |
| PP-P   | Pierced primer at proof           |                      |              |              |              |              |              |              |               |             |             |
| SCB-P  | Stock cracked or broken at proof  |                      |              |              |              |              |              |              |               |             |             |
| UNCM-P | Uncoded proof malfunctions        |                      |              |              |              |              |              |              |               |             |             |

| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |

ILE00054618

[illegible]

[illegible]

[illegible]







|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

**CONFIDENTIAL**

**Test Date:**

|   |   |   |   |   |
|---|---|---|---|---|
| 0 | 0 | 0 | 0 | 0 |
|---|---|---|---|---|

|   |   |   |   |   |
|---|---|---|---|---|
| 0 | 0 | 0 | 0 | 0 |
|---|---|---|---|---|

|   |   |   |   |   |
|---|---|---|---|---|
| 0 | 0 | 0 | 0 | 0 |
|---|---|---|---|---|

| 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U |
|----------|------------------|--------|------|------------|-----|
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |
|          |                  |        |      |            |     |

ive Order - Williams v. Remington











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |             |
|----------------|------------------------------------|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>1312</b> |
|                | <b>Total Rejected:</b>             | <b>13</b>   |
|                | <b>Overall Reject Rate:</b>        | <b>0.99</b> |

**Proof**

|           |     |   |     |   |   |   |   |   |     |   |
|-----------|-----|---|-----|---|---|---|---|---|-----|---|
| Shot:     | 4   |   | 172 |   |   |   |   |   | 856 |   |
| Rejected: | 0   | 0 | 0   | 0 | 0 | 0 | 0 | 0 | 0   | 0 |
| Percent:  | 0.0 |   | 0.0 |   |   |   |   |   | 0.0 |   |

**Test**

|           |     |   |     |   |   |   |   |      |     |   |
|-----------|-----|---|-----|---|---|---|---|------|-----|---|
| Shot:     | 42  |   | 145 |   |   |   |   | 13   | 856 |   |
| Rejected: | 2   | 0 | 7   | 0 | 0 | 0 | 0 | 3    | 1   | 0 |
| Percent:  | 4.8 |   | 4.8 |   |   |   |   | 23.1 | 0.1 |   |

**Target**

|           |   |   |   |   |   |   |   |   |   |   |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot:     |   |   |   |   |   |   |   |   |   |   |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent:  |   |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |   |  |  |  |  |   |  |  |  |
|------|--------------------------------------|--|--|---|--|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar              |  |  |   |  |  |  |  |   |  |  |  |
| CLM  | Can't load magazine                  |  |  |   |  |  |  |  |   |  |  |  |
| CO   | Cut-off                              |  |  |   |  |  |  |  |   |  |  |  |
| CR   | Cuts rim                             |  |  |   |  |  |  |  |   |  |  |  |
| CS   | Cases swell                          |  |  |   |  |  |  |  |   |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |   |  |  |  |  |   |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |   |  |  |  |  |   |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |   |  |  |  |  |   |  |  |  |
| DBB  | Doesn't blow back                    |  |  | 4 |  |  |  |  | 1 |  |  |  |
| DCS  | Double click in safety switch        |  |  |   |  |  |  |  |   |  |  |  |
| DCT  | Double click in trigger              |  |  |   |  |  |  |  |   |  |  |  |
| DCU  | Doesn't close-up                     |  |  |   |  |  |  |  |   |  |  |  |
| DE   | Doesn't eject                        |  |  |   |  |  |  |  |   |  |  |  |
| DEL  | Doesn't eject live round             |  |  |   |  |  |  |  |   |  |  |  |
| DFU  | Doesn't feed up                      |  |  |   |  |  |  |  |   |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |   |  |  |  |  |   |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |   |  |  |  |  |   |  |  |  |
| DS   | Dead safe                            |  |  |   |  |  |  |  |   |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |   |  |  |  |  |   |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |   |  |  |  |  |   |  |  |  |
| DX   | Doesn't extract                      |  |  |   |  |  |  |  |   |  |  |  |
| DXL  | Doesn't extract live round           |  |  |   |  |  |  |  |   |  |  |  |
| EDS  | Extractor drops shell                |  |  |   |  |  |  |  | 2 |  |  |  |
| ESB  | Ejector sticks back                  |  |  |   |  |  |  |  |   |  |  |  |
| ESS  | Extractor stems shell                |  |  |   |  |  |  |  |   |  |  |  |
| FA   | Fires automatically                  |  |  |   |  |  |  |  |   |  |  |  |
| FB   | Follower binds                       |  |  |   |  |  |  |  |   |  |  |  |

|      |                                   |   |  |   |  |  |  |  |  |  |  |  |
|------|-----------------------------------|---|--|---|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |   |  |   |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |   |  |   |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |   |  |   |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |   |  |   |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |   |  |   |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |   |  |   |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |   |  |   |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |   |  |   |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |   |  |   |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |   |  |   |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |   |  |   |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              | 1 |  |   |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |   |  |   |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |   |  | 1 |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |   |  |   |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |   |  |   |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |   |  |   |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |   |  |   |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |   |  |   |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |   |  |   |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |   |  |   |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |   |  |   |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |   |  |   |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |   |  |   |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |   |  |   |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |   |  |   |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |   |  |   |  |  |  |  |  |  |  |  |



|        |                                |   |  |   |  |  |  |  |  |   |  |  |
|--------|--------------------------------|---|--|---|--|--|--|--|--|---|--|--|
| PSM    | Proof stamp missing            |   |  |   |  |  |  |  |  |   |  |  |
| RBOC   | Rings and bulges on case       |   |  |   |  |  |  |  |  |   |  |  |
| RDW    | (Action) release doesn't work  |   |  | 2 |  |  |  |  |  |   |  |  |
| RIC    | Rings in chamber               |   |  |   |  |  |  |  |  |   |  |  |
| SBC    | Stems bottom chambers          | 1 |  |   |  |  |  |  |  |   |  |  |
| SBCL   | Shell binds carrier latch      |   |  |   |  |  |  |  |  |   |  |  |
| SBE    | Stems bbl extension            |   |  |   |  |  |  |  |  |   |  |  |
| SCB    | Stock cracked or broken        |   |  |   |  |  |  |  |  | 1 |  |  |
| SCX    | Shell catches                  |   |  |   |  |  |  |  |  |   |  |  |
| SHI    | Short indent                   |   |  |   |  |  |  |  |  |   |  |  |
| SIC    | Stems in chamber               |   |  |   |  |  |  |  |  |   |  |  |
| SL     | shaves lead                    |   |  |   |  |  |  |  |  |   |  |  |
| SLC    | Stems left side of chamber     |   |  |   |  |  |  |  |  |   |  |  |
| SMOC   | Stretch marks on case          |   |  |   |  |  |  |  |  |   |  |  |
| SRC    | Stems right side of chamber    |   |  |   |  |  |  |  |  |   |  |  |
| SRIC   | Specific rings in chamber      |   |  |   |  |  |  |  |  |   |  |  |
| SSC    | shell stems carrier            |   |  |   |  |  |  |  |  |   |  |  |
| STC    | Stems top chamber              |   |  |   |  |  |  |  |  |   |  |  |
| SWE    | Safety switch works too easily |   |  |   |  |  |  |  |  |   |  |  |
| SWH    | Safety switch works too hard   |   |  |   |  |  |  |  |  |   |  |  |
| SWW    | Safety ewitxh won't work       |   |  |   |  |  |  |  |  |   |  |  |
| TD     | Tips down                      |   |  |   |  |  |  |  |  |   |  |  |
| TU     | Tips up                        |   |  |   |  |  |  |  |  |   |  |  |
| TWP    | Trigger won't pull             |   |  |   |  |  |  |  |  |   |  |  |
| TWR    | Trigger won't retract          |   |  |   |  |  |  |  |  |   |  |  |
| UNCN-T | Uncoded                        |   |  |   |  |  |  |  |  |   |  |  |
| XH     | Extracts hard                  |   |  |   |  |  |  |  |  |   |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| Test Date: |     |     |  |     |
|------------|-----|-----|--|-----|
| 85         | 101 | 59  |  |     |
| 0          | 0   | 0   |  | 0   |
| 0.0        | 0.0 | 0.0 |  |     |
| 85         | 101 | 70  |  |     |
| 0          | 0   | 0   |  | 0   |
| 0.0        | 0.0 | 0.0 |  |     |
| 0          | 0   | 11  |  | 0   |
|            |     |     |  | 0.0 |

|     |   |     |   |     |
|-----|---|-----|---|-----|
| 85  |   | 101 |   | 59  |
| 0   | 0 | 0   | 0 | 0   |
| 0.0 |   | 0.0 |   | 0.0 |
| 85  |   | 101 |   | 70  |
| 0   | 0 | 0   | 0 | 0   |
| 0.0 |   | 0.0 |   | 0.0 |
| 0   | 0 | 0   | 0 | 0   |
| 0.0 |   | 0.0 |   | 0.0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |             |
|----------------|------------------------------------|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>1165</b> |
|                | <b>Total Rejected:</b>             | <b>27</b>   |
|                | <b>Overall Reject Rate:</b>        | <b>2.32</b> |

|               |           |     |     |      |   |     |   |   |     |   |
|---------------|-----------|-----|-----|------|---|-----|---|---|-----|---|
| <b>Proof</b>  | Shot:     | 53  | 90  |      |   | 79  |   |   | 764 |   |
|               | Rejected: | 0   | 0   | 0    | 0 | 0   | 0 | 0 | 0   | 0 |
|               | Percent:  | 0.0 | 0.0 |      |   | 0.0 |   |   | 0.0 |   |
| <b>Test</b>   | Shot:     | 53  | 195 |      |   |     |   |   | 764 |   |
|               | Rejected: | 0   | 1   | 22   | 0 | 0   | 0 | 0 | 2   | 0 |
|               | Percent:  |     | 1.9 | 11.3 |   |     |   |   | 0.3 |   |
| <b>Target</b> | Shot:     | 5   |     |      |   |     |   |   |     |   |
|               | Rejected: | 0   | 0   | 0    | 0 | 0   | 0 | 0 | 0   | 0 |
|               | Percent:  | 0.0 |     |      |   |     |   |   |     |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |    |  |  |  |  |  |   |  |  |
|------|--------------------------------------|--|--|----|--|--|--|--|--|---|--|--|
| CHAB | Carrier hits action bar              |  |  |    |  |  |  |  |  |   |  |  |
| CLM  | Can't load magazine                  |  |  |    |  |  |  |  |  |   |  |  |
| CO   | Cut-off                              |  |  |    |  |  |  |  |  |   |  |  |
| CR   | Cuts rim                             |  |  |    |  |  |  |  |  |   |  |  |
| CS   | Cases swell                          |  |  |    |  |  |  |  |  |   |  |  |
| CTOG | Chamber torn or gouged               |  |  |    |  |  |  |  |  |   |  |  |
| CTP  | Creepy trigger pull                  |  |  |    |  |  |  |  |  |   |  |  |
| CWSB | Cams wrong side of action bar        |  |  |    |  |  |  |  |  |   |  |  |
| DBB  | Doesn't blow back                    |  |  | 15 |  |  |  |  |  |   |  |  |
| DCS  | Double click in safety switch        |  |  |    |  |  |  |  |  |   |  |  |
| DCT  | Double click in trigger              |  |  |    |  |  |  |  |  |   |  |  |
| DCU  | Doesn't close-up                     |  |  |    |  |  |  |  |  |   |  |  |
| DE   | Doesn't eject                        |  |  |    |  |  |  |  |  |   |  |  |
| DEL  | Doesn't eject live round             |  |  |    |  |  |  |  |  |   |  |  |
| DFU  | Doesn't feed up                      |  |  |    |  |  |  |  |  |   |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |    |  |  |  |  |  |   |  |  |
| DLU  | Doesn't lock-up                      |  |  |    |  |  |  |  |  |   |  |  |
| DS   | Dead safe                            |  |  |    |  |  |  |  |  |   |  |  |
| DSM  | Drops shell-magazine                 |  |  |    |  |  |  |  |  | 1 |  |  |
| DTL  | Doesn't trip latch                   |  |  |    |  |  |  |  |  |   |  |  |
| DX   | Doesn't extract                      |  |  |    |  |  |  |  |  |   |  |  |
| DXL  | Doesn't extract live round           |  |  |    |  |  |  |  |  |   |  |  |
| EDS  | Extractor drops shell                |  |  |    |  |  |  |  |  |   |  |  |
| ESB  | Ejector sticks back                  |  |  |    |  |  |  |  |  |   |  |  |
| ESS  | Extractor stems shell                |  |  |    |  |  |  |  |  |   |  |  |
| FA   | Fires automatically                  |  |  |    |  |  |  |  |  |   |  |  |
| FB   | Follower binds                       |  |  |    |  |  |  |  |  |   |  |  |

|      |                                   |  |  |   |  |  |  |  |  |   |  |  |
|------|-----------------------------------|--|--|---|--|--|--|--|--|---|--|--|
| FC   | Fails to connect                  |  |  |   |  |  |  |  |  |   |  |  |
| FCB  | Fore-end cracked or broken        |  |  |   |  |  |  |  |  |   |  |  |
| FD   | Follows-down                      |  |  |   |  |  |  |  |  |   |  |  |
| FF   | Fails to fire                     |  |  | 1 |  |  |  |  |  |   |  |  |
| FFM  | Fails to feed from magazine       |  |  |   |  |  |  |  |  | 1 |  |  |
| FFP  | Flat firing pin                   |  |  |   |  |  |  |  |  |   |  |  |
| FOS  | Fires on safe                     |  |  |   |  |  |  |  |  |   |  |  |
| FSR  | Fires when safe is released       |  |  |   |  |  |  |  |  |   |  |  |
| GCSO | Gas cyl shot off                  |  |  |   |  |  |  |  |  |   |  |  |
| GRSO | Guide ring shot off               |  |  |   |  |  |  |  |  |   |  |  |
| HPA  | High pressure ammo                |  |  |   |  |  |  |  |  |   |  |  |
| HUE  | Hard under extractor              |  |  |   |  |  |  |  |  |   |  |  |
| ILOP | Int. latch out of position        |  |  |   |  |  |  |  |  |   |  |  |
| ILRM | Int. latch ret. Missing           |  |  |   |  |  |  |  |  |   |  |  |
| ILSB | Int. latch stud broken            |  |  |   |  |  |  |  |  |   |  |  |
| ILSP | Int. latch spring out of position |  |  |   |  |  |  |  |  |   |  |  |
| JL   | Jumps latch                       |  |  |   |  |  |  |  |  |   |  |  |
| JO   | Jars off                          |  |  |   |  |  |  |  |  |   |  |  |
| LB   | Light blow                        |  |  |   |  |  |  |  |  |   |  |  |
| MCSO | Magazine cap shot off             |  |  |   |  |  |  |  |  |   |  |  |
| MCW  | Magazine capacity wrong           |  |  | 2 |  |  |  |  |  |   |  |  |
| MFA  | Misfires (ammo)                   |  |  |   |  |  |  |  |  |   |  |  |
| MFOP | Magazine follower out of position |  |  |   |  |  |  |  |  |   |  |  |
| MLH  | Magazine loads hard               |  |  | 1 |  |  |  |  |  |   |  |  |
| OH   | Opens hard                        |  |  |   |  |  |  |  |  |   |  |  |
| PH   | Pulls hard                        |  |  |   |  |  |  |  |  |   |  |  |
| PSI  | Proof stamp illegible             |  |  |   |  |  |  |  |  |   |  |  |

|        |                                |  |   |   |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|---|---|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |   |   |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |   |   |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |   |   |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |   |   |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  | 1 |   |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |   |   |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |   |   |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |   |   |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |   |   |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |   |   |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |   |   |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |   |   |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |   |   |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |   |   |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |   |   |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |   |   |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |   |   |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |   | 3 |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |   |   |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |   |   |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |   |   |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |   |   |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |   |   |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |   |   |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |   |   |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |   |   |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |   |   |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| Test Date: |     |     |   |    |
|------------|-----|-----|---|----|
| 46         | 82  | 25  |   |    |
| 0          | 0   | 0   | 0 | 0  |
| 0.0        | 0.0 | 0.0 |   |    |
| 46         | 82  | 25  |   |    |
| 0          | 0   | 0   | 0 | 0  |
| 0.0        | 0.0 | 0.0 |   |    |
| 0          | 0   | 46  |   | 0  |
|            |     | 2   |   | 43 |

|     |   |     |    |     |
|-----|---|-----|----|-----|
| 46  |   | 82  |    | 25  |
| 0   | 0 | 0   | 0  | 0   |
| 0.0 |   | 0.0 |    | 0.0 |
| 46  |   | 82  |    | 25  |
| 0   | 0 | 0   | 0  | 0   |
| 0.0 |   | 0.0 |    | 0.0 |
| 0   | 0 | 0   | 2  | 0   |
|     |   |     | 43 |     |

[illegible]







[illegible]



|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |             |
|----------------|------------------------------------|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>1262</b> |
|                | <b>Total Rejected:</b>             | <b>20</b>   |
|                | <b>Overall Reject Rate:</b>        | <b>1.58</b> |

**Proof**

|           |     |     |     |     |   |   |   |     |     |   |
|-----------|-----|-----|-----|-----|---|---|---|-----|-----|---|
| Shot:     | 9   | 56  | 170 | 22  |   |   |   | 18  | 572 |   |
| Rejected: | 0   | 0   | 0   | 0   | 0 | 0 | 0 | 0   | 0   | 0 |
| Percent:  | 0.0 | 0.0 | 0.0 | 0.0 |   |   |   | 0.0 | 0.0 |   |

**Test**

|           |      |      |     |     |   |   |   |      |     |   |
|-----------|------|------|-----|-----|---|---|---|------|-----|---|
| Shot:     | 9    | 6    | 170 | 60  |   |   |   | 18   | 572 |   |
| Rejected: | 2    | 1    | 4   | 4   | 0 | 0 | 0 | 8    | 0   | 0 |
| Percent:  | 22.2 | 16.7 | 2.4 | 6.7 |   |   |   | 44.4 | 0.0 |   |

**Target**

|           |   |   |   |   |   |   |   |   |   |   |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot:     |   |   |   |   |   |   |   |   |   |   |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent:  |   |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   | 1                    |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |   |   |  |  |  |   |  |  |  |
|------|--------------------------------------|--|--|---|---|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar              |  |  |   |   |  |  |  |   |  |  |  |
| CLM  | Can't load magazine                  |  |  |   |   |  |  |  |   |  |  |  |
| CO   | Cut-off                              |  |  |   |   |  |  |  |   |  |  |  |
| CR   | Cuts rim                             |  |  |   |   |  |  |  |   |  |  |  |
| CS   | Cases swell                          |  |  |   |   |  |  |  |   |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |   |   |  |  |  |   |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |   |   |  |  |  |   |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |   |   |  |  |  |   |  |  |  |
| DBB  | Doesn't blow back                    |  |  | 2 | 4 |  |  |  | 2 |  |  |  |
| DCS  | Double click in safety switch        |  |  |   |   |  |  |  |   |  |  |  |
| DCT  | Double click in trigger              |  |  |   |   |  |  |  |   |  |  |  |
| DCU  | Doesn't close-up                     |  |  |   |   |  |  |  |   |  |  |  |
| DE   | Doesn't eject                        |  |  |   |   |  |  |  |   |  |  |  |
| DEL  | Doesn't eject live round             |  |  |   |   |  |  |  |   |  |  |  |
| DFU  | Doesn't feed up                      |  |  |   |   |  |  |  |   |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |   |   |  |  |  |   |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |   |   |  |  |  |   |  |  |  |
| DS   | Dead safe                            |  |  |   |   |  |  |  |   |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |   |   |  |  |  |   |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |   |   |  |  |  |   |  |  |  |
| DX   | Doesn't extract                      |  |  |   |   |  |  |  |   |  |  |  |
| DXL  | Doesn't extract live round           |  |  |   |   |  |  |  |   |  |  |  |
| EDS  | Extractor drops shell                |  |  |   |   |  |  |  | 3 |  |  |  |
| ESB  | Ejector sticks back                  |  |  |   |   |  |  |  |   |  |  |  |
| ESS  | Extractor stems shell                |  |  |   |   |  |  |  |   |  |  |  |
| FA   | Fires automatically                  |  |  |   |   |  |  |  |   |  |  |  |
| FB   | Follower binds                       |  |  |   |   |  |  |  |   |  |  |  |

|      |                                   |  |   |  |  |  |  |  |   |  |  |  |
|------|-----------------------------------|--|---|--|--|--|--|--|---|--|--|--|
| FC   | Fails to connect                  |  |   |  |  |  |  |  |   |  |  |  |
| FCB  | Fore-end cracked or broken        |  |   |  |  |  |  |  |   |  |  |  |
| FD   | Follows-down                      |  |   |  |  |  |  |  |   |  |  |  |
| FF   | Fails to fire                     |  |   |  |  |  |  |  |   |  |  |  |
| FFM  | Fails to feed from magazine       |  |   |  |  |  |  |  | 2 |  |  |  |
| FFP  | Flat firing pin                   |  |   |  |  |  |  |  |   |  |  |  |
| FOS  | Fires on safe                     |  |   |  |  |  |  |  |   |  |  |  |
| FSR  | Fires when safe is released       |  |   |  |  |  |  |  |   |  |  |  |
| GCSO | Gas cyl shot off                  |  |   |  |  |  |  |  |   |  |  |  |
| GRSO | Guide ring shot off               |  |   |  |  |  |  |  |   |  |  |  |
| HPA  | High pressure ammo                |  |   |  |  |  |  |  |   |  |  |  |
| HUE  | Hard under extractor              |  | 1 |  |  |  |  |  | 1 |  |  |  |
| ILOP | Int. latch out of position        |  |   |  |  |  |  |  |   |  |  |  |
| ILRM | Int. latch ret. Missing           |  |   |  |  |  |  |  |   |  |  |  |
| ILSB | Int. latch stud broken            |  |   |  |  |  |  |  |   |  |  |  |
| ILSP | Int. latch spring out of position |  |   |  |  |  |  |  |   |  |  |  |
| JL   | Jumps latch                       |  |   |  |  |  |  |  |   |  |  |  |
| JO   | Jars off                          |  |   |  |  |  |  |  |   |  |  |  |
| LB   | Light blow                        |  |   |  |  |  |  |  |   |  |  |  |
| MCSO | Magazine cap shot off             |  |   |  |  |  |  |  |   |  |  |  |
| MCW  | Magazine capacity wrong           |  |   |  |  |  |  |  |   |  |  |  |
| MFA  | Misfires (ammo)                   |  |   |  |  |  |  |  |   |  |  |  |
| MFOP | Magazine follower out of position |  |   |  |  |  |  |  |   |  |  |  |
| MLH  | Magazine loads hard               |  |   |  |  |  |  |  |   |  |  |  |
| OH   | Opens hard                        |  |   |  |  |  |  |  |   |  |  |  |
| PH   | Pulls hard                        |  |   |  |  |  |  |  |   |  |  |  |
| PSI  | Proof stamp illegible             |  |   |  |  |  |  |  |   |  |  |  |



|        |                                |   |  |   |  |  |  |  |  |  |  |  |
|--------|--------------------------------|---|--|---|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |   |  |   |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |   |  |   |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |   |  | 2 |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |   |  |   |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          | 1 |  |   |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |   |  |   |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |   |  |   |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |   |  |   |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |   |  |   |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |   |  |   |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |   |  |   |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |   |  |   |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |   |  |   |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |   |  |   |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |   |  |   |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |   |  |   |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |   |  |   |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |   |  |   |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |   |  |   |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |   |  |   |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |   |  |   |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |   |  |   |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |   |  |   |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |   |  |   |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |   |  |   |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |   |  |   |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |   |  |   |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



Test Date:

|    |     |    |
|----|-----|----|
| 27 | 333 | 61 |
| 27 | 333 | 61 |

|    |   |   |     |   |    |
|----|---|---|-----|---|----|
| 27 |   |   | 332 |   | 68 |
| 0  | 0 | 0 | 1   | 0 | 0  |

|     |     |     |
|-----|-----|-----|
| 0.0 | 0.3 | 0.0 |
| 0.0 | 0.0 | 58  |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |             |
|----------------|------------------------------------|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>1138</b> |
|                | <b>Total Rejected:</b>             | <b>17</b>   |
|                | <b>Overall Reject Rate:</b>        | <b>1.49</b> |

|               |           |       |     |   |     |   |   |   |   |     |   |
|---------------|-----------|-------|-----|---|-----|---|---|---|---|-----|---|
| <b>Proof</b>  | Shot:     | 6     | 76  |   | 82  |   |   |   |   | 653 |   |
|               | Rejected: | 0     | 0   | 0 | 0   | 0 | 0 | 0 | 0 | 0   | 0 |
|               | Percent:  | 0.0   | 0.0 |   | 0.0 |   |   |   |   | 0.0 |   |
| <b>Test</b>   | Shot:     | 6     | 76  |   | 82  |   |   |   |   | 653 |   |
|               | Rejected: | 6     | 7   | 0 | 0   | 0 | 0 | 0 | 0 | 2   | 0 |
|               | Percent:  | 100.0 | 9.2 |   | 0.0 |   |   |   |   | 0.3 |   |
| <b>Target</b> | Shot:     |       |     |   |     |   |   |   |   |     |   |
|               | Rejected: | 0     | 0   | 0 | 0   | 0 | 0 | 0 | 0 | 0   | 0 |
|               | Percent:  |       |     |   |     |   |   |   |   |     |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               | 1           |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   | 1                    |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |   |   |  |  |  |  |  |  |   |  |  |
|------|--------------------------------------|---|---|--|--|--|--|--|--|---|--|--|
| CHAB | Carrier hits action bar              |   |   |  |  |  |  |  |  |   |  |  |
| CLM  | Can't load magazine                  |   |   |  |  |  |  |  |  | 1 |  |  |
| CO   | Cut-off                              |   |   |  |  |  |  |  |  |   |  |  |
| CR   | Cuts rim                             |   |   |  |  |  |  |  |  |   |  |  |
| CS   | Cases swell                          |   |   |  |  |  |  |  |  |   |  |  |
| CTOG | Chamber torn or gouged               |   |   |  |  |  |  |  |  |   |  |  |
| CTP  | Creepy trigger pull                  |   |   |  |  |  |  |  |  |   |  |  |
| CWSB | Cams wrong side of action bar        |   |   |  |  |  |  |  |  |   |  |  |
| DBB  | Doesn't blow back                    |   |   |  |  |  |  |  |  |   |  |  |
| DCS  | Double click in safety switch        |   |   |  |  |  |  |  |  |   |  |  |
| DCT  | Double click in trigger              |   |   |  |  |  |  |  |  |   |  |  |
| DCU  | Doesn't close-up                     |   |   |  |  |  |  |  |  |   |  |  |
| DE   | Doesn't eject                        | 1 |   |  |  |  |  |  |  |   |  |  |
| DEL  | Doesn't eject live round             |   |   |  |  |  |  |  |  |   |  |  |
| DFU  | Doesn't feed up                      |   | 5 |  |  |  |  |  |  |   |  |  |
| DLO  | Doesn't lock open (after last shell) |   |   |  |  |  |  |  |  |   |  |  |
| DLU  | Doesn't lock-up                      |   |   |  |  |  |  |  |  |   |  |  |
| DS   | Dead safe                            |   |   |  |  |  |  |  |  |   |  |  |
| DSM  | Drops shell-magazine                 |   | 2 |  |  |  |  |  |  |   |  |  |
| DTL  | Doesn't trip latch                   |   |   |  |  |  |  |  |  |   |  |  |
| DX   | Doesn't extract                      |   |   |  |  |  |  |  |  |   |  |  |
| DXL  | Doesn't extract live round           |   |   |  |  |  |  |  |  |   |  |  |
| EDS  | Extractor drops shell                |   |   |  |  |  |  |  |  |   |  |  |
| ESB  | Ejector sticks back                  |   |   |  |  |  |  |  |  |   |  |  |
| ESS  | Extractor stems shell                |   |   |  |  |  |  |  |  |   |  |  |
| FA   | Fires automatically                  |   |   |  |  |  |  |  |  |   |  |  |
| FB   | Follower binds                       |   |   |  |  |  |  |  |  |   |  |  |

|      |                                   |   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|---|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |   |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |   |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |   |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |   |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |   |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |   |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |   |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |   |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |   |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |   |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |   |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |   |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |   |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |   |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |   |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       | 2 |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |   |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |   |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |   |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |   |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |   |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |   |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |   |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |   |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |   |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |   |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|---|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |   |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |   |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |   |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |   |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          | 2 |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |   |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |   |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |   |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |   |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |   |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |   |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |   |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |   |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |   |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |   |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |   |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |   |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |   |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |   |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |   |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |   |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |   |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |   |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |   |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |   |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |   |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |   |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| Test Date: |   |     |   |     |
|------------|---|-----|---|-----|
| 31         |   | 229 |   | 37  |
| 0          | 0 | 0   | 0 | 0   |
| 0.0        |   | 0.0 |   | 0.0 |
| 31         |   | 228 |   | 62  |
| 0          | 0 | 1   | 0 | 0   |
| 0.0        |   | 0.4 |   | 0.0 |
| 0          | 0 | 0   | 0 | 28  |
|            |   |     |   | 1   |
|            |   |     |   | 36  |

|     |     |     |
|-----|-----|-----|
| 31  | 229 | 37  |
| 0   | 0   | 0   |
| 0.0 | 0.0 | 0.0 |
| 31  | 228 | 62  |
| 0   | 1   | 0   |
| 0.0 | 0.4 | 0.0 |
|     |     | 28  |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



[illegible][illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |  |             |
|----------------|------------------------------------|--|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> |  | <b>914</b>  |
|                | <b>Total Rejected:</b>             |  | <b>20</b>   |
|                | <b>Overall Reject Rate:</b>        |  | <b>2.19</b> |

**Proof**

|           |     |     |     |     |   |   |   |   |     |   |
|-----------|-----|-----|-----|-----|---|---|---|---|-----|---|
| Shot:     | 2   | 139 | 75  | 19  |   |   |   |   | 374 |   |
| Rejected: | 0   | 0   | 0   | 0   | 0 | 0 | 0 | 0 | 0   | 0 |
| Percent:  | 0.0 | 0.0 | 0.0 | 0.0 |   |   |   |   | 0.0 |   |

**Test**

|           |   |     |     |     |   |   |   |   |     |   |
|-----------|---|-----|-----|-----|---|---|---|---|-----|---|
| Shot:     |   | 132 | 75  | 19  |   |   |   |   | 374 |   |
| Rejected: | 0 | 13  | 7   | 0   | 0 | 0 | 0 | 0 | 0   | 0 |
| Percent:  |   | 9.8 | 9.3 | 0.0 |   |   |   |   | 0.0 |   |

**Target**

|           |   |   |   |   |   |   |   |   |   |   |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot:     |   |   |   |   |   |   |   |   |   |   |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent:  |   |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      | 1            |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |   |   |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|---|---|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |   |   |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |   |   |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |   |   |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |   |   |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |   |   |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |   |   |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |   |   |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |   |   |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |   | 2 |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |   |   |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |   |   |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |   |   |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |   |   |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |   |   |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  | 1 |   |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |   |   |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |   |   |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |   |   |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |   |   |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |   |   |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |   |   |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |   |   |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |   |   |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |   |   |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |   |   |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |   |   |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |   |   |  |  |  |  |  |  |  |  |

|      |                                   |  |   |   |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|---|---|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |   |   |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |   |   |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |   |   |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |   |   |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  | 6 | 1 |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |   |   |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |   |   |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |   |   |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |   |   |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |   |   |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |   |   |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  | 2 |   |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |   |   |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |   |   |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |   |   |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |   |   |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  | 1 |   |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |   |   |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |   |   |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |   |   |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |   |   |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |   |   |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |   |   |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |   |   |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |   |   |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |   |   |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |   |   |  |  |  |  |  |  |  |  |



|        |                                |  |   |   |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|---|---|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |   |   |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |   |   |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  | 2 | 2 |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |   |   |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |   |   |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |   |   |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |   |   |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |   |   |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |   |   |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |   |   |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |   |   |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |   |   |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |   |   |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |   |   |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |   |   |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |   |   |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |   |   |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |   | 2 |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |   |   |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |   |   |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |   |   |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |   |   |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |   |   |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |   |   |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |   |   |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |   |   |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |   |   |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                  |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof   |
| GRSO-P | Guide ring shot off at proof     |
| MCSO-P | Magazine cap shot off at proof   |
| MSI-P  | Magnaflux stamp illegible on bbl |
| MSM-P  | Magnaflux stamp missing on bbl   |
| PP-P   | Pierced primer at proof          |
| SCB-P  | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions       |

| Test Date: |   |     |   |   |   |   |   |   |   |
|------------|---|-----|---|---|---|---|---|---|---|
| 38         |   | 244 |   |   |   |   |   |   |   |
| 0          | 0 | 0   | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0        |   | 0.0 |   |   |   |   |   |   |   |
| 38         |   | 244 |   |   |   |   |   |   |   |
| 0          | 0 | 0   | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0        |   | 0.0 |   |   |   |   |   |   |   |
| 0          | 0 | 0   | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0        |   | 0.0 |   |   |   |   |   |   |   |
| 0          | 0 | 0   | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0        |   | 0.0 |   |   |   |   |   |   |   |

|     |     |     |     |     |     |
|-----|-----|-----|-----|-----|-----|
| 38  | 0   | 244 | 0   | 0   | 0   |
| 0   | 0   | 0   | 0   | 0   | 0   |
| 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0   |
| 38  | 0   | 244 | 0   | 0   | 32  |
| 0   | 0   | 0   | 0   | 0   | 0   |
| 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| 0   | 0   | 0   | 0   | 0   | 14  |
| 0   | 0   | 0   | 0   | 0   | 0   |
|     |     |     |     |     | 0.0 |
|     |     |     |     |     | 0.0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |             |
|----------------|------------------------------------|-------------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>1216</b> |
|                | <b>Total Rejected:</b>             | <b>38</b>   |
|                | <b>Overall Reject Rate:</b>        | <b>3.13</b> |

**Proof**

|           |     |     |     |     |   |   |   |   |     |   |
|-----------|-----|-----|-----|-----|---|---|---|---|-----|---|
| Shot:     | 63  | 82  | 99  | 52  |   |   |   |   | 613 |   |
| Rejected: | 1   | 0   | 0   | 0   | 0 | 0 | 0 | 0 | 0   | 0 |
| Percent:  | 1.6 | 0.0 | 0.0 | 0.0 |   |   |   |   | 0.0 |   |

**Test**

|           |      |     |   |     |   |     |   |   |     |   |
|-----------|------|-----|---|-----|---|-----|---|---|-----|---|
| Shot:     | 64   | 24  |   | 52  |   | 85  |   |   | 612 |   |
| Rejected: | 22   | 0   | 1 | 1   | 4 | 0   | 0 | 0 | 2   | 0 |
| Percent:  | 34.4 | 0.0 |   | 1.9 |   | 0.0 |   |   | 0.3 |   |

**Target**

|           |   |   |   |   |   |   |   |   |   |   |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot:     |   |   |   |   |   |   |   |   |   |   |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent:  |   |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               | 1           |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |   |  |  |  |   |  |  |  |  |   |  |
|------|--------------------------------------|---|--|--|--|---|--|--|--|--|---|--|
| CHAB | Carrier hits action bar              |   |  |  |  |   |  |  |  |  |   |  |
| CLM  | Can't load magazine                  |   |  |  |  |   |  |  |  |  |   |  |
| CO   | Cut-off                              |   |  |  |  |   |  |  |  |  |   |  |
| CR   | Cuts rim                             |   |  |  |  |   |  |  |  |  |   |  |
| CS   | Cases swell                          |   |  |  |  |   |  |  |  |  |   |  |
| CTOG | Chamber torn or gouged               |   |  |  |  |   |  |  |  |  |   |  |
| CTP  | Creepy trigger pull                  |   |  |  |  |   |  |  |  |  |   |  |
| CWSB | Cams wrong side of action bar        |   |  |  |  |   |  |  |  |  |   |  |
| DBB  | Doesn't blow back                    |   |  |  |  |   |  |  |  |  |   |  |
| DCS  | Double click in safety switch        |   |  |  |  |   |  |  |  |  |   |  |
| DCT  | Double click in trigger              |   |  |  |  |   |  |  |  |  |   |  |
| DCU  | Doesn't close-up                     |   |  |  |  |   |  |  |  |  |   |  |
| DE   | Doesn't eject                        |   |  |  |  |   |  |  |  |  |   |  |
| DEL  | Doesn't eject live round             |   |  |  |  |   |  |  |  |  |   |  |
| DFU  | Doesn't feed up                      | 1 |  |  |  | 1 |  |  |  |  |   |  |
| DLO  | Doesn't lock open (after last shell) |   |  |  |  |   |  |  |  |  |   |  |
| DLU  | Doesn't lock-up                      |   |  |  |  |   |  |  |  |  |   |  |
| DS   | Dead safe                            |   |  |  |  |   |  |  |  |  |   |  |
| DSM  | Drops shell-magazine                 |   |  |  |  |   |  |  |  |  |   |  |
| DTL  | Doesn't trip latch                   |   |  |  |  |   |  |  |  |  |   |  |
| DX   | Doesn't extract                      |   |  |  |  |   |  |  |  |  |   |  |
| DXL  | Doesn't extract live round           |   |  |  |  |   |  |  |  |  |   |  |
| EDS  | Extractor drops shell                |   |  |  |  |   |  |  |  |  |   |  |
| ESB  | Ejector sticks back                  |   |  |  |  |   |  |  |  |  |   |  |
| ESS  | Extractor stems shell                |   |  |  |  |   |  |  |  |  |   |  |
| FA   | Fires automatically                  |   |  |  |  |   |  |  |  |  |   |  |
| FB   | Follower binds                       |   |  |  |  |   |  |  |  |  | 1 |  |

|      |                                   |   |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|---|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |   |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |   |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |   |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |   |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       | 3 |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |   |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |   |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |   |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |   |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |   |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |   |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |   |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |   |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |   |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |   |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |   |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |   |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |   |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |   |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |   |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |   |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |   |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |   |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |   |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |   |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |   |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |   |  |  |  |  |  |  |  |  |  |  |

|        |                                |    |  |   |  |  |  |  |  |  |  |  |
|--------|--------------------------------|----|--|---|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |    |  |   |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |    |  |   |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |    |  | 1 |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |    |  |   |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          | 11 |  |   |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |    |  |   |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |    |  |   |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |    |  |   |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |    |  |   |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |    |  |   |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |    |  |   |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |    |  |   |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     | 3  |  |   |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |    |  |   |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |    |  |   |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |    |  |   |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |    |  |   |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              | 4  |  |   |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |    |  |   |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |    |  |   |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |    |  |   |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |    |  |   |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |    |  |   |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |    |  |   |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |    |  |   |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |    |  |   |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |    |  |   |  |  |  |  |  |  |  |  |

|        |                                   |   |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|---|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |   |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |   |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |   |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |   |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |   |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |   |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |   |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |   |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |   |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |   |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |   |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |   |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |   |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |   |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |   |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |   |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |   |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |   |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |   |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |   |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |   |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |   |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |   |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |   |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |   |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            | 1 |  |  |  |  |  |  |  |  |  |  |  |

|        |                                  |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof   |
| GRSO-P | Guide ring shot off at proof     |
| MCSO-P | Magazine cap shot off at proof   |
| MSI-P  | Magnaflux stamp illegible or bbl |
| MSM-P  | Magnaflux stamp missing or bbl   |
| PP-P   | Pierced primer at proof          |
| SCB-P  | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions       |

**Test Date:**

|    |     |    |
|----|-----|----|
| 62 | 276 | 56 |
|----|-----|----|

|    |   |     |    |
|----|---|-----|----|
| 62 |   | 275 | 40 |
| 0  | 0 | 1   | 3  |
|    |   |     | 0  |

|     |     |     |
|-----|-----|-----|
| 0.0 | 0.4 | 7.5 |
| 39  |     |     |

[illegible]











|  |  |  |  |  |   |  |  |
|--|--|--|--|--|---|--|--|
|  |  |  |  |  |   |  |  |
|  |  |  |  |  |   |  |  |
|  |  |  |  |  |   |  |  |
|  |  |  |  |  | 1 |  |  |
|  |  |  |  |  |   |  |  |
|  |  |  |  |  |   |  |  |

|                |           |                                    |      |             |     |   |   |   |     |     |   |
|----------------|-----------|------------------------------------|------|-------------|-----|---|---|---|-----|-----|---|
| <b>Summary</b> |           | <b>Total Test + Proof Failures</b> |      | <b>1435</b> |     |   |   |   |     |     |   |
|                |           | <b>Total Rejected:</b>             |      | <b>26</b>   |     |   |   |   |     |     |   |
|                |           | <b>Overall Reject Rate:</b>        |      | <b>1.81</b> |     |   |   |   |     |     |   |
| <b>Proof</b>   | Shot:     | 76                                 | 3    | 97          | 32  |   |   |   | 4   | 926 |   |
|                | Rejected: | 0                                  | 0    | 0           | 0   | 0 | 0 | 0 | 0   | 1   | 0 |
|                | Percent:  | 0.0                                | 0.0  | 0.0         | 0.0 |   |   |   | 0.0 | 0.1 |   |
| <b>Test</b>    | Shot:     | 26                                 | 26   | 114         | 26  |   |   |   | 4   | 926 |   |
|                | Rejected: | 8                                  | 6    | 7           | 0   | 0 | 0 | 0 | 0   | 1   | 0 |
|                | Percent:  | 30.8                               | 23.1 | 6.1         | 0.0 |   |   |   | 0.0 | 0.1 |   |
| <b>Target</b>  | Shot:     |                                    |      |             |     |   |   |   |     | 6   |   |
|                | Rejected: | 0                                  | 0    | 0           | 0   | 0 | 0 | 0 | 0   | 0   | 0 |
|                | Percent:  |                                    |      |             |     |   |   |   |     | 0.0 |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               | 1           |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |   |   |   |  |  |  |  |  |  |  |  |
|------|--------------------------------------|---|---|---|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |   |   |   |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |   |   |   |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |   |   |   |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |   |   |   |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |   |   |   |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |   |   |   |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |   |   |   |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |   |   |   |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    | 2 | 2 | 3 |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |   |   |   |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |   |   |   |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |   |   |   |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |   |   | 3 |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |   |   |   |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |   |   |   |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |   |   |   |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |   |   |   |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            | 1 |   |   |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |   |   |   |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |   |   |   |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |   |   |   |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |   |   |   |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |   |   |   |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |   |   |   |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |   |   |   |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |   |   |   |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |   |   |   |  |  |  |  |  |  |  |  |

|      |                                   |  |   |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|---|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |   |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |   |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |   |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |   |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |   |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |   |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |   |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |   |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |   |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |   |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |   |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  | 1 |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |   |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |   |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |   |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |   |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |   |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |   |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |   |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |   |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |   |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |   |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |   |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |   |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |   |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |   |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |   |  |  |  |  |  |  |  |  |  |



|        |                                |   |   |   |  |  |  |  |  |  |  |  |
|--------|--------------------------------|---|---|---|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |   |   |   |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |   |   |   |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |   | 1 | 1 |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |   |   |   |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          | 2 | 1 |   |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |   |   |   |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |   |   |   |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |   |   |   |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |   |   |   |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |   |   |   |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |   |   |   |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |   |   |   |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     | 2 |   |   |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |   |   |   |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |   |   |   |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |   |   |   |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |   |   |   |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              | 1 | 1 |   |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |   |   |   |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |   |   |   |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |   |   |   |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |   |   |   |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |   |   |   |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |   |   |   |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |   |   |   |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |   |   |   |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |   |   |   |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |   |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|---|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |   |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |   |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |   |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |   |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |   |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |   |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |   |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |   |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |   |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |   |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |   |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |   |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |   |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |   |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |   |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |   |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |   |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |   |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |   |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |   |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |   |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |   |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |   |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |   |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |   |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  | 1 |  |



**Test Date:**

|    |     |    |
|----|-----|----|
| 61 | 208 | 65 |
| 61 | 208 | 65 |

|    |   |     |    |
|----|---|-----|----|
| 61 |   | 208 | 43 |
| 0  | 0 | 1   | 0  |
| 0  | 0 | 0   | 0  |

|  |     |     |     |
|--|-----|-----|-----|
|  | 0.0 | 0.5 | 0.6 |
|  | 0.0 | 0.0 | 8.0 |
|  | 0.0 | 0.0 | 0.0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|         |           |                             |     |      |     |   |   |   |     |     |   |
|---------|-----------|-----------------------------|-----|------|-----|---|---|---|-----|-----|---|
| Summary |           | Total Test + Proof Failures |     | 1324 |     |   |   |   |     |     |   |
|         |           | Total Rejected:             |     | 51   |     |   |   |   |     |     |   |
|         |           | Overall Reject Rate:        |     | 3.85 |     |   |   |   |     |     |   |
| Proof   | Shot:     | 166                         | 6   | 3    |     |   |   |   | 1   | 532 |   |
|         | Rejected: | 0                           | 0   | 0    | 0   | 0 | 0 | 0 | 0   | 0   | 0 |
|         | Percent:  | 0.0                         | 0.0 | 0.0  |     |   |   |   | 0.0 | 0.0 |   |
| Test    | Shot:     | 191                         | 3   |      | 6   |   |   |   |     | 532 |   |
|         | Rejected: | 43                          | 0   | 0    | 0   | 0 | 0 | 0 | 0   | 0   | 0 |
|         | Percent:  | 22.5                        | 0.0 |      | 0.0 |   |   |   |     | 0.0 |   |
| Target  | Shot:     |                             |     |      |     |   |   |   |     |     |   |
|         | Rejected: | 0                           | 0   | 0    | 0   | 0 | 0 | 0 | 0   | 0   | 0 |
|         | Percent:  |                             |     |      |     |   |   |   |     |     |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB    | Action binds                             | 1                    |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   | 1                    |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |   |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|---|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |   |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |   |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |   |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |   |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |   |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |   |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |   |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |   |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    | 1 |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |   |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |   |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |   |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        | 1 |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |   |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      | 1 |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) | 1 |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |   |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |   |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 | 3 |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |   |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |   |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |   |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |   |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |   |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |   |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |   |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |   |  |  |  |  |  |  |  |  |  |  |

|      |                                   |   |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|---|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |   |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |   |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |   |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     | 1 |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       | 3 |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |   |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |   |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |   |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |   |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |   |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |   |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |   |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        | 2 |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           | 1 |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |   |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |   |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       | 2 |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |   |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |   |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |   |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |   |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |   |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |   |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |   |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |   |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |   |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |   |  |  |  |  |  |  |  |  |  |  |

|        |                                |    |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|----|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |    |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |    |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  | 3  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |    |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          | 12 |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |    |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |    |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |    |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |    |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |    |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               | 1  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |    |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     | 9  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |    |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |    |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |    |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |    |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |    |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |    |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |    |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |    |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |    |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |    |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |    |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |    |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |    |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |    |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



**Test Date:** \_\_\_\_\_

[illegible]











|  |  |  |  |  |   |  |  |
|--|--|--|--|--|---|--|--|
|  |  |  |  |  |   |  |  |
|  |  |  |  |  |   |  |  |
|  |  |  |  |  |   |  |  |
|  |  |  |  |  | 1 |  |  |
|  |  |  |  |  |   |  |  |
|  |  |  |  |  |   |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                  |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof   |
| GRSO-P | Guide ring shot off at proof     |
| MCSO-P | Magazine cap shot off at proof   |
| MSI-P  | Magnaflux stamp illegible on bbl |
| MSM-P  | Magnaflux stamp missing on bbl   |
| PP-P   | Pierced primer at proof          |
| SCB-P  | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions       |

| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |

ILE00054774











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                  |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof   |
| GRSO-P | Guide ring shot off at proof     |
| MCSO-P | Magazine cap shot off at proof   |
| MSI-P  | Magnaflux stamp illegible on bbl |
| MSM-P  | Magnaflux stamp missing on bbl   |
| PP-P   | Pierced primer at proof          |
| SCB-P  | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions       |

| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |

[illegible]

| <b><i>Test Date:</i></b> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <b><i>Test Date:</i></b> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <b><i>Test Date:</i></b> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <b><i>Test Date:</i></b> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

ILE00054882











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



[illegible][illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                             |   |
|-----------------------------|---|
| Total Test + Proof Failures | 0 |
| Total Rejected:             | 0 |
| Overall Reject Rate:        |   |

|        |           |   |   |   |   |   |   |   |   |   |   |
|--------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof  | Shot:     |   |   |   |   |   |   |   |   |   |   |
|        | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|        | Percent:  |   |   |   |   |   |   |   |   |   |   |
| Test   | Shot:     |   |   |   |   |   |   |   |   |   |   |
|        | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|        | Percent:  |   |   |   |   |   |   |   |   |   |   |
| Target | Shot:     |   |   |   |   |   |   |   |   |   |   |
|        | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|        | Percent:  |   |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |

[illegible]

| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |

ILE00054918











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



[illegible][illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



[illegible][illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <i><b>Test Date:</b></i> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |

|                |                                    |          |
|----------------|------------------------------------|----------|
| <b>Summary</b> | <b>Total Test + Proof Failures</b> | <b>0</b> |
|                | <b>Total Rejected:</b>             | <b>0</b> |
|                | <b>Overall Reject Rate:</b>        |          |

|               |           |   |   |   |   |   |   |   |   |   |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| <b>Proof</b>  | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Test</b>   | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |
| <b>Target</b> | Shot:     |   |   |   |   |   |   |   |   |   |
|               | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
|               | Percent:  |   |   |   |   |   |   |   |   |   |

| CODE  | MALFUNCTION INDEX                        | 1187<br>Super<br>Mag | 1187<br>12Ga | 1187<br>20Ga | 1100<br>12Ga | 1100<br>16Ga | 1100<br>20Ga | 1100<br>28Ga | 1100<br>410Ga | 870<br>12Ga | 870<br>16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
|       |  |                      |              |              |              |              |              |              |               |             |             |
| AB    | Action binds                             |                      |              |              |              |              |              |              |               |             |             |
| ASFB  | Action spring follower binds             |                      |              |              |              |              |              |              |               |             |             |
| BABS  | Bulge at body shoulder                   |                      |              |              |              |              |              |              |               |             |             |
| BAC   | Burr at chamber                          |                      |              |              |              |              |              |              |               |             |             |
| BB    | Bolt binds/catches                       |                      |              |              |              |              |              |              |               |             |             |
| BCOE  | Bolt catches on ejector                  |                      |              |              |              |              |              |              |               |             |             |
| BC    | Blows cases                              |                      |              |              |              |              |              |              |               |             |             |
| BLOP  | Bar lock or disconnecter out of position |                      |              |              |              |              |              |              |               |             |             |
| BSCO  | Barrel support came out                  |                      |              |              |              |              |              |              |               |             |             |
| CBS-F | Shells catch on bbl support-feeding      |                      |              |              |              |              |              |              |               |             |             |
| CBS-L | Shells catch on bbl support-loading      |                      |              |              |              |              |              |              |               |             |             |
| CC    | Carrier catches on shells,mag,receiver   |                      |              |              |              |              |              |              |               |             |             |
| CD    | Case dented                              |                      |              |              |              |              |              |              |               |             |             |
| CH    | Closes hard                              |                      |              |              |              |              |              |              |               |             |             |

|      |                                      |  |  |  |  |  |  |  |  |  |  |  |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar              |  |  |  |  |  |  |  |  |  |  |  |
| CLM  | Can't load magazine                  |  |  |  |  |  |  |  |  |  |  |  |
| CO   | Cut-off                              |  |  |  |  |  |  |  |  |  |  |  |
| CR   | Cuts rim                             |  |  |  |  |  |  |  |  |  |  |  |
| CS   | Cases swell                          |  |  |  |  |  |  |  |  |  |  |  |
| CTOG | Chamber torn or gouged               |  |  |  |  |  |  |  |  |  |  |  |
| CTP  | Creepy trigger pull                  |  |  |  |  |  |  |  |  |  |  |  |
| CWSB | Cams wrong side of action bar        |  |  |  |  |  |  |  |  |  |  |  |
| DBB  | Doesn't blow back                    |  |  |  |  |  |  |  |  |  |  |  |
| DCS  | Double click in safety switch        |  |  |  |  |  |  |  |  |  |  |  |
| DCT  | Double click in trigger              |  |  |  |  |  |  |  |  |  |  |  |
| DCU  | Doesn't close-up                     |  |  |  |  |  |  |  |  |  |  |  |
| DE   | Doesn't eject                        |  |  |  |  |  |  |  |  |  |  |  |
| DEL  | Doesn't eject live round             |  |  |  |  |  |  |  |  |  |  |  |
| DFU  | Doesn't feed up                      |  |  |  |  |  |  |  |  |  |  |  |
| DLO  | Doesn't lock open (after last shell) |  |  |  |  |  |  |  |  |  |  |  |
| DLU  | Doesn't lock-up                      |  |  |  |  |  |  |  |  |  |  |  |
| DS   | Dead safe                            |  |  |  |  |  |  |  |  |  |  |  |
| DSM  | Drops shell-magazine                 |  |  |  |  |  |  |  |  |  |  |  |
| DTL  | Doesn't trip latch                   |  |  |  |  |  |  |  |  |  |  |  |
| DX   | Doesn't extract                      |  |  |  |  |  |  |  |  |  |  |  |
| DXL  | Doesn't extract live round           |  |  |  |  |  |  |  |  |  |  |  |
| EDS  | Extractor drops shell                |  |  |  |  |  |  |  |  |  |  |  |
| ESB  | Ejector sticks back                  |  |  |  |  |  |  |  |  |  |  |  |
| ESS  | Extractor stems shell                |  |  |  |  |  |  |  |  |  |  |  |
| FA   | Fires automatically                  |  |  |  |  |  |  |  |  |  |  |  |
| FB   | Follower binds                       |  |  |  |  |  |  |  |  |  |  |  |

|      |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC   | Fails to connect                  |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB  | Fore-end cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |  |
| FD   | Follows-down                      |  |  |  |  |  |  |  |  |  |  |  |  |
| FF   | Fails to fire                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FFM  | Fails to feed from magazine       |  |  |  |  |  |  |  |  |  |  |  |  |
| FFP  | Flat firing pin                   |  |  |  |  |  |  |  |  |  |  |  |  |
| FOS  | Fires on safe                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSR  | Fires when safe is released       |  |  |  |  |  |  |  |  |  |  |  |  |
| GCSO | Gas cyl shot off                  |  |  |  |  |  |  |  |  |  |  |  |  |
| GRSO | Guide ring shot off               |  |  |  |  |  |  |  |  |  |  |  |  |
| HPA  | High pressure ammo                |  |  |  |  |  |  |  |  |  |  |  |  |
| HUE  | Hard under extractor              |  |  |  |  |  |  |  |  |  |  |  |  |
| ILOP | Int. latch out of position        |  |  |  |  |  |  |  |  |  |  |  |  |
| ILRM | Int. latch ret. Missing           |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSB | Int. latch stud broken            |  |  |  |  |  |  |  |  |  |  |  |  |
| ILSP | Int. latch spring out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| JL   | Jumps latch                       |  |  |  |  |  |  |  |  |  |  |  |  |
| JO   | Jars off                          |  |  |  |  |  |  |  |  |  |  |  |  |
| LB   | Light blow                        |  |  |  |  |  |  |  |  |  |  |  |  |
| MCSO | Magazine cap shot off             |  |  |  |  |  |  |  |  |  |  |  |  |
| MCW  | Magazine capacity wrong           |  |  |  |  |  |  |  |  |  |  |  |  |
| MFA  | Misfires (ammo)                   |  |  |  |  |  |  |  |  |  |  |  |  |
| MFOP | Magazine follower out of position |  |  |  |  |  |  |  |  |  |  |  |  |
| MLH  | Magazine loads hard               |  |  |  |  |  |  |  |  |  |  |  |  |
| OH   | Opens hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PH   | Pulls hard                        |  |  |  |  |  |  |  |  |  |  |  |  |
| PSI  | Proof stamp illegible             |  |  |  |  |  |  |  |  |  |  |  |  |



|        |                                |  |  |  |  |  |  |  |  |  |  |  |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM    | Proof stamp missing            |  |  |  |  |  |  |  |  |  |  |  |
| RBOC   | Rings and bulges on case       |  |  |  |  |  |  |  |  |  |  |  |
| RDW    | (Action) release doesn't work  |  |  |  |  |  |  |  |  |  |  |  |
| RIC    | Rings in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SBC    | Stems bottom chambers          |  |  |  |  |  |  |  |  |  |  |  |
| SBCL   | Shell binds carrier latch      |  |  |  |  |  |  |  |  |  |  |  |
| SBE    | Stems bbl extension            |  |  |  |  |  |  |  |  |  |  |  |
| SCB    | Stock cracked or broken        |  |  |  |  |  |  |  |  |  |  |  |
| SCX    | Shell catches                  |  |  |  |  |  |  |  |  |  |  |  |
| SHI    | Short indent                   |  |  |  |  |  |  |  |  |  |  |  |
| SIC    | Stems in chamber               |  |  |  |  |  |  |  |  |  |  |  |
| SL     | shaves lead                    |  |  |  |  |  |  |  |  |  |  |  |
| SLC    | Stems left side of chamber     |  |  |  |  |  |  |  |  |  |  |  |
| SMOC   | Stretch marks on case          |  |  |  |  |  |  |  |  |  |  |  |
| SRC    | Stems right side of chamber    |  |  |  |  |  |  |  |  |  |  |  |
| SRIC   | Specific rings in chamber      |  |  |  |  |  |  |  |  |  |  |  |
| SSC    | shell stems carrier            |  |  |  |  |  |  |  |  |  |  |  |
| STC    | Stems top chamber              |  |  |  |  |  |  |  |  |  |  |  |
| SWE    | Safety switch works too easily |  |  |  |  |  |  |  |  |  |  |  |
| SWH    | Safety switch works too hard   |  |  |  |  |  |  |  |  |  |  |  |
| SWW    | Safety ewitxh won't work       |  |  |  |  |  |  |  |  |  |  |  |
| TD     | Tips down                      |  |  |  |  |  |  |  |  |  |  |  |
| TU     | Tips up                        |  |  |  |  |  |  |  |  |  |  |  |
| TWP    | Trigger won't pull             |  |  |  |  |  |  |  |  |  |  |  |
| TWR    | Trigger won't retract          |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-T | Uncoded                        |  |  |  |  |  |  |  |  |  |  |  |
| XH     | Extracts hard                  |  |  |  |  |  |  |  |  |  |  |  |

|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB    | Extractor hits bbl                |  |  |  |  |  |  |  |  |  |  |  |  |
| HI     | High                              |  |  |  |  |  |  |  |  |  |  |  |  |
| LO     | Low                               |  |  |  |  |  |  |  |  |  |  |  |  |
| LEFT   | Left                              |  |  |  |  |  |  |  |  |  |  |  |  |
| RIGHT  | Right                             |  |  |  |  |  |  |  |  |  |  |  |  |
| DG     | Doesn't Group                     |  |  |  |  |  |  |  |  |  |  |  |  |
| FSST   | Front sight tipped                |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTT   | Rear sight tipped                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSBR   | Rear sight base raised            |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTR   | Front sight raised                |  |  |  |  |  |  |  |  |  |  |  |  |
| FSTL   | Front sight loose                 |  |  |  |  |  |  |  |  |  |  |  |  |
| RSTL   | Rear sight loose                  |  |  |  |  |  |  |  |  |  |  |  |  |
| MGPT-G | Missing parts at target           |  |  |  |  |  |  |  |  |  |  |  |  |
| UNCN-G | Uncoded nonconformity at target   |  |  |  |  |  |  |  |  |  |  |  |  |
|        |                                   |  |  |  |  |  |  |  |  |  |  |  |  |
| AI-P   | Assembly incomplete at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| BC-P   | Blows cases at proof              |  |  |  |  |  |  |  |  |  |  |  |  |
| BEB-P  | Barrel extension broken at proof  |  |  |  |  |  |  |  |  |  |  |  |  |
| BLP-P  | Blanked primer at proof           |  |  |  |  |  |  |  |  |  |  |  |  |
| BP-P   | Blown primer at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| BS-P   | Barrel split at proof             |  |  |  |  |  |  |  |  |  |  |  |  |
| DLOS-P | Doesn't lock over shells at proof |  |  |  |  |  |  |  |  |  |  |  |  |
| ESB-P  | Ejector sticks back at proof      |  |  |  |  |  |  |  |  |  |  |  |  |
| FCB-P  | Fore-end cracked at proof         |  |  |  |  |  |  |  |  |  |  |  |  |
| FESO-P | Fore-end shot off at proof        |  |  |  |  |  |  |  |  |  |  |  |  |
| FF-P   | Fails to fire at proof            |  |  |  |  |  |  |  |  |  |  |  |  |



| <b><i>Test Date:</i></b> |   |   |   |   |   |
|--------------------------|---|---|---|---|---|
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |
|                          |   |   |   |   |   |
| 0                        | 0 | 0 | 0 | 0 | 0 |

[illegible]











|  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |
|  |  |  |  |  |  |  |  |