

| | | |
|----------------|------------------------------------|--------------|
| Summary | Total Test + Proof Failures | 20240 |
| | Total Rejected: | 731 |
| | Overall Reject Rate: | 3.61 |

Proof

| | | | | | | | | | |
|-----------|-----|------|-----|-----|---|-----|-----|-----|------|
| Shot: | 384 | 1234 | 759 | 122 | | 5 | 2 | 513 | 9773 |
| Rejected: | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 3 |
| Percent: | 0.3 | 0.1 | 0.0 | 0.0 | | 0.0 | 0.0 | 0.0 | 0.0 |

Test

| | | | | | | | | | |
|-----------|------|------|-----|-----|---|-----|-----|------|------|
| Shot: | 527 | 1235 | 777 | 176 | | 5 | 3 | 460 | 9764 |
| Rejected: | 241 | 115 | 26 | 8 | 0 | 0 | 0 | 147 | 68 |
| Percent: | 45.7 | 9.3 | 3.3 | 4.5 | | 0.0 | 0.0 | 32.0 | 0.7 |

Target

| | | | | | | | | | |
|-----------|---|-----|---|---|---|---|---|---|---|
| Shot: | | 12 | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 2 |
| Percent: | | 0.0 | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|-------|--|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| AB | Action binds | 21 | 4 | | | | | | 4 | 9 |
| ASFB | Action spring follower binds | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | |
| BC | Blows cases | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 5 |
| BSCO | Barrel support came out | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 4 | | | | | | | | |
| CD | Case dented | | | | | | | | | |
| CH | Closes hard | | | | | | | | | |
| CHAB | Carrier hits action bar | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | 1 |
| CO | Cut-off | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | |
| CS | Cases swell | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|------|--------------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| CTOG | Chamber torn or gouged | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | |
| DBB | Doesn't blow back | 4 | 8 | 23 | 5 | | | | 12 | |
| DCS | Double click in safety switch | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | |
| DCU | Doesn't close-up | | 3 | | | | | | | |
| DE | Doesn't eject | 3 | 39 | 1 | | | | | 10 | 1 |
| DEL | Doesn't eject live round | | | | | | | | | |
| DFU | Doesn't feed up | 1 | 3 | | | | | | 5 | |
| DLO | Doesn't lock open (after last shell) | 2 | 8 | 1 | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | 1 | 10 |
| DS | Dead safe | | | | | | | | | |
| DSM | Drops shell-magazine | 9 | | | | | | | 1 | |
| DTL | Doesn't trip latch | 10 | 1 | | | | | | 1 | |
| DX | Doesn't extract | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 35 | |
| ESB | Ejector sticks back | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | 1 | |
| FA | Fires automatically | | | | | | | | | |
| FB | Follower binds | | | | | | | | | 4 |
| FC | Fails to connect | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | |
| FD | Follows-down | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | 1 |
| FFM | Fails to feed from magazine | 29 | 5 | | 1 | | | | 22 | 1 |
| FFP | Flat firing pin | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|------|-----------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| GCSQ | Gas cyl. shot off | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 8 |
| HPA | High pressure ammo | | | | | | | | | |
| HUE | Hard under extractor | 20 | 14 | | | | | | 3 | 9 |
| ILOP | Int. latch out of position | | 2 | | | | | | 1 | |
| ILRM | Int. latch ret. Missing | 4 | 8 | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | |
| JL | Jumps latch | 20 | 1 | | | | | | 5 | |
| JO | Jars off | | | | | | | | | |
| LB | Light blow | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | |
| MCW | Magazine capacity wrong | 1 | 1 | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | 1 |
| OH | Opens hard | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | |
| PSM | Proof stamp missing | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | |
| RDW | (Action) release doesn't work | 2 | 3 | 1 | 1 | | | | | 1 |
| RIC | Rings in chamber | | | | | | | | | |
| SBC | Stems bottom chambers | 86 | | | | | | | 3 | |
| SBCL | Shell binds carrier latch | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 3 |
| SCX | Shell catches | | | | | | | | | |
| SHI | Short indent | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | 2 | 1 |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|--------|--------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| SL | shaves lead | | | | | | | | | |
| SLC | Stems left side of chamber | 10 | | | | | | | 24 | |
| SMOC | Stretch marks on case | | | | | | | | | |
| SRC | Stems right side of chamber | 3 | | | | | | | 10 | |
| SRIC | Specific rings in chamber | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | 3 | |
| STC | Stems top chamber | 3 | 15 | | | | | | 4 | 12 |
| SWE | Safety switch works too easily | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | 1 |
| TD | Tips down | 9 | | | | | | | | |
| TU | Tips up | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | |
| UNCN-T | Uncoded | | | | 1 | | | | | |
| XH | Extracts hard | | | | | | | | | |
| XHB | Extractor hits bbl | | | | | | | | | |
| | | | | | | | | | | |
| HI | High | | | | | | | | | |
| LO | Low | | | | | | | | | |
| LEFT | Left | | | | | | | | | |
| RIGHT | Right | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | 2 |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|--------|-----------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | |
| BS-P | Barrel split at proof | 1 | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | |
| FF-P | Fails to fire at proof | | 1 | | | | | | | |
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | | |
| MSI-P | Magnaflux stamp illegible on bbl | | | | | | | | | |
| MSM-P | Magnaflux stamp missing on bbl | | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | | 3 |
| UNCM-P | Uncoded proof malfunctions | | | | | | | | | |

| Month: | | | | | | | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | | | |
| | 3511 | | 2646 | | 1031 | | 19980 | 3019 | 15930 |
| 0 | 1 | 0 | 1 | 0 | 1 | 0 | 8 | 2 | 5 |
| | 0.0 | | 0.0 | | 0.1 | | 0.040 | 0.066 | 0.031 |
| | 3511 | | 2643 | | 1128 | 3 | 20232 | 3183 | 15918 |
| 0 | 6 | 0 | 26 | 0 | 0 | 0 | 637 | 537 | 100 |
| | 0.2 | | 1.0 | | 0.0 | 0.0 | 3.15 | 16.87 | 0.63 |
| | | | | | 803 | | 815 | 12 | 0 |
| 0 | 0 | 0 | 0 | 0 | 84 | 0 | 86 | 0 | 2 |
| | | | | | 10.5 | | 10.55 | 0.00 | #DIV/0! |
| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
| | 1 | | 1 | | | | 40 | 29 | 11 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | 1 | | | | 1 | 0 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 5 | 0 | 5 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 4 | 4 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 1 | 0 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |


| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 52 | 52 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 3 | 3 | 0 |
| | | | | | | | 54 | 53 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 9 | 9 | 0 |
| | | | | | | | 11 | 11 | 0 |
| | | | 3 | | | | 14 | 1 | 13 |
| | | | | | | | 0 | 0 | 0 |
| | 1 | | | | | | 11 | 10 | 1 |
| | | | | | | | 12 | 12 | 0 |
| | | | 2 | | | | 2 | 0 | 2 |
| | | | | | | | 0 | 0 | 0 |
| | | | 9 | | | | 44 | 35 | 9 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 1 | 1 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 4 | 0 | 4 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 1 | 0 | 1 |
| | | | | | | | 58 | 57 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |

| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | 0 | 0 | 0 |
| | 1 | | 1 | | | | 10 | 0 | 10 |
| | | | | | | | 0 | 0 | 0 |
| | 1 | | 1 | | | | 48 | 37 | 11 |
| | | | 1 | | | | 4 | 3 | 1 |
| | | | | | | | 12 | 12 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | 3 | | | | 29 | 26 | 3 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 2 | 2 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | 1 | | | | | | 2 | 0 | 2 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 8 | 7 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | 1 | | | | 90 | 89 | 1 |
| | | | | | | | | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | 1 | | | | 4 | 0 | 4 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 3 | 2 | 1 |

| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 34 | 34 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 13 | 13 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 3 | 3 | 0 |
| | | | | | | | 34 | 22 | 12 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 1 | 0 | 1 |
| | | | | | | | 9 | 9 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 1 | 1 | 0 |
| | 1 | | 2 | | | | 3 | 0 | 3 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | | | 0 |
| | | | | | 50 | | 50 | 0 | 0 |
| | | | | | 11 | | 11 | 0 | 0 |
| | | | | | 2 | | 2 | 0 | 0 |
| | | | | | 13 | | 13 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | 1 | | 1 | 0 | 0 |
| | | | | | 1 | | 1 | 0 | 0 |
| | | | | | 6 | | 8 | 0 | 2 |

GALLERY TOP FAULTS FOR PUMP SHOTGUNS - CURRENT MONTH THROUGH:

8/13/06




through:

| DSM | FF | FFM | ILOP |
|----------------------|---------------|-----------------------------|----------------------------|
| Drops shell-magazine | Falls to fire | Falls to feed from magazine | Int. latch out of position |

Gallery Top Faults for Autoloading Shotguns - Current month through:

8/13/06




| | U | TD | RDW | CC | DCU |
|--|---|----|-----|----|-----|
| Tips down | | | | | |
| (Action) release doesn't work | | | | | |
| Carrier catches on shells, mag, receiver | | | | | |
| Doesn't close-up | | | | | |

ILE00064012

Gallery Top Faults for Police Shotguns - Current month through:

8/13/06



| position | Barrel support came out | Shells catch on bal support-feeding | Shells catch on bal support-loading | Carrier catches on shells mag receiver |
|----------|----------------------------|--|--|---|
| P | B3C0 | CBS-F | CBS-L | CC |

ILE00064014

| | | |
|--------|-----------------------------------|---|
| DS | Dead safe | 0 |
| DTL | Doesn't trip latch | 0 |
| DXL | Doesn't extract live round | 0 |
| ESB | Ejector sticks back | 0 |
| ESS | Extractor stems shell | 0 |
| FA | Fires automatically | 0 |
| FC | Fails to connect | 0 |
| FCB | Fore-end cracked or broken | 0 |
| FD | Follows-down | 0 |
| FFP | Flat firing pin | 0 |
| FOS | Fires on safe | 0 |
| FSR | Fires when safe is released | 0 |
| GCSO | Gas cyl shot off | 0 |
| HPA | High pressure ammo | 0 |
| ILRM | Int. latch ret. Missing | 0 |
| ILSB | Int. latch stud broken | 0 |
| ILSP | Int. latch spring out of position | 0 |
| JO | Jars off | 0 |
| LB | Light blow | 0 |
| MCSO | Magazine cap shot off | 0 |
| MCW | Magazine capacity wrong | 0 |
| MFA | Misfires (ammo) | 0 |
| MFOP | Magazine follower out of position | 0 |
| OH | Opens hard | 0 |
| PH | Pulls hard | 0 |
| PSI | Proof stamp illegible | 0 |
| PSM | Proof stamp missing | 0 |
| RBOC | Rings and bulges on case | 0 |
| RIC | Rings in chamber | 0 |
| SBCL | Shell binds carrier latch | 0 |
| SBE | Stems bbl extension | 0 |
| SCX | Shell catches | 0 |
| SHI | Short indent | 0 |
| SL | shaves lead | 0 |
| SLC | Stems left side of chamber | 0 |
| SMOC | Stretch marks on case | 0 |
| SRC | Stems right side of chamber | 0 |
| SRIC | Specific rings in chamber | 0 |
| SSC | shell stems carrier | 0 |
| SWE | Safety switch works too easily | 0 |
| SWH | Safety switch works too hard | 0 |
| TD | Tips down | 0 |
| TU | Tips up | 0 |
| TWP | Trigger won't pull | 0 |
| TWR | Trigger won't retract | 0 |
| UNCN-T | Uncoded | 0 |
| XHB | Extractor hits bbl | 0 |
| | | 0 |
| HI | High | 0 |
| LO | Low | 0 |
| LEFT | Left | 0 |

| | | |
|--------|-----------------------------------|---|
| RIGHT | Right | 0 |
| DG | Doesn't Group | 0 |
| FSST | Front sight tipped | 0 |
| RSTT | Rear sight tipped | 0 |
| RSBR | Rear sight base raised | 0 |
| FSTR | Front sight raised | 0 |
| FSTL | Front sight loose | 0 |
| RSTL | Rear sight loose | 0 |
| MGPT-G | Missing parts at target | 0 |
| UNCN-G | Uncoded nonconformity at target | 0 |
| AI-P | Assembly incomplete at proof | 0 |
| BC-P | Blows cases at proof | 0 |
| BEB-P | Barrel extension broken at proof | 0 |
| BLP-P | Blanked primer at proof | 0 |
| BP-P | Blown primer at proof | 0 |
| BS-P | Barrel split at proof | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P | Ejector sticks back at proof | 0 |
| FCB-P | Fore-end cracked at proof | 0 |
| FESO-P | Fore-end shot off at proof | 0 |
| GCSO-P | Gas cylinder shot off at proof | 0 |
| GRSO-P | Guide ring shot off at proof | 0 |
| MCSO-P | Magazine cap shot off at proof | 0 |
| MSI-P | Magnaflux stamp illegible on bbl | 0 |
| MSM-P | Magnaflux stamp missing on bbl | 0 |
| PP-P | Pierced primer at proof | 0 |
| UNCM-P | Uncoded proof malfunctions | 0 |
| | | |

| | | |
|--------|--|----|
| SBC | Stems bottom chambers | 89 |
| FFM | Fails to feed from magazine | 57 |
| DE | Doesn't eject | 51 |
| DBB | Doesn't blow back | 49 |
| HUE | Hard under extractor | 37 |
| EDS | Extractor drops shell | 35 |
| SLC | Stems left side of chamber | 34 |
| AB | Action binds | 29 |
| JL | Jumps latch | 26 |
| STC | Stems top chamber | 17 |
| SRC | Stems right side of chamber | 13 |
| DTL | Doesn't trip latch | 12 |
| ILRM | Int. latch ret. Missing | 12 |
| DLO | Doesn't lock open (after last shell) | 11 |
| DSM | Drops shell-magazine | 10 |
| DFU | Doesn't feed up | 9 |
| TD | Tips down | 9 |
| RDW | (Action) release doesn't work | 7 |
| CC | Carrier catches on shells,mag,receiver | 4 |
| DCU | Doesn't close-up | 3 |
| ILOP | Int. latch out of position | 3 |
| SSC | shell stems carrier | 3 |
| MCW | Magazine capacity wrong | 2 |
| SIC | Stems in chamber | 2 |
| DLU | Doesn't lock-up | 1 |
| ESS | Extractor stems shell | 1 |
| UNCN-T | Uncoded | 1 |
| BS-P | Barrel split at proof | 1 |
| FF-P | Fails to fire at proof | 1 |
| ASFB | Action spring follower binds | 0 |
| BABS | Bulge at body shoulder | 0 |
| BAC | Burr at chamber | 0 |
| BB | Bolt binds/catches | 0 |
| BCOE | Bolt catches on ejector | 0 |
| BC | Blows cases | 0 |
| BLOP | Bar lock or disconnecter out of position | 0 |
| BSCO | Barrel support came out | 0 |
| CBS-F | Shells catch on bbl support-feeding | 0 |
| CBS-L | Shells catch on bbl support-loading | 0 |
| CD | Case dented | 0 |
| CH | Closes hard | 0 |
| CHAB | Carrier hits action bar | 0 |
| CLM | Can't load magazine | 0 |
| CO | Cut-off | 0 |
| CR | Cuts rim | 0 |
| CS | Cases swell | 0 |
| CTOG | Chamber torn or gouged | 0 |
| CTP | Creepy trigger pull | 0 |
| CWSB | Cams wrong side of action bar | 0 |
| DCS | Double click in safety switch | 0 |
| DCT | Double click in trigger | 0 |

| | | |
|-------|-----------------------------------|---|
| DEL | Doesn't eject live round | 0 |
| DS | Dead safe | 0 |
| DX | Doesn't extract | 0 |
| DXL | Doesn't extract live round | 0 |
| ESB | Ejector sticks back | 0 |
| FA | Fires automatically | 0 |
| FB | Follower binds | 0 |
| FC | Fails to connect | 0 |
| FCB | Fore-end cracked or broken | 0 |
| FD | Follows-down | 0 |
| FF | Fails to fire | 0 |
| FFP | Flat firing pin | 0 |
| FOS | Fires on safe | 0 |
| FSR | Fires when safe is released | 0 |
| GCSO | Gas cyl shot off | 0 |
| GRSO | Guide ring shot off | 0 |
| HPA | High pressure ammo | 0 |
| ILSB | Int. latch stud broken | 0 |
| ILSP | Int. latch spring out of position | 0 |
| JO | Jars off | 0 |
| LB | Light blow | 0 |
| MCSO | Magazine cap shot off | 0 |
| MFA | Misfires (ammo) | 0 |
| MFOP | Magazine follower out of position | 0 |
| MLH | Magazine loads hard | 0 |
| OH | Opens hard | 0 |
| PH | Pulls hard | 0 |
| PSI | Proof stamp illegible | 0 |
| PSM | Proof stamp missing | 0 |
| RBOC | Rings and bulges on case | 0 |
| RIC | Rings in chamber | 0 |
| SBCL | Shell binds carrier latch | 0 |
| SBE | Stems bbl extension | 0 |
| SCB | Stock cracked or broken | 0 |
| SCX | Shell catches | 0 |
| SHI | Short indent | 0 |
| SL | shaves lead | 0 |
| SMOC | Stretch marks on case | 0 |
| SRIC | Specific rings in chamber | 0 |
| SWE | Safety switch works too easily | 0 |
| SWH | Safety switch works too hard | 0 |
| SWW | Safety switch won't work | 0 |
| TU | Tips up | 0 |
| TWP | Trigger won't pull | 0 |
| TWR | Trigger won't retract | 0 |
| XH | Extracts hard | 0 |
| XHB | Extractor hits bbl | 0 |
| HI | High | 0 |
| LO | Low | 0 |
| LEFT | Left | 0 |
| RIGHT | Right | 0 |

| | | |
|--------|-----------------------------------|---|
| DG | Doesn't Group | 0 |
| FSST | Front sight tipped | 0 |
| RSTT | Rear sight tipped | 0 |
| RSBR | Rear sight base raised | 0 |
| FSTR | Front sight raised | 0 |
| FSTL | Front sight loose | 0 |
| RSTL | Rear sight loose | 0 |
| MGPT-G | Missing parts at target | 0 |
| UNCN-G | Uncoded nonconformity at target | 0 |
| AI-P | Assembly incomplete at proof | 0 |
| BC-P | Blows cases at proof | 0 |
| BEB-P | Barrel extension broken at proof | 0 |
| BLP-P | Blanked primer at proof | 0 |
| BP-P | Blown primer at proof | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P | Ejector sticks back at proof | 0 |
| FCB-P | Fore-end cracked at proof | 0 |
| FESO-P | Fore-end shot off at proof | 0 |
| GCSO-P | Gas cylinder shot off at proof | 0 |
| GRSO-P | Guide ring shot off at proof | 0 |
| MCSO-P | Magazine cap shot off at proof | 0 |
| MSI-P | Magnaflux stamp illegible on bbl | 0 |
| MSM-P | Magnaflux stamp missing on bbl | 0 |
| PP-P | Pierced primer at proof | 0 |
| SCB-P | Stock cracked or broken at proof | 0 |
| UNCM-P | Uncoded proof malfunctions | 0 |
| | | |
| | | |

| | | |
|--------|--|----|
| HI | High | 48 |
| RIGHT | Right | 13 |
| LO | Low | 11 |
| MGPT-G | Missing parts at target | 5 |
| LEFT | Left | 1 |
| FSTL | Front sight loose | 1 |
| RSTL | Rear sight loose | 1 |
| SCB-P | Stock cracked or broken at proof | 1 |
| AB | Action binds | 0 |
| ASFB | Action spring follower binds | 0 |
| BABS | Bulge at body shoulder | 0 |
| BAC | Burr at chamber | 0 |
| BB | Bolt binds/catches | 0 |
| BCOE | Bolt catches on ejector | 0 |
| BC | Blows cases | 0 |
| BLOP | Bar lock or disconnecter out of position | 0 |
| BSCO | Barrel support came out | 0 |
| CBS-F | Shells catch on bbl support-feeding | 0 |
| CBS-L | Shells catch on bbl support-loading | 0 |
| CC | Carrier catches on shells,mag,receiver | 0 |
| CD | Case dented | 0 |
| CH | Closes hard | 0 |
| CHAB | Carrier hits action bar | 0 |
| CLM | Can't load magazine | 0 |
| CO | Cut-off | 0 |
| CR | Cuts rim | 0 |
| CS | Cases swell | 0 |
| CTOG | Chamber torn or gouged | 0 |
| CTP | Creepy trigger pull | 0 |
| CWSB | Cams wrong side of action bar | 0 |
| DBB | Doesn't blow back | 0 |
| DCS | Double click in safety switch | 0 |
| DCT | Double click in trigger | 0 |
| DCU | Doesn't close-up | 0 |
| DE | Doesn't eject | 0 |
| DEL | Doesn't eject live round | 0 |
| DFU | Doesn't feed up | 0 |
| DLO | Doesn't lock open (after last shell) | 0 |
| DLU | Doesn't lock-up | 0 |
| DS | Dead safe | 0 |
| DSM | Drops shell magazine | 0 |
| DTL | Doesn't trip latch | 0 |
| DX | Doesn't extract | 0 |
| DXL | Doesn't extract live round | 0 |
| EDS | Extractor drops shell | 0 |
| ESB | Ejector sticks back | 0 |
| ESS | Extractor stems shell | 0 |
| FA | Fires automatically | 0 |
| FB | Follower binds | 0 |
| FC | Fails to connect | 0 |
| FCB | Fore-end cracked or broken | 0 |

| | | |
|--------|-----------------------------------|---|
| FD | Follows-down | 0 |
| FF | Fails to fire | 0 |
| FFM | Fails to feed from magazine | 0 |
| FFP | Flat firing pin | 0 |
| FOS | Fires on safe | 0 |
| FSR | Fires when safe is released | 0 |
| GCSO | Gas cyl shot off | 0 |
| GRSO | Guide ring shot off | 0 |
| HPA | High pressure ammo | 0 |
| HUE | Hard under extractor | 0 |
| ILOP | Int. latch out of position | 0 |
| ILRM | Int. latch ret. Missing | 0 |
| ILSB | Int. latch stud broken | 0 |
| ILSP | Int. latch spring out of position | 0 |
| JL | Jumps latch | 0 |
| JO | Jars off | 0 |
| LB | Light blow | 0 |
| MCSO | Magazine cap shot off | 0 |
| MCW | Magazine capacity wrong | 0 |
| MFA | Misfires (ammo) | 0 |
| MFOP | Magazine follower out of position | 0 |
| MLH | Magazine loads hard | 0 |
| OH | Opens hard | 0 |
| PH | Pulls hard | 0 |
| PSI | Proof stamp illegible | 0 |
| PSM | Proof stamp missing | 0 |
| RBOC | Rings and bulges on case | 0 |
| RDW | (Action) release doesn't work | 0 |
| RIC | Rings in chamber | 0 |
| SBC | Stems bottom chambers | 0 |
| SBCL | Shell binds carrier latch | 0 |
| SBE | Stems bbl extension | 0 |
| SCB | Stock cracked or broken | 0 |
| SCX | Shell catches | 0 |
| SHI | Short indent | 0 |
| SIC | Stems in chamber | 0 |
| SL | shaves lead | 0 |
| SLC | Stems left side of chamber | 0 |
| SMOC | Stretch marks on case | 0 |
| SRC | Stems right side of chamber | 0 |
| SRIC | Specific rings in chamber | 0 |
| SSC | shell stems carrier | 0 |
| STC | Stems top chamber | 0 |
| SWE | Safety switch works too easily | 0 |
| SWH | Safety switch works too hard | 0 |
| SWW | Safety switch won't work | 0 |
| TD | Tips down | 0 |
| TU | Tips up | 0 |
| TWP | Trigger won't pull | 0 |
| TWR | Trigger won't retract | 0 |
| UNCN-T | Uncoded | 0 |

| | | |
|--------|-----------------------------------|---|
| XH | Extracts hard | 0 |
| XHB | Extractor hits bbl | 0 |
| DG | Doesn't Group | 0 |
| FSST | Front sight tipped | 0 |
| RSTT | Rear sight tipped | 0 |
| RSBR | Rear sight base raised | 0 |
| FSTR | Front sight raised | 0 |
| UNCN-G | Uncoded nonconformity at target | 0 |
| | | 0 |
| AI-P | Assembly incomplete at proof | 0 |
| BC-P | Blows cases at proof | 0 |
| BEB-P | Barrel extension broken at proof | 0 |
| BLP-P | Blanked primer at proof | 0 |
| BP-P | Blown primer at proof | 0 |
| BS-P | Barrel split at proof | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P | Ejector sticks back at proof | 0 |
| FCB-P | Fore-end cracked at proof | 0 |
| FESO-P | Fore-end shot off at proof | 0 |
| FF-P | Fails to fire at proof | 0 |
| GCSO-P | Gas cylinder shot off at proof | 0 |
| GRSO-P | Guide ring shot off at proof | 0 |
| MCSO-P | Magazine cap shot off at proof | 0 |
| MSI-P | Magnaflux stamp illegible on bbl | 0 |
| MSM-P | Magnaflux stamp missing on bbl | 0 |
| PP-P | Pierced primer at proof | 0 |
| UNCM-P | Uncoded proof malfunctions | 0 |
| | | 0 |

| | | | | | | | | | | | |
|----------------|-----------|------------------------------------|------|-------------|-----|---|---|-----|-----|-----|---|
| Summary | | Total Test + Proof Failures | | 1491 | | | | | | | |
| | | Total Rejected: | | 37 | | | | | | | |
| | | Overall Reject Rate: | | 2.48 | | | | | | | |
| Proof | Shot: | 22 | 5 | 70 | 30 | | | | 3 | 987 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | 0.0 | | | | 0.0 | 0.0 | |
| Test | Shot: | 40 | 4 | 123 | 41 | | | 1 | 7 | 984 | |
| | Rejected: | 21 | 1 | 6 | 1 | 0 | 0 | 0 | 0 | 7 | 0 |
| | Percent: | 52.5 | 25.0 | 4.9 | 2.4 | | | 0.0 | 0.0 | 0.7 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|------|--------------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| CHAB | Carrier hits action bar | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | 1 | |
| CO | Cut-off | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | |
| DBB | Doesn't blow back | | | 4 | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | |
| DE | Doesn't eject | | 1 | 1 | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | 1 | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | 2 | |
| DS | Dead safe | | | | | | | | | | |
| DSM | Drops shell-magazine | 2 | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|------|-----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| FA | Fires automatically | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | 1 | |
| FC | Fails to connect | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | |
| FFM | Fails to feed from magazine | 5 | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | |
| JL | Jumps latch | 5 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|------|--------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| MLH | Magazine loads hard | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | |
| PSM | Proof stamp missing | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | 1 | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | |
| SBC | Stems bottom chambers | 9 | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | |
| SCX | Shell catches | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | 1 | |
| SL | shaves lead | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | 1 | |
| SWE | Safety switch works too easily | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|--------|----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| TD | Tips down | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | |
| XHB | Extractor hits bbl | | | | | | | | | | |
| | | | | | | | | | | | |
| HI | High | | | | | | | | | | |
| LO | Low | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | |
| | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|--------|-----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| BLP-P | Blanked primer at proof | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | |
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | | | |
| MSI-P | Magnaflux stamp illegible on bbl | | | | | | | | | | |
| MSM-P | Magnaflux stamp missing on bbl | | | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | | | |
| UNCM-P | Uncoded proof malfunctions | | | | | | | | | | |

| Test Date: | | | | |
|------------|-----|-----|--|---|
| 4 | 211 | 75 | | |
| 0 | 1 | 0 | | 0 |
| 0.0 | 0.5 | 0.0 | | |
| 4 | 211 | 75 | | |
| 0 | 0 | 0 | | 0 |
| 0.0 | 0.0 | 0.0 | | |
| 0 | 0 | 0 | | 0 |
| 0.0 | 0.0 | 0.0 | | |
| 0 | 0 | 0 | | 0 |
| 0.0 | 0.0 | 0.0 | | |

| | | | |
|-----|-----|-----|-----|
| 4 | 0 | 211 | 75 |
| 0 | 0 | 1 | 0 |
| 0.0 | 0.0 | 0.5 | 0.0 |
| 4 | 0 | 211 | 75 |
| 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | 0.0 |

[illegible]

[illegible]

[illegible]

[illegible]

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 903 |
| | Total Rejected: | 50 |
| | Overall Reject Rate: | 5.54 |

| | | | | | | | | | | |
|---------------|-----------|-----|-----|---|---|---|---|---|-----|---|
| Proof | Shot: | 50 | 98 | | | | | | 714 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | | | | | | 0.0 | |
| Test | Shot: | | 93 | | | | | | 714 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 2 | 0 |
| | Percent: | | 0.0 | | | | | | 0.3 | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | 1 | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | 1 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | | | | | |
|------------|---|-----|------|-----|-----|-----|-----|-----|-----|
| 0 | 0 | 19 | 103 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 19 | 77 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| 0 | 0 | 0 | 132 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 48 | 0 | 0 | 0 | 0 | 0 | 0 |
| | | | 36.4 | | | | | | |

| Test Date: | | | | | | | | | |
|------------|---|-----|------|-----|-----|-----|-----|-----|-----|
| 0 | 0 | 19 | 103 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 19 | 77 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| 0 | 0 | 0 | 132 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 48 | 0 | 0 | 0 | 0 | 0 | 0 |
| | | | 36.4 | | | | | | |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1414 |
| | Total Rejected: | 15 |
| | Overall Reject Rate: | 1.06 |

| | | | | | | | | | | | |
|---------------|-----------|---|---|-----|---|---|---|---|-----|-----|---|
| Proof | Shot: | | | 207 | | | | | 26 | 601 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | 0.0 | | | | | 0.0 | 0.0 | |
| Test | Shot: | | | 252 | | | | | | 600 | |
| | Rejected: | 0 | 0 | 5 | 0 | 0 | 0 | 0 | 0 | 6 | 0 |
| | Percent: | | | 2.0 | | | | | | 1.0 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 2 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|---|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | 5 | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | 1 | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 2 | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | 1 | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | | | | | |
|------------|---|------|---|-----|--|--|--|--|---|
| 97 | | 4.11 | | 58 | | | | | |
| 0 | 0 | 0 | 0 | 0 | | | | | 0 |
| 0.0 | | 0.0 | | 0.0 | | | | | |
| 97 | | 409 | | 56 | | | | | |
| 0 | 0 | 4 | 0 | 0 | | | | | 0 |
| 0.0 | | 1.0 | | 0.0 | | | | | |
| 0 | 0 | 0 | 0 | 0 | | | | | 0 |

| | | | | |
|-----|---|-----|---|-----|
| 97 | | 411 | | 58 |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 |
| 97 | | 409 | | 56 |
| 0 | 0 | 4 | 0 | 0 |
| 0.0 | | 1.0 | | 0.0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1408 |
| | Total Rejected: | 52 |
| | Overall Reject Rate: | 3.69 |

| | | | | | | | | | | | |
|---------------|-----------|------|---|-----|---|---|---|---|------|-----|---|
| Proof | Shot: | | | 209 | | | | | | 913 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | 0.0 | | | | | | 0.0 | |
| Test | Shot: | 26 | | 224 | | | | | 31 | 913 | |
| | Rejected: | 18 | 0 | 12 | 0 | 0 | 0 | 0 | 11 | 7 | 0 |
| | Percent: | 69.2 | | 5.4 | | | | | 35.5 | 0.8 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 2 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 2 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|--|----|--|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | 12 | | | | | 1 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | 1 | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | 1 | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | 1 | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|--|--|--|--|--|--|---|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | 2 | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 1 | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 1 | | | | | | | 2 | 1 | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 1 | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|--|--|--|--|---|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 12 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | 3 | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | 1 | | | | | | 1 | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | 1 | | 1 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

| | | | | | |
|--|--|--|----|--|-----|
| | | | | | |
| | | | 79 | | 135 |
| | | | | | |

| | | | |
|-----------|--|--|-----|
| 870 light | | | 870 |
|-----------|--|--|-----|

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | | | | | | | | | | |
|---------|-----------|-----------------------------|-----|------|-----|---|---|---|-----|-----|---|
| Summary | | Total Test + Proof Failures | | 1244 | | | | | | | |
| | | Total Rejected: | | 27 | | | | | | | |
| | | Overall Reject Rate: | | 2.17 | | | | | | | |
| Proof | Shot: | 13 | 60 | 143 | | | | | 17 | 598 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | | | | | 0.0 | 0.5 | |
| Test | Shot: | 38 | 65 | 47 | 32 | | | | | 598 | |
| | Rejected: | 10 | 1 | 0 | 2 | 0 | 0 | 0 | 0 | 3 | 0 |
| | Percent: | 26.3 | 1.5 | 0.0 | 6.3 | | | | | 0.5 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 2 | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|---|---|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | 1 | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | 4 | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 2 | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | 2 | | | | | | | | 2 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | | | | | |
|------------|---|-----|---|-----|---|--|--|--|-----|
| 99 | | 257 | | 35 | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | | | | |
| 0.0 | | 0.0 | | 0.0 | | | | | |
| 99 | | 257 | | 105 | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | | | | |
| 0.0 | | 0.0 | | 0.0 | | | | | |
| 0 | 0 | 0 | 0 | 97 | | | | | 0 |
| | | | | 8 | | | | | 8.2 |

| | | | | | |
|-----|---|-----|---|-----|---|
| 99 | | 257 | | 35 | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 | |
| 99 | | 257 | | 105 | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 | |
| 0 | 0 | 0 | 0 | 97 | 0 |
| | | | | 8 | |
| | | | | 8.2 | |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1350 |
| | Total Rejected: | 70 |
| | Overall Reject Rate: | 5.19 |

Proof

| | | | | | | | | | | |
|-----------|-----|-----|---|---|---|---|---|---|-----|---|
| Shot: | 38 | 144 | | | | | | | 681 | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | 0.0 | 0.0 | | | | | | | 0.0 | |

Test

| | | | | | | | | | | |
|-----------|------|-----|-----|---|---|---|---|------|-----|---|
| Shot: | 78 | 94 | 20 | | | | | 25 | 681 | |
| Rejected: | 42 | 6 | 1 | 0 | 0 | 0 | 0 | 15 | 4 | 0 |
| Percent: | 53.8 | 6.4 | 5.0 | | | | | 60.0 | 0.6 | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 4 | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|---|--|--|--|--|--|---|---|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | 2 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | 1 | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | 1 | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | 1 | 1 | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 1 | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 1 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|---|--|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 7 | 1 | | | | | | 6 | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | 1 | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 4 | | | | | | | | | | |
| ILOP | Int. latch out of position | | 1 | | | | | | | | | |
| ILRM | Int. latch ret. Missing | 1 | 2 | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 6 | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|---|--|--|--|---|---|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | 1 | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 14 | | | | | | 1 | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 3 | | | | | | 3 | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | 2 | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | 1 | | | | | | | 2 | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | | | | | | | | | | |
|--------|----------------------------------|--|--|--|--|--|--|--|--|--|
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | | |
| MSI-P | Magnaflux stamp illegible on bbl | | | | | | | | | |
| MSM-P | Magnaflux stamp missing on bbl | | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | | |
| UNCM-P | Uncoded proof malfunctions | | | | | | | | | |

| Test Date: | | | | | | | | | |
|------------|-----|-----|---|---|-----|-----|---|---|---|
| 344 | | 3 | | | 81 | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | | | 0.0 | 0.0 | | | |
| 344 | | 3 | | | 102 | 3 | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | |
| 0.0 | 0.0 | 0.0 | | | 0.0 | 0.0 | | | |
| 0 | | 0 | 0 | 0 | 40 | | | | |
| | | | | | 2 | 0 | | | |
| | | | | | 5.0 | | | | |

| | | |
|-----|-----|-----|
| 344 | 3 | 81 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 344 | 3 | 102 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 0 | 0 | 40 |
| 0 | 0 | 2 |
| | | 50 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1208 |
| | Total Rejected: | 20 |
| | Overall Reject Rate: | 1.66 |

| | | | | | | | | | | | |
|---------------|-----------|-----|-----|---|---|---|---|---|------|-----|---|
| Proof | Shot: | 74 | | | | | | | 142 | 624 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | | | | | | | 0.0 | 0.0 | |
| Test | Shot: | | 30 | | | | | | 52 | 624 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 9 | 1 | 0 |
| | Percent: | | 0.0 | | | | | | 17.3 | 0.2 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | 4 | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 5 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | 1 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | |
|------------|-----|-----|-----|---|
| 246 | 190 | 68 | | |
| 0 | 0 | 0 | 1 | 0 |
| 0.0 | 0.0 | 1.4 | | |
| 246 | 190 | 85 | | |
| 0 | 6 | 0 | 0 | 0 |
| 0.0 | 3.2 | 0.0 | | |
| | | 50 | | |
| 0 | 0 | 0 | 3 | 0 |
| | | | 6.0 | |

| | | | | |
|-----|-----|-----|-----|-----|
| 246 | 0 | 0 | 190 | 69 |
| 0 | 0 | 0 | 1 | 0 |
| 0.0 | 0.0 | 0.0 | 1.4 | |
| 246 | 0 | 0 | 190 | 85 |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 3.2 | 0.0 | 0.0 |
| 0 | 0 | 0 | 0 | 50 |
| | | | 3 | 0 |
| | | | 6.0 | |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 232 |
| | Total Rejected: | 14 |
| | Overall Reject Rate: | 6.03 |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|-----|---|
| Proof | Shot: | | | | | | | | | 86 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | 0.0 | |
| Test | Shot: | | | | | | | | | 86 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 6 | 0 |
| | Percent: | | | | | | | | | 7.0 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | 6 | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | |
|-------------------|------|---|---|---|---|
| 120 | 26 | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | | | | |
| 120 | 26 | 0 | 0 | | |
| 2 | 6 | 0 | 0 | | |
| 1.7 | 23.1 | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

| | | | |
|-----|------|---|---|
| 120 | 26 | | |
| 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | | |
| 120 | 26 | 0 | 0 |
| 2 | 6 | 0 | 0 |
| 1.7 | 23.1 | | |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1247 |
| | Total Rejected: | 99 |
| | Overall Reject Rate: | 7.94 |

| | | | | | | | | | | | |
|---------------|-----------|------|---|---|---|---|---|---|------|-----|---|
| Proof | Shot: | | | | | | | | 110 | 580 | |
| | Rejected: | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | 0.0 | 0.0 | |
| Test | Shot: | 102 | | | | | | | 137 | 579 | |
| | Rejected: | 48 | 0 | 0 | 0 | 0 | 0 | 0 | 45 | 1 | 0 |
| | Percent: | 47.1 | | | | | | | 32.8 | 0.2 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 5 | | | | | | | 1 | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|--|--|--|--|--|--|---|---|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | 3 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | 6 | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | 1 | | | |
| DLO | Doesn't lock open (after last shell) | 1 | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | 1 | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 2 | | | | | | | 1 | | | |
| DTL | Doesn't trip latch | 5 | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 8 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|--|--|--|--|--|--|----|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 4 | | | | | | | 10 | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 2 | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | 2 | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | 1 | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|--|--|--|--|--|---|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 14 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 5 | | | | | | | 5 | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | 5 | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | 3 | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | 9 | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|---|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | 1 | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | |
|------------|---|-----|---|-----|
| 276 | | 99 | | 53 |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 |
| 276 | | 99 | | 53 |
| 1 | 0 | 0 | 0 | 0 |
| 0.4 | | 0.0 | | 0.0 |
| 0 | 0 | 0 | 0 | 0 |
| | | | | 51 |
| | | | | 3 |
| | | | | 59 |

| | | | |
|-----|-----|-----|-----|
| 276 | | 99 | 53 |
| 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | 0.0 |
| 276 | | 99 | 53 |
| 1 | 0 | 0 | 0 |
| 0.4 | 0.0 | 0.0 | 0.0 |
| 0 | 0 | 0 | 0 |
| | | | 51 |
| | | | 3 |
| | | | 59 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1446 |
| | Total Rejected: | 54 |
| | Overall Reject Rate: | 3.73 |

| | | | | | | | | | | | |
|---------------|-----------|------|-----|---|---|---|---|---|------|-----|---|
| Proof | Shot: | 112 | 195 | | | | | | 64 | 671 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | | | | | | 0.0 | 0.0 | |
| Test | Shot: | 51 | 38 | | | | | | 66 | 671 | |
| | Rejected: | 21 | 3 | 0 | 0 | 0 | 0 | 0 | 24 | 3 | 0 |
| | Percent: | 41.2 | 7.9 | | | | | | 36.4 | 0.4 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 3 | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 1 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|---|--|--|--|--|--|---|---|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | 2 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | 2 | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | 1 | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 1 | | | | | | | | | | |
| DTL | Doesn't trip latch | 1 | 1 | | | | | | 1 | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 4 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | 1 | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|---|--|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 2 | 1 | | | | | | 2 | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | 1 | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 4 | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | 1 | 1 | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 1 | | | | | | | 2 | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|--|--|--|--|--|--|---|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 7 | | | | | | | 2 | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | 8 | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | 1 | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | | | | | | | | | | |
|--------|----------------------------------|--|--|--|--|--|--|--|--|--|
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | | |
| MSI-P | Magnaflux stamp illegible on bbl | | | | | | | | | |
| MSM-P | Magnaflux stamp missing on bbl | | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | | |
| UNCN-M | Uncoded proof malfunctions | | | | | | | | | |

| Test Date: | | | | |
|------------|---|-----|---|-----|
| 349 | | 220 | | 52 |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 |
| 349 | | 220 | | 51 |
| 0 | 0 | 1 | 0 | 0 |
| 0.0 | | 0.5 | | 0.0 |
| | | | | 51 |
| 0 | 0 | 0 | 0 | 0 |
| | | | | 39 |

| | | | |
|-----|---|-----|-----|
| 349 | | 220 | 52 |
| 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | 0.0 |
| 349 | | 220 | 51 |
| 0 | 0 | 1 | 0 |
| 0.0 | | 0.5 | 0.0 |
| 0 | 0 | 0 | 51 |
| 0 | 0 | 0 | 2 |
| | | | 39 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1381 |
| | Total Rejected: | 54 |
| | Overall Reject Rate: | 3.91 |

Proof

| | | | | | | | | | | |
|-----------|---|-----|-----|---|---|---|-----|-----|-----|---|
| Shot: | | 105 | 2 | | | | 2 | 40 | 576 | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | 0.0 | 0.0 | | | | 0.0 | 0.0 | 0.0 | |

Test

| | | | | | | | | | | |
|-----------|------|-----|-----|---|---|---|-----|------|-----|---|
| Shot: | 39 | 214 | 2 | | | | 2 | 30 | 576 | |
| Rejected: | 18 | 15 | 0 | 0 | 0 | 0 | 0 | 12 | 0 | 0 |
| Percent: | 46.2 | 7.0 | 0.0 | | | | 0.0 | 40.0 | 0.0 | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | 3 | | | | | | | 2 | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|---|--|--|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | 4 | | | | | | 1 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | 1 | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | 1 | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | 1 | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 1 | | | | | | | | | | |
| DTL | Doesn't trip latch | 2 | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 6 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|---|--|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 3 | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 3 | 1 | | | | | | 1 | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 2 | 1 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | 1 | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|---|--|--|--|--|---|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 4 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | 1 | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | 6 | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof |
| CPSO-P | Guide ring shot off at proof |
| MCSO-P | Magazine cap shot off at proof |
| MSI-P | Magnaflux stamp illegible or bbl |
| MSM-P | Magnaflux stamp missing or bbl |
| PP-P | Pierced primer at proof |
| SCB-P | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions |

Test Date:

| | | | |
|-----|----|----|--|
| 344 | 81 | 92 | |
|-----|----|----|--|

| | | | | |
|-----|---|----|---|----|
| 344 | | 81 | | 93 |
| 1 | 0 | 2 | 0 | 0 |

| | | |
|-----|-----|-----|
| 0.3 | 2.5 | 0.0 |
| 0 | 0 | 73 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1118 |
| | Total Rejected: | 71 |
| | Overall Reject Rate: | 6.35 |

Proof

| | | | | | | | | | | |
|-----------|-----|-----|-----|---|---|---|---|-----|-----|---|
| Shot: | 26 | 146 | 14 | | | | | 73 | 513 | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | 0.0 | 0.0 | 0.0 | | | | | 0.0 | 0.0 | |

Test

| | | | | | | | | | | |
|-----------|------|------|---|---|---|---|---|------|-----|---|
| Shot: | 22 | 195 | | | | | | 56 | 513 | |
| Rejected: | 12 | 38 | 0 | 0 | 0 | 0 | 0 | 20 | 1 | 0 |
| Percent: | 54.5 | 19.5 | | | | | | 35.7 | 0.2 | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 3 | | | | | | | 1 | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|----|--|--|--|--|----|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | 2 | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | 1 | | | | | | | | | |
| DE | Doesn't eject | | 11 | | | | | 1 | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | 1 | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | 6 | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 1 | | | | | | | | | | |
| DTL | Doesn't trip latch | 1 | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | 10 | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|----|--|--|--|--|---|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 1 | 2 | | | | | | 1 | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | 1 | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 4 | 11 | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | 1 | | | | |
| ILRM | Int. latch ret. Missing | | 4 | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | 1 | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|--|--|--|--|--|---|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | 1 | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 1 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | 2 | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | 1 | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | 2 | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

[illegible]

0
0
0
0
0
0

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | | |
|----------------|------------------------------------|--|-------------|
| Summary | Total Test + Proof Failures | | 1099 |
| | Total Rejected: | | 14 |
| | Overall Reject Rate: | | 1.27 |

Proof

| | | | | | | | | | | |
|-----------|-----|-----|---|---|---|---|---|-----|-----|---|
| Shot: | 8 | 127 | | | | | | 11 | 593 | |
| Rejected: | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | 0.0 | 0.8 | | | | | | 0.0 | 0.0 | |

Test

| | | | | | | | | | | |
|-----------|---|-----|---|---|---|---|---|---|-----|---|
| Shot: | | 171 | | | | | | | 593 | |
| Rejected: | 0 | 8 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 |
| Percent: | | 4.7 | | | | | | | 0.5 | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | 4 | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | 1 | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 1 | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|---|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | 4 | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|---|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | 1 | | | | | | | | | | |

| | |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof |
| GRSO-P | Guide ring shot off at proof |
| MCSO-P | Magazine cap shot off at proof |
| MSI-P | Magnaflux stamp illegible on bbl |
| MSSM-P | Magnaflux stamp missing on bbl |
| PP-P | Pierced primer at proof |
| SCB-P | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions |

Test Date:

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 392 |
| | Total Rejected: | 11 |
| | Overall Reject Rate: | 2.81 |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|-----|---|
| Proof | Shot: | | | | | | | | | 302 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | 0.0 | |
| Test | Shot: | | | | | | | | | 302 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 10 | 0 |
| | Percent: | | | | | | | | | 3.3 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | 5 | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 1 | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | 2 | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | 1 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | |
|-------------------|---|-----|-----|---|---|
| 14 | | | 76 | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | | | 0.0 | | |
| 14 | | | 76 | | |
| 0 | 0 | 1 | 0 | 0 | 0 |
| 0.0 | | 1.3 | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 210 |
| | Total Rejected: | 2 |
| | Overall Reject Rate: | 0.95 |

| | | | | | | | | | | |
|---------------|-----------|-----|---|---|---|---|---|---|-----|---|
| Proof | Shot: | 5 | | | | | | | 47 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | | | | | | | 0.0 | |
| Test | Shot: | 5 | | | | | | | 47 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| | Percent: | 0.0 | | | | | | | 2.1 | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

[illegible][illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | | | | | | | | |
|---------|-----------|-----------------------------|------|------|---|---|----|------|-----|
| Summary | | Total Test + Proof Failures | | 1257 | | | | | |
| | | Total Rejected: | | 62 | | | | | |
| | | Overall Reject Rate: | | 4.93 | | | | | |
| Proof | Shot: | 16 | 101 | 4 | | | 7 | 219 | |
| | Rejected: | 0 | | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | | | | 0.0 | 0.0 |
| Test | Shot: | 52 | 165 | 6 | | | 33 | 219 | |
| | Rejected: | 23 | 24 | 0 | 0 | 0 | 0 | 6 | 5 |
| | Percent: | 44.2 | 14.5 | 0.0 | | | | 18.2 | 2.3 |
| Target | Shot: | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|----|--|--|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | 1 | | | | | | 2 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | 18 | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | 1 | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 1 | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 1 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|---|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 5 | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 1 | 1 | | | | | | | | | |
| ILOP | Int. latch out of position | | 1 | | | | | | | | | |
| ILRM | Int. latch ret. Missing | 2 | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 1 | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|---|--|--|--|--|--|---|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | 2 | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 10 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | 3 | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | 2 | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | 3 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

| | | |
|-----|-----|----|
| 259 | 450 | 64 |
|-----|-----|----|

| | | | |
|-----|---|-----|----|
| 259 | | 450 | 73 |
| 1 | 0 | 0 | 0 |

| | | | | | |
|--|-----|-----|-----|-----|-----|
| | 0.4 | 0.0 | 0.0 | 0.0 | 0.0 |
| | | | | 51 | 0.0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | | | | | | | | | | |
|---------|-----------|-----------------------------|-----|------|-----|---|---|---|-----|-----|---|
| Summary | | Total Test + Proof Failures | | 1261 | | | | | | | |
| | | Total Rejected: | | 17 | | | | | | | |
| | | Overall Reject Rate: | | 1.35 | | | | | | | |
| Proof | Shot: | 50 | 118 | 9 | 37 | | | | 20 | 416 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | 0.0 | | | | 0.0 | 0.0 | |
| Test | Shot: | 12 | 117 | 9 | 23 | | | | | 416 | |
| | Rejected: | 8 | 1 | 0 | 2 | 0 | 0 | 0 | 0 | 5 | 0 |
| | Percent: | 66.7 | 0.9 | 0.0 | 8.7 | | | | | 1.2 | |
| Target | Shot: | | 12 | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | 0.0 | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 1 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | 2 | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|---|--|--|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | 1 | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | 1 | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|--|--|--|---|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | 1 | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 6 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | 1 | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

B

[illegible][illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 858 |
| | Total Rejected: | 39 |
| | Overall Reject Rate: | 4.55 |

| | | | | | | | | | | | |
|---------------|-----------|------|------|------|-----|---|-----|---|------|-----|---|
| Proof | Shot: | 13 | 137 | 7 | | | 5 | | | 264 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | | | 0.0 | | | 0.0 | |
| Test | Shot: | 54 | 60 | 7 | 48 | | 5 | | 23 | 264 | |
| | Rejected: | 15 | 13 | 2 | 3 | 0 | 0 | 0 | 5 | 0 | 0 |
| | Percent: | 27.8 | 21.7 | 28.6 | 6.3 | | 0.0 | | 21.7 | 0.0 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 1 | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|---|---|---|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | 1 | 1 | 2 | 2 | | | | 1 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | 9 | | | | | | 1 | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | 1 | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|---|--|---|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 2 | | | 1 | | | | | 1 | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 1 | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | 1 | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|---|--|--|--|--|---|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | 1 | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 9 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | 1 | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | 1 | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof |
| GRSO-P | Guide ring shot off at proof |
| MCSO-P | Magazine cap shot off at proof |
| MSI-P | Magnaflex stamp illegible on bbl |
| MSM-P | Magnaflex stamp missing on bbl |
| PP-P | Pierced primer at proof |
| SCB-P | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions |

| Test Date: | | | | | |
|-------------------|---|-----|---|---|---|
| 134 | | 263 | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | | |
| 134 | | 263 | | | |
| 0 | 0 | 1 | 0 | 0 | 0 |
| 0.0 | | 0.4 | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof |
| GRSO-P | Guide ring shot off at proof |
| MCSO-P | Magazine cap shot off at proof |
| MSI-P | Magnaflux stamp illegible or bbl |
| MSM-P | Magnaflux stamp missing or bbl |
| PP-P | Pierced primer at proof |
| SCB-P | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | |
|-----------------------------|---|
| Total Test + Proof Failures | 0 |
| Total Rejected: | 0 |
| Overall Reject Rate: | |

| | | | | | | | | | | | |
|--------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | |
|-------------------|---|---|---|---|---|
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 721 |
| | Total Rejected: | 23 |
| | Overall Reject Rate: | 3.19 |

Proof

| | | | | | | | | | | |
|-----------|-----|-----|---|-----|---|---|---|---|-----|---|
| Shot: | 12 | 41 | | 51 | | | | | 388 | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | 0.0 | 0.0 | | 0.0 | | | | | 0.0 | |

Test

| | | | | | | | | | | |
|-----------|------|-----|---|-----|---|---|---|---|-----|---|
| Shot: | 13 | 77 | | 26 | | | | | 384 | |
| Rejected: | 5 | 5 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 |
| Percent: | 38.5 | 6.5 | | 0.0 | | | | | 0.8 | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 2 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 1 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|--|--|--|--|--|--|--|--|---|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | 3 | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | 2 | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | 2 | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|---|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | 5 | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|---|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | 2 | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| Test Date: | | | | | |
|------------|---|-----|-----|---|------|
| | | | 209 | | 27 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | 0.0 | | 0.0 |
| | | | | | |
| | | | 208 | | 13 |
| 0 | 0 | 4 | 0 | 0 | 0 |
| | | 1.9 | | | 0.0 |
| | | | | | |
| | | | 0 | | 22 |
| 0 | 0 | 0 | 0 | 0 | 4 |
| | | | | | 18.2 |

| Test Date: | | | | | |
|------------|---|-----|-----|------|---|
| 0 | 0 | 209 | 0 | 27 | 0 |
| | | 0.0 | 0.0 | 0.0 | 0 |
| | | 0.0 | | | |
| | | 208 | 0 | 13 | 0 |
| 0 | 0 | 4 | 0 | 0 | 0 |
| | | 1.9 | | 0.0 | |
| | | | | 22 | |
| 0 | 0 | 0 | 0 | 4 | 0 |
| | | | | 18.2 | |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

ILE00064354

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Test | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | |
|--|--|--|--|--|--|--|--|
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |