

| | | |
|----------------|------------------------------------|--------------|
| Summary | Total Test + Proof Failures | 11866 |
| | Total Rejected: | 592 |
| | Overall Reject Rate: | 4.99 |

Proof

| | | | | | | | | | |
|-----------|-----|-----|-----|-----|---|-----|-----|-----|------|
| Shot: | 770 | 278 | 797 | 27 | | 24 | 465 | 163 | 5430 |
| Rejected: | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 1 |
| Percent: | 0.0 | 0.0 | 0.1 | 0.0 | | 0.0 | 0.0 | 0.0 | 0.0 |

Test

| | | | | | | | | | |
|-----------|------|------|-----|-----|---|------|-----|------|------|
| Shot: | 949 | 158 | 658 | 27 | | 67 | 486 | 126 | 5419 |
| Rejected: | 353 | 57 | 24 | 0 | 0 | 10 | 24 | 50 | 27 |
| Percent: | 37.2 | 36.1 | 3.6 | 0.0 | | 14.9 | 4.9 | 39.7 | 0.5 |

Target

| | | | | | | | | | |
|-----------|---|---|-----|-----|---|-----|---|---|---|
| Shot: | | | 10 | 10 | | 226 | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | 0.0 | 0.0 | | 0.0 | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|-------|--|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| AB | Action binds | 5 | | 4 | | | | | | 5 |
| ASFB | Action spring follower binds | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | |
| BC | Blows cases | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | 1 | | | | | | | | 3 |
| BSCO | Barrel support came out | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 10 | 1 | | | | | | | 2 |
| CD | Case dented | | | | | | | | | |
| CH | Closes hard | | | | | | | | | |
| CHAB | Carrier hits action bar | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | |
| CO | Cut-off | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | |
| CS | Cases swell | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|------|--------------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| CTOG | Chamber torn or gouged | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | |
| DBB | Doesn't blow back | 20 | 1 | 4 | | | 1 | 1 | 9 | |
| DCS | Double click in safety switch | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | |
| DCU | Doesn't close up | | | | | | | | | |
| DE | Doesn't eject | 8 | | | | | | 1 | 1 | |
| DEL | Doesn't eject live round | | | | | | | | | |
| DFU | Doesn't feed up | 44 | | 1 | | | | | | |
| DLO | Doesn't lock open (after last shell) | 11 | | | | | | 2 | | |
| DLU | Doesn't lock-up | 1 | | | | | | 1 | | |
| DS | Dead safe | | | | | | | | | |
| DSM | Drops shell-magazine | 10 | 1 | | | | | | | |
| DTL | Doesn't trip latch | 3 | 1 | 1 | | | | | 1 | |
| DX | Doesn't extract | 1 | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | |
| EDS | Extractor drops shell | 1 | | | | | | 2 | 8 | |
| ESB | Ejector sticks back | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | |
| FB | Follower binds | | | | | | | | | |
| FC | Fails to connect | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | |
| FD | Follows-down | | | | | | | | | |
| FF | Fails to fire | 1 | | | | | | | | 1 |
| FFM | Fails to feed from magazine | 17 | 1 | | | | 5 | | 1 | 3 |
| FFP | Flat firing pin | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|------|-----------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| GCSO | Gas cyl. shot off | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 2 |
| HPA | High pressure ammo | | | | | | | | | |
| HUE | Hard under extractor | 9 | | 1 | | | | 3 | | 2 |
| ILOP | Int. latch out of position | | | | | | | | 1 | |
| ILRM | Int. latch ret. Missing | | 1 | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | |
| JL | Jumps latch | 37 | 43 | | | | | 1 | 1 | |
| JO | Jars off | | | | | | | | | |
| LB | Light blow | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | |
| MCW | Magazine capacity wrong | 2 | | 1 | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | |
| MLH | Magazine loads hard | | | 2 | | | | 1 | | |
| OH | Opens hard | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | |
| PSM | Proof stamp missing | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | |
| RDW | (Action) release doesn't work | 5 | | | | | 2 | | | 1 |
| RIC | Rings in chamber | | | | | | | | | |
| SBC | Stems bottom chambers | 115 | | | | | | 3 | 3 | |
| SBCL | Shell binds carrier latch | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 6 |
| SCX | Shell catches | | | | | | | | | |
| SHI | Short indent | | | | | | | | | |
| SIC | Stems in chamber | | 2 | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|--------|--------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| SL | shaves lead | | | | | | | | | |
| SLC | Stems left side of chamber | 42 | | 1 | | | | | 13 | |
| SMOC | Stretch marks on case | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | 6 | 8 | |
| SRIC | Specific rings in chamber | 2 | | | | | | | | |
| SSC | shell stems carrier | 3 | | | | | | | | |
| STC | Stems top chamber | | 5 | 9 | | | 2 | 3 | 4 | 2 |
| SWE | Safety switch works too easily | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | |
| TD | Tips down | | | | | | | | | |
| TU | Tips up | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | |
| UNCN-T | Uncoded | 4 | 1 | | | | | | | |
| XH | Extracts hard | | | | | | | | | |
| XHB | Extractor hits bbl | | | | | | | | | |
| | | | | | | | | | | |
| HI | High | | | | | | | | | |
| LO | Low | | | | | | | | | |
| LEFT | Left | | | | | | | | | |
| RIGHT | Right | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga |
|--------|-----------------------------------|-------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | |
| FF-P | Fails to fire at proof | | | 1 | | | | | | 1 |
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | | |
| MSI-P | Magnaflux stamp illegible on bbl | | | | | | | | | |
| MSM-P | Magnaflux stamp missing on bbl | | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | | |
| UNCM-P | Uncoded proof malfunctions | | | | | | | | | |

| Month: | | | | | | | | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| total | | | | | | | | | |
| 113 | 1557 | | 1558 | | 778 | | 11960 | 2524 | 8658 |
| 0 | 1 | 0 | 6 | 0 | 0 | 0 | 9 | 1 | 8 |
| 0.0 | 0.1 | | 0.4 | | 0.0 | | 0.075 | 0.040 | 0.092 |
| 113 | 1500 | | 1558 | | 796 | | 11857 | 2471 | 8590 |
| 0 | 3 | 0 | 1 | 0 | 3 | 0 | 552 | 518 | 31 |
| 0.0 | 0.2 | | 0.1 | | 0.4 | | 4.66 | 20.96 | 0.36 |
| | | | | | 404 | 57 | 707 | 246 | 0 |
| 0 | 0 | 0 | 0 | 0 | 31 | 0 | 31 | 0 | 0 |
| | | | | | 7.7 | 0.0 | 4.38 | 0.00 | #DIV/0! |
| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
| | 1 | | 1 | | 1 | | 17 | 9 | 7 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 4 | 1 | 3 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 13 | 11 | 2 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |

| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 36 | 36 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 10 | 10 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 45 | 45 | 0 |
| | | | | | | | 13 | 13 | 0 |
| | | | | | | | 2 | 2 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 11 | 11 | 0 |
| | | | | | | | 6 | 6 | 0 |
| | 1 | | | | | | 2 | 1 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 11 | 11 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 2 | 1 | 1 |
| | | | | | 1 | | 28 | 24 | 3 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |


| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | 0 | 0 | 0 |
| | 1 | | | | | | 3 | 0 | 3 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 15 | 13 | 2 |
| | | | | | | | 1 | 1 | 0 |
| | | | | | | | 1 | 1 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 32 | 82 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 1 | 1 | 0 |
| | | | | | 1 | | 4 | 3 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 3 | 3 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 8 | 7 | 1 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 121 | 121 | 0 |
| | | | | | | | | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 6 | 0 | 6 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 2 | 2 | 0 |

| 870 16Ga | 870 20Ga | 870 light weight | 870 SM | SP10 | 870 Police | O/U | total | Auto Total | Pump Total |
|-------------|----------|---------------------|--------|------|---------------|-----|-------|---------------|---------------|
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 56 | 56 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 14 | 14 | 0 |
| | | | | | | | 2 | 2 | 0 |
| | | | | | | | 3 | 3 | 0 |
| | | | | | | | 25 | 23 | 2 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 5 | 5 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | | | 0 |
| | | | | | 28 | | 28 | 0 | 0 |
| | | | | | 3 | | 3 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |
| | | | | | | | 0 | 0 | 0 |

[illegible]

Gallery Top Faults for Pump Shotguns - Current month through:

8/13/06




through:

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

Gallery Top Faults for Autoloading Shotguns - Current month through:

8/13/06




month

| | | | | |
|-------------------------------|-----|-----|--------|-----|
| L | RDW | MCW | UNCN-T | DLU |
| (Action) release doesn't work | | | | |
| Magazine capacity wrong | | | | |
| Uncoded | | | | |
| Doesn't lock-up | | | | |

Gallery Top Faults for Police Shotguns - Current month through:

8/13/06



through:

| | | | | | | | |
|----|--------------|----|------------|------|------------------------|-----|--------------------|
| CD | Close denied | CH | Close hand | CHAB | Carrie hits action bar | CUM | Cart load magazine |
|----|--------------|----|------------|------|------------------------|-----|--------------------|

| | | |
|--------|-----------------------------------|---|
| FD | Follows-down | 0 |
| FFP | Flat firing pin | 0 |
| FOS | Fires on safe | 0 |
| FSR | Fires when safe is released | 0 |
| GCSO | Gas cyl shot off | 0 |
| HPA | High pressure ammo | 0 |
| ILOP | Int. latch out of position | 0 |
| ILRM | Int. latch ret. Missing | 0 |
| ILSB | Int. latch stud broken | 0 |
| ILSP | Int. latch spring out of position | 0 |
| JL | Jumps latch | 0 |
| JO | Jars off | 0 |
| LB | Light blow | 0 |
| MCSO | Magazine cap shot off | 0 |
| MCW | Magazine capacity wrong | 0 |
| MFA | Misfires (ammo) | 0 |
| MFOP | Magazine follower out of position | 0 |
| MLH | Magazine loads hard | 0 |
| OH | Opens hard | 0 |
| PH | Pulls hard | 0 |
| PSI | Proof stamp illegible | 0 |
| PSM | Proof stamp missing | 0 |
| RBOC | Rings and bulges on case | 0 |
| RIC | Rings in chamber | 0 |
| SBC | Stems bottom chambers | 0 |
| SBCL | Shell binds carrier latch | 0 |
| SBE | Stems bbl extension | 0 |
| SCX | Shell catches | 0 |
| SHI | Short indent | 0 |
| SIC | Stems in chamber | 0 |
| SL | shaves lead | 0 |
| SLC | Stems left side of chamber | 0 |
| SMOC | Stretch marks on case | 0 |
| SRC | Stems right side of chamber | 0 |
| SRIC | Specific rings in chamber | 0 |
| SSC | shell stems carrier | 0 |
| STC | Stems top chamber | 0 |
| SWE | Safety switch works too easily | 0 |
| SWH | Safety switch works too hard | 0 |
| SWW | Safety switch won't work | 0 |
| TD | Tips down | 0 |
| TU | Tips up | 0 |
| TWP | Trigger won't pull | 0 |
| TWR | Trigger won't retract | 0 |
| UNCN-T | Uncoded | 0 |
| XH | Extracts hard | 0 |
| XHB | Extractor hits bbl | 0 |
| | | 0 |
| HI | High | 0 |
| LO | Low | 0 |
| LEFT | Left | 0 |

| | | |
|--------|-----------------------------------|---|
| RIGHT | Right | 0 |
| DG | Doesn't Group | 0 |
| FSST | Front sight tipped | 0 |
| RSTT | Rear sight tipped | 0 |
| RSBR | Rear sight base raised | 0 |
| FSTR | Front sight raised | 0 |
| FSTL | Front sight loose | 0 |
| RSTL | Rear sight loose | 0 |
| MGPT-G | Missing parts at target | 0 |
| UNCN-G | Uncoded nonconformity at target | 0 |
| AI-P | Assembly incomplete at proof | 0 |
| BC-P | Blows cases at proof | 0 |
| BEB-P | Barrel extension broken at proof | 0 |
| BLP-P | Blanked primer at proof | 0 |
| BP-P | Blown primer at proof | 0 |
| BS-P | Barrel split at proof | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P | Ejector sticks back at proof | 0 |
| FCB-P | Fore-end cracked at proof | 0 |
| FESO-P | Fore-end shot off at proof | 0 |
| GCSO-P | Gas cylinder shot off at proof | 0 |
| GRSO-P | Guide ring shot off at proof | 0 |
| MCSO-P | Magazine cap shot off at proof | 0 |
| MSI-P | Magnaflux stamp illegible on bbl | 0 |
| MSM-P | Magnaflux stamp missing on bbl | 0 |
| PP-P | Pierced primer at proof | 0 |
| UNCM-P | Uncoded proof malfunctions | 0 |
| | | |

| | | |
|--------|--|-----|
| SBC | Stems bottom chambers | 101 |
| JL | Jumps latch | 67 |
| SLC | Stems left side of chamber | 56 |
| DFU | Doesn't feed up | 41 |
| DBB | Doesn't blow back | 34 |
| STC | Stems top chamber | 20 |
| FFM | Fails to feed from magazine | 18 |
| SRC | Stems right side of chamber | 14 |
| HUE | Hard under extractor | 13 |
| DLO | Doesn't lock open (after last shell) | 11 |
| DSM | Drops shell-magazine | 11 |
| EDS | Extractor drops shell | 11 |
| DE | Doesn't eject | 10 |
| CC | Carrier catches on shells,mag,receiver | 9 |
| AB | Action binds | 8 |
| DTL | Doesn't trip latch | 6 |
| RDW | (Action) release doesn't work | 6 |
| MCW | Magazine capacity wrong | 3 |
| UNCN-T | Uncoded | 3 |
| DLU | Doesn't lock-up | 2 |
| MLH | Magazine loads hard | 2 |
| SIC | Stems in chamber | 2 |
| SRIC | Specific rings in chamber | 2 |
| BLOP | Bar lock or disconnecter out of position | 1 |
| DX | Doesn't extract | 1 |
| FF | Fails to fire | 1 |
| ILOP | Int. latch out of position | 1 |
| MCSO | Magazine cap shot off | 1 |
| SSC | shell stems carrier | 1 |
| FF-P | Fails to fire at proof | 1 |
| ASFB | Action spring follower binds | 0 |
| BABS | Bulge at body shoulder | 0 |
| BAC | Burr at chamber | 0 |
| BB | Bolt binds/catches | 0 |
| BCOE | Bolt catches on ejector | 0 |
| BC | Blows cases | 0 |
| BSCO | Barrel support came out | 0 |
| CBS-F | Shells catch on bbl support-feeding | 0 |
| CBS-L | Shells catch on bbl support-loading | 0 |
| CD | Case dented | 0 |
| CH | Closes hard | 0 |
| CHAB | Carrier hits action bar | 0 |
| CLM | Can't load magazine | 0 |
| CO | Cut-off | 0 |
| CR | Cuts rim | 0 |
| CS | Cases swell | 0 |
| CTOG | Chamber torn or gouged | 0 |
| CTP | Creepy trigger pull | 0 |
| CWSB | Cams wrong side of action bar | 0 |
| DCS | Double click in safety switch | 0 |
| DCT | Double click in trigger | 0 |

| | | |
|-------|-----------------------------------|---|
| DCU | Doesn't close-up | 0 |
| DEL | Doesn't eject live round | 0 |
| DS | Dead safe | 0 |
| DXL | Doesn't extract live round | 0 |
| ESB | Ejector sticks back | 0 |
| ESS | Extractor stems shell | 0 |
| FA | Fires automatically | 0 |
| FB | Follower binds | 0 |
| FC | Fails to connect | 0 |
| FCB | Fore-end cracked or broken | 0 |
| FD | Follows-down | 0 |
| FFP | Flat firing pin | 0 |
| FOS | Fires on safe | 0 |
| FSR | Fires when safe is released | 0 |
| GCSO | Gas cyl shot off | 0 |
| GRSO | Guide ring shot off | 0 |
| HPA | High pressure ammo | 0 |
| ILRM | Int. latch ret. Missing | 0 |
| ILSB | Int. latch stud broken | 0 |
| ILSP | Int. latch spring out of position | 0 |
| JO | Jars off | 0 |
| LB | Light blow | 0 |
| MFA | Misfires (ammo) | 0 |
| MFOP | Magazine follower out of position | 0 |
| OH | Opens hard | 0 |
| PH | Pulls hard | 0 |
| PSI | Proof stamp illegible | 0 |
| PSM | Proof stamp missing | 0 |
| RBOC | Rings and bulges on case | 0 |
| RIC | Rings in chamber | 0 |
| SBCL | Shell binds carrier latch | 0 |
| SBE | Stems bbl extension | 0 |
| SCB | Stock cracked or broken | 0 |
| SCX | Shell catches | 0 |
| SHI | Short indent | 0 |
| SL | shaves lead | 0 |
| SMOC | Stretch marks on case | 0 |
| SWE | Safety switch works too easily | 0 |
| SWH | Safety switch works too hard | 0 |
| SWW | Safety switch won't work | 0 |
| TD | Tips down | 0 |
| TU | Tips up | 0 |
| TWP | Trigger won't pull | 0 |
| TWR | Trigger won't retract | 0 |
| XH | Extracts hard | 0 |
| XHB | Extractor hits bbl | 0 |
| HI | High | 0 |
| LO | Low | 0 |
| LEFT | Left | 0 |
| RIGHT | Right | 0 |
| DG | Doesn't Group | 0 |

| | | |
|--------|-----------------------------------|---|
| FSST | Front sight tipped | 0 |
| RSTT | Rear sight tipped | 0 |
| RSBR | Rear sight base raised | 0 |
| FSTR | Front sight raised | 0 |
| FSTL | Front sight loose | 0 |
| RSTL | Rear sight loose | 0 |
| MGPT-G | Missing parts at target | 0 |
| UNCN-G | Uncoded nonconformity at target | 0 |
| AI-P | Assembly incomplete at proof | 0 |
| BC-P | Blows cases at proof | 0 |
| BEB-P | Barrel extension broken at proof | 0 |
| BLP-P | Blanked primer at proof | 0 |
| BP-P | Blown primer at proof | 0 |
| BS-P | Barrel split at proof | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P | Ejector sticks back at proof | 0 |
| FCB-P | Fore-end cracked at proof | 0 |
| FESO-P | Fore-end shot off at proof | 0 |
| GCSO-P | Gas cylinder shot off at proof | 0 |
| GRSO-P | Guide ring shot off at proof | 0 |
| MCSO-P | Magazine cap shot off at proof | 0 |
| MSI-P | Magnaflux stamp illegible on bbl | 0 |
| MSM-P | Magnaflux stamp missing on bbl | 0 |
| PP-P | Pierced primer at proof | 0 |
| SCB-P | Stock cracked or broken at proof | 0 |
| UNCM-P | Uncoded proof malfunctions | 0 |
| | | |
| | | |

| | | |
|-------|--|----|
| HI | High | 27 |
| LO | Low | 3 |
| AB | Action binds | 1 |
| FFM | Fails to feed from magazine | 1 |
| MCW | Magazine capacity wrong | 1 |
| ASFB | Action spring follower binds | 0 |
| BABS | Bulge at body shoulder | 0 |
| BAC | Burr at chamber | 0 |
| BB | Bolt binds/catches | 0 |
| BCOE | Bolt catches on ejector | 0 |
| BC | Blows cases | 0 |
| BLOP | Bar lock or disconnect out of position | 0 |
| BSCO | Barrel support came out | 0 |
| CBS-F | Shells catch on bbl support-feeding | 0 |
| CBS-L | Shells catch on bbl support-loading | 0 |
| CC | Carrier catches on shells,mag,receiver | 0 |
| CD | Case dented | 0 |
| CH | Closes hard | 0 |
| CHAB | Carrier hits action bar | 0 |
| CLM | Can't load magazine | 0 |
| CO | Cut-off | 0 |
| CR | Cuts rim | 0 |
| CS | Cases swell | 0 |
| CTOG | Chamber torn or gouged | 0 |
| CTP | Creepy trigger pull | 0 |
| CWSB | Cams wrong side of action bar | 0 |
| DBB | Doesn't blow back | 0 |
| DCS | Double click in safety switch | 0 |
| DCT | Double click in trigger | 0 |
| DCU | Doesn't close-up | 0 |
| DE | Doesn't eject | 0 |
| DEL | Doesn't eject live round | 0 |
| DFU | Doesn't feed up | 0 |
| DLO | Doesn't lock open (after last shell) | 0 |
| DLU | Doesn't lock-up | 0 |
| DS | Dead safe | 0 |
| DSM | Drops shell-magazine | 0 |
| DTL | Doesn't trip latch | 0 |
| DX | Doesn't extract | 0 |
| DXL | Doesn't extract live round | 0 |
| EDS | Extractor drops shell | 0 |
| ESB | Ejector sticks back | 0 |
| ESS | Extractor stems shell | 0 |
| FA | Fires automatically | 0 |
| FB | Follower binds | 0 |
| FC | Fails to connect | 0 |
| FCB | Fore-end cracked or broken | 0 |
| FD | Follows down | 0 |
| FF | Fails to fire | 0 |
| FFP | Flat firing pin | 0 |
| FOS | Fires on safe | 0 |

| | | |
|--------|-----------------------------------|---|
| FSR | Fires when safe is released | 0 |
| GCSO | Gas cyl shot off | 0 |
| GRSO | Guide ring shot off | 0 |
| HPA | High pressure ammo | 0 |
| HUE | Hard under extractor | 0 |
| ILOP | Int. latch out of position | 0 |
| ILRM | Int. latch ret. Missing | 0 |
| ILSB | Int. latch stud broken | 0 |
| ILSP | Int. latch spring out of position | 0 |
| JL | Jumps latch | 0 |
| JO | Jars off | 0 |
| LB | Light blow | 0 |
| MCSO | Magazine cap shot off | 0 |
| MFA | Misfires (ammo) | 0 |
| MFOP | Magazine follower out of position | 0 |
| MLH | Magazine loads hard | 0 |
| OH | Opens hard | 0 |
| PH | Pulls hard | 0 |
| PSI | Proof stamp illegible | 0 |
| PSM | Proof stamp missing | 0 |
| RBOC | Rings and bulges on case | 0 |
| RDW | (Action) release doesn't work | 0 |
| RIC | Rings in chamber | 0 |
| SBC | Stems bottom chambers | 0 |
| SBCL | Shell binds carrier latch | 0 |
| SBE | Stems bbl extension | 0 |
| SCB | Stock cracked or broken | 0 |
| SCX | Shell catches | 0 |
| SHI | Short indent | 0 |
| SIC | Stems in chamber | 0 |
| SL | shaves lead | 0 |
| SLC | Stems left side of chamber | 0 |
| SMOC | Stretch marks on case | 0 |
| SRC | Stems right side of chamber | 0 |
| SRIC | Specific rings in chamber | 0 |
| SSC | shell stems carrier | 0 |
| STC | Stems top chamber | 0 |
| SWE | Safety switch works too easily | 0 |
| SWH | Safety switch works too hard | 0 |
| SWW | Safety switch won't work | 0 |
| TD | Tips down | 0 |
| TU | Tips up | 0 |
| TWP | Trigger won't pull | 0 |
| TWR | Trigger won't retract | 0 |
| UNCN-T | Uncoded | 0 |
| XH | Extracts hard | 0 |
| XHB | Extractor hits bbl | 0 |
| LEFT | Left | 0 |
| RIGHT | Right | 0 |
| DG | Doesn't Group | 0 |
| FSST | Front sight tipped | 0 |

| | | |
|--------|-----------------------------------|---|
| RSTT | Rear sight tipped | 0 |
| RSBR | Rear sight base raised | 0 |
| FSTR | Front sight raised | 0 |
| FSTL | Front sight loose | 0 |
| RSTL | Rear sight loose | 0 |
| MGPT-G | Missing parts at target | 0 |
| UNCN-G | Uncoded nonconformity at target | 0 |
| | | 0 |
| AI-P | Assembly incomplete at proof | 0 |
| BC-P | Blows cases at proof | 0 |
| BEB-P | Barrel extension broken at proof | 0 |
| BLP-P | Blanked primer at proof | 0 |
| BP-P | Blown primer at proof | 0 |
| BS-P | Barrel split at proof | 0 |
| DLOS-P | Doesn't lock over shells at proof | 0 |
| ESB-P | Ejector sticks back at proof | 0 |
| FCB-P | Fore-end cracked at proof | 0 |
| FESO-P | Fore-end shot off at proof | 0 |
| FF-P | Fails to fire at proof | 0 |
| GCSO-P | Gas cylinder shot off at proof | 0 |
| GRSO-P | Guide ring shot off at proof | 0 |
| MCSO-P | Magazine cap shot off at proof | 0 |
| MSI-P | Magnaflux stamp illegible on bbl | 0 |
| MSM-P | Magnaflux stamp missing on bbl | 0 |
| PP-P | Pierced primer at proof | 0 |
| SCB-P | Stock cracked or broken at proof | 0 |
| UNCM-P | Uncoded proof malfunctions | 0 |
| | | 0 |

| | | | | | | | | | | | |
|---------|-----------|-----------------------------|------|-----|-----|---|------|---|------|-----|-----|
| Summary | | Total Test + Proof Failures | 1077 | | | | | | | | |
| | | Total Rejected: | 102 | | | | | | | | |
| | | Overall Reject Rate: | 9.47 | | | | | | | | |
| Proof | Shot: | 48 | 14 | 20 | 11 | | 24 | | 39 | 364 | 113 |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | 0.0 | | 0.0 | | 0.0 | 0.0 | 0.0 |
| Test | Shot: | 128 | 20 | | | | 56 | | 27 | 364 | 113 |
| | Rejected: | 57 | 0 | 0 | 0 | 0 | 10 | 0 | 12 | 4 | 0 |
| | Percent: | 44.5 | 0.0 | | | | 17.9 | | 44.4 | 1.1 | 0.0 |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 1 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|------|--------------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| CHAB | Carrier hits action bar | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | |
| DBB | Doesn't blow back | 1 | | | | | 1 | | | | |
| DCS | Double click in safety switch | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | |
| DE | Doesn't eject | 2 | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | 4 | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | |
| DSM | Drops shell-magazine | 5 | | | | | | | | | |
| DTL | Doesn't trip latch | 1 | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 5 | | |
| ESB | Ejector sticks back | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|------|-----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| FA | Fires automatically | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | |
| FC | Fails to connect | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | |
| FFM | Fails to feed from magazine | 6 | | | | | 5 | | | | |
| FFP | Flat firing pin | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | |
| HUE | Hard under extractor | 8 | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | |
| JL | Jumps latch | 5 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|------|--------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| MLH | Magazine loads hard | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | |
| PSM | Proof stamp missing | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | |
| RDW | (Action) release doesn't work | 1 | | | | | 2 | | | | |
| RIC | Rings in chamber | | | | | | | | | | |
| SBC | Stems bottom chambers | 20 | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 2 | |
| SCX | Shell catches | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | |
| SLC | Stems left side of chamber | 2 | | | | | | | 5 | | |
| SMOC | Stretch marks on case | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | 2 | | |
| SRIC | Specific rings in chamber | | | | | | | | | | |
| SSC | shell stems carrier | 1 | | | | | | | | | |
| STC | Stems top chamber | | | | | | 2 | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|--------|----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| TD | Tips down | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | |
| XHB | Extractor hits bbl | | | | | | | | | | |
| | | | | | | | | | | | |
| HI | High | | | | | | | | | | |
| LO | Low | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | |
| | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|--------|-----------------------------------|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| BLP-P | Blanked primer at proof | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | |
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | | | |
| MSI-P | Magnaflux stamp illegible on bbl | | | | | | | | | | |
| MSM-P | Magnaflux stamp missing on bbl | | | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | | | |
| UNCM-P | Uncoded proof malfunctions | | | | | | | | | | |

| Test Date: | | | | |
|------------|-----|-----|--|--|
| 18 | 304 | 94 | | |
| 0 | 0 | 0 | | |
| 0.0 | 0.0 | 0.0 | | |
| 18 | 304 | 47 | | |
| 0 | 0 | 0 | | |
| 0.0 | 0.0 | 0.0 | | |
| 0 | 0 | 87 | | |
| 0 | 0 | 19 | | |
| | | 218 | | |

| | | | | |
|-----|---|-----|---|------|
| 18 | | 304 | | 94 |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 |
| 18 | | 304 | | 47 |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 |
| | | | | 87 |
| 0 | 0 | 0 | 0 | 19 |
| | | | | 21.8 |

[illegible]

[illegible]

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1059 |
| | Total Rejected: | 7 |
| | Overall Reject Rate: | 0.66 |

| | | | | | | | | | | | |
|---------------|-----------|-----|------|---|-----|---|---|---|-----|-----|---|
| Proof | Shot: | 25 | 66 | | 10 | | | | 31 | 814 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | | 0.0 | | | | 0.0 | 0.0 | |
| Test | Shot: | 4 | 43 | | 10 | | | | | 814 | |
| | Rejected: | 0 | 6 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| | Percent: | 0.0 | 14.0 | | 0.0 | | | | | 0.1 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | 1 | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|---|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | 5 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|---|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | 1 | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1016 |
| | Total Rejected: | 37 |
| | Overall Reject Rate: | 3.64 |

| | | | | | | | | | | | |
|---------------|-----------|-----|------|---|-----|---|---|-----|------|-----|---|
| Proof | Shot: | 14 | 36 | | 3 | | | 13 | 24 | 619 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| | Percent: | 0.0 | 0.0 | | 0.0 | | | 0.0 | 0.0 | 0.2 | |
| Test | Shot: | 14 | 12 | | 14 | | | 16 | 50 | 619 | |
| | Rejected: | 1 | 2 | 0 | 0 | 0 | 0 | 0 | 17 | 3 | 0 |
| | Percent: | 7.1 | 16.7 | | 0.0 | | | 0.0 | 34.0 | 0.5 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|---|--|--|--|--|--|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | 2 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | 1 | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | 1 | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | 1 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|---|--|--|--|--|--|---|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | 1 | | |
| FFM | Fails to feed from magazine | | | | | | | | 1 | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | 1 | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | 1 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|---|--|--|--|--|--|--|---|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | 1 | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 1 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | 3 | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | 6 | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | 2 | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|---|--|
| XHB | Extractor hits bbl | | | | | | | | | | | |
| HI | High | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | |
| | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | 1 | |

| Test Date: | | | | |
|------------|-----|-----|-----|-----|
| 0 | 0 | 193 | 98 | 0 |
| | 0 | 0.0 | 0 | 0 |
| | | 0.0 | 0.0 | 0 |
| 0 | 0 | 193 | 97 | 0 |
| | 1 | 0 | 1 | 0 |
| | 0.5 | | 1.0 | |
| 0 | 0 | 0 | 112 | 0 |
| | 0 | 0 | 11 | 9.8 |

| | | | | | | |
|---|---|-----|-----|-----|-----|---|
| | | | 193 | | 98 | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | | | 0.0 | | 0.0 | |
| | | | 193 | | 97 | |
| 0 | 0 | 1 | 0 | 1 | 0 | |
| | | 0.5 | | 1.0 | | |
| | | | | | | |
| | | | | | | |
| 0 | 0 | 0 | 0 | 11 | 0 | |
| | | | | 98 | | |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1011 |
| | Total Rejected: | 17 |
| | Overall Reject Rate: | 1.68 |

| | | | | | | | | | | | |
|---------------|-----------|-----|-----|-----|-----|---|-----|-----|------|-----|---|
| Proof | Shot: | 10 | 7 | 166 | 3 | | | 88 | 14 | 575 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | 0.0 | | | 0.0 | 0.0 | 0.0 | |
| Test | Shot: | | | 116 | | | 11 | 87 | 15 | 575 | |
| | Rejected: | 0 | 0 | 4 | 0 | 0 | 0 | 0 | 6 | 1 | 0 |
| | Percent: | | | 3.4 | | | 0.0 | 0.0 | 40.0 | 0.2 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | 1 | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | 1 | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | 1 | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|---|--|--|--|--|---|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | 2 | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | 2 | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | 2 | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

[illegible]

[illegible]

[illegible]

ILE00088743

| | | |
|----------------|-----------------------------|---|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1307 |
| | Total Rejected: | 19 |
| | Overall Reject Rate: | 1.45 |

| | | | | | | | | | | | |
|---------------|-----------|-----|-----|-----|-----|---|---|-----|-----|-----|---|
| Proof | Shot: | 13 | 38 | 189 | | | | 132 | 8 | 665 | |
| | Rejected: | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.5 | | | | 0.0 | 0.0 | 0.0 | |
| Test | Shot: | | | 283 | | | | 128 | | 665 | |
| | Rejected: | 0 | 4 | 4 | 0 | 0 | 0 | 5 | 0 | 5 | 0 |
| | Percent: | | | 1.4 | | | | 3.9 | | 0.8 | |
| Target | Shot: | | | | 10 | | | 226 | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | | 0 | 0 | 0 | 0 |
| | Percent: | | | | 0.0 | | | 0.0 | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | 1 | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 1 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|---|--|--|--|---|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | 1 | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | 1 | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | 1 | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | 1 | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|---|--|--|--|---|---|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | 1 | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | 1 | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | 1 | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | 1 | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | 1 | | | | 1 | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|---|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | 2 | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | 2 | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|---|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | 1 | | | | | | | | |

| Test Date: | | | | |
|------------|-----|-----|--|----|
| 122 | 56 | 52 | | |
| 0 | 0 | 0 | | 0 |
| 0.0 | 0.0 | 0.0 | | |
| 122 | 56 | 52 | | |
| 0 | 0 | 0 | | 0 |
| 0.0 | 0.0 | 0.0 | | |
| 122 | 56 | 52 | | |
| 0 | 0 | 0 | | 0 |
| 0.0 | 0.0 | 0.0 | | |
| 0 | 0 | 0 | | 57 |
| 0 | 0 | 0 | | 0 |

| | | | | |
|-----|-----|-----|-----|----|
| | 122 | 56 | 52 | |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | 0.0 | 0 |
| | | | | |
| 122 | 56 | 52 | | |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | 0.0 | 0 |
| | | | | |
| | | | | 57 |
| 0 | 0 | 0 | 0 | 0 |

ILE00088779

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1390 |
| | Total Rejected: | 113 |
| | Overall Reject Rate: | 8.13 |

| | | | | | | | | | | | |
|---------------|-----------|------|------|---|---|---|---|---|---|-----|---|
| Proof | Shot: | 211 | | | | | | | | 517 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | | | | | | | | 0.0 | |
| Test | Shot: | 293 | 40 | | | | | | | 517 | |
| | Rejected: | 93 | 17 | 0 | 0 | 0 | 0 | 0 | 0 | 3 | 0 |
| | Percent: | 31.7 | 42.5 | | | | | | | 0.6 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 4 | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | 1 | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | 1 | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|----|---|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | 15 | 1 | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | 3 | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | 14 | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | 1 | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | 1 | | | | | | | | | | |
| DX | Doesn't extract | 1 | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|----|----|--|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | 1 | | | | | | | | | | |
| FFM | Fails to feed from magazine | | 1 | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | 1 | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 10 | 15 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | 1 | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | 2 | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 22 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 13 | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | 2 | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | 2 | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | |
|--------|----------------------------------|
| GCSO-P | Gas cylinder shot off at proof |
| GRSO-P | Guide ring shot off at proof |
| MCSO-P | Magazine cap shot off at proof |
| MSI-P | Magnaflex stamp illegible or bbl |
| MSM-P | Magniflux stamp missing or bbl |
| PP-P | Pierced primer at proof |
| SCB-P | Stock cracked or broken at proof |
| UNCM-P | Uncoded proof malfunctions |

| Test Date: | | | |
|------------|-----|-----|-----|
| 63 | 437 | 89 | |
| 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | 0 |
| 63 | 437 | 40 | |
| 0 | 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 | 0.0 |
| 0 | 0 | 0 | 0 |

| | | |
|-----|-----|-----|
| 63 | 437 | 89 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 63 | 437 | 40 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 0 | 0 | 0 |

ILE00088791

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | | | | |
|----------------|-----------|------------------------------------|-----|-------------|-----|
| Summary | | Total Test + Proof Failures | | 1259 | |
| | | Total Rejected: | | 75 | |
| | | Overall Reject Rate: | | 5.96 | |
| Proof | Shot: | 131 | 82 | 26 | 353 |
| | Rejected: | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | 0.0 |
| Test | Shot: | 159 | 98 | 353 | |
| | Rejected: | 69 | 0 | 3 | 0 |
| | Percent: | 43.4 | 0.0 | 0.8 | |
| Target | Shot: | | 10 | | |
| | Rejected: | 0 | 0 | 0 | 0 |
| | Percent: | | 0.0 | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 4 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|----|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | 2 | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | 15 | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | 5 | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 2 | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|--|--|--|--|--|--|--|---|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 2 | | | | | | | | 1 | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | 1 | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 2 | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | 1 | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|--|--|--|--|--|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 25 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | 1 | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 10 | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

| Test Date: | | | | |
|------------|---|---|-----|---|
| 531 | | | 93 | |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | | 0.0 | |
| 531 | | | 118 | |
| 1 | 0 | 0 | 2 | 0 |
| 0.2 | | | 1.7 | |
| 0 | 0 | 0 | 0 | 0 |

| Test Date: | | | | |
|------------|---|---|-----|---|
| 531 | | | 93 | |
| 0 | 0 | 0 | 0 | 0 |
| 0.0 | | | 0.0 | |
| 531 | | | 118 | |
| 1 | 0 | 0 | 2 | 0 |
| 0.2 | | | 1.7 | |
| 0 | 0 | 0 | 0 | 0 |

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | | | | | | | | | | |
|---------|-----------|-----------------------------|-----|------|---|---|---|------|------|-----|---|
| Summary | | Total Test + Proof Failures | | 1261 | | | | | | | |
| | | Total Rejected: | | 86 | | | | | | | |
| | | Overall Reject Rate: | | 6.82 | | | | | | | |
| Proof | Shot: | 45 | 30 | 29 | | | | 113 | | 559 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | | | | 0.0 | | 0.0 | |
| Test | Shot: | 96 | | 26 | | | | 115 | 34 | 559 | |
| | Rejected: | 54 | 0 | 3 | 0 | 0 | 0 | 14 | 15 | 0 | 0 |
| | Percent: | 56.3 | | 11.5 | | | | 12.2 | 44.1 | 0.0 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | 1 | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 3 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|----|--|--|--|--|--|---|---|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | 2 | | | | | | | 7 | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | 1 | | | | | | 1 | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | 10 | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 1 | | | | | | | | | | |
| DTL | Doesn't trip latch | 1 | | | | | | | 1 | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | 1 | 1 | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|----|--|--|--|--|---|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 2 | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | 3 | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 10 | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | 1 | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|---|--|--|--|---|---|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | 1 | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 15 | | | | | | 3 | 1 | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 6 | | 1 | | | | 3 | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | 6 | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | 2 | | | | | 2 | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

| Test Date: | | | | | |
|------------|---|-----|---|-----|---|
| 271 | | 2 | | 93 | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 | |
| 271 | | 2 | | 158 | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0.0 | | 0.0 | | 0.0 | |
| 0 | 0 | 0 | 0 | 17 | |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | 0.0 | |

| | | |
|-----|-----|-----|
| 271 | 2 | 93 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 271 | 2 | 158 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 0 | 0 | 17 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | | | | | | | | | | |
|---------|-----------|-----------------------------|------|------|---|---|---|-----|---|-----|---|
| Summary | | Total Test + Proof Failures | | 1165 | | | | | | | |
| | | Total Rejected: | | 61 | | | | | | | |
| | | Overall Reject Rate: | | 5.24 | | | | | | | |
| Proof | Shot: | 161 | 75 | 26 | | | | 12 | | 401 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | 0.0 | | | | 0.0 | | 0.0 | |
| Test | Shot: | 121 | 22 | 27 | | | | 10 | | 390 | |
| | Rejected: | 38 | 15 | 6 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| | Percent: | 31.4 | 68.2 | 22.2 | | | | 0.0 | | 0.3 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|---|---|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | 1 | | 1 | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | 1 | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | 1 | | | | | | | | | | |
| DLU | Doesn't lock-up | 1 | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | 2 | | | | | | | | | | |
| DTL | Doesn't trip latch | | 1 | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | 1 | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|----|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 1 | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 6 | 11 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|---|---|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 12 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | 11 | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | 3 | 5 | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

| Test Date: | | | | | | | | | |
|------------|---|-----|---|-----|-----|--|--|--|--|
| 335 | | 198 | | 54 | | | | | |
| 1 | 0 | 0 | 0 | 0 | 0 | | | | |
| 0.3 | | 0.0 | | 0.0 | | | | | |
| 335 | | 198 | | 61 | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | | | | |
| 0.0 | | 0.0 | | 0.0 | | | | | |
| | | | | | | | | | |
| 0 | 0 | 0 | 0 | 25 | 0 | | | | |
| | | | | 0.0 | 0.0 | | | | |

| | | |
|-----|-----|-----|
| 335 | 198 | 54 |
| 1 | 0 | 0 |
| 0.3 | 0.0 | 0.0 |
| 335 | 198 | 54 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |
| 0 | 0 | 0 |
| 0.0 | 0.0 | 0.0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 159 |
| | Total Rejected: | 3 |
| | Overall Reject Rate: | 1.89 |

| | | | | | | | | | | |
|---------------|-----------|-----|-----|---|---|---|---|---|-----|---|
| Proof | Shot: | 12 | 83 | | | | | | 68 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | 0.0 | | | | | | 0.0 | |
| Test | Shot: | | | | | | | | 68 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| | Percent: | | | | | | | | 1.5 | |
| Target | Shot: | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | 1 | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date: _____

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 85 |
| | Total Rejected: | 4 |
| | Overall Reject Rate: | 4.71 |

| | | | | | | | | | | | |
|---------------|-----------|---|---|-----|---|---|---|---|---|---|---|
| Proof | Shot: | | | 132 | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | 0.0 | | | | | | | |
| Test | Shot: | | | 85 | | | | | | | |
| | Rejected: | 0 | 0 | 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | 4.7 | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | 1 | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|---|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | 1 | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | 1 | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

The diagram consists of four horizontal rows of rectangular blocks. The top row has 4 blocks, the second row has 5 blocks, the third row has 6 blocks, and the bottom row has 7 blocks. The blocks are arranged in a staggered pattern, with each row shifted to the right relative to the one above it. The blocks are labeled with '0' and '1' in a specific pattern.

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|-------------|
| Summary | Total Test + Proof Failures | 1077 |
| | Total Rejected: | 68 |
| | Overall Reject Rate: | 6.31 |

| | | | | | | | | | | | |
|---------------|-----------|------|------|------|-----|---|---|-----|-----|-----|---|
| Proof | Shot: | 112 | | 70 | | | | 107 | 21 | 495 | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | 0.0 | | 0.0 | | | | 0.0 | 0.0 | 0.0 | |
| Test | Shot: | 134 | 21 | 23 | 3 | | | 130 | | 495 | |
| | Rejected: | 41 | 13 | 3 | 0 | 0 | 0 | 5 | 0 | 5 | 0 |
| | Percent: | 30.6 | 61.9 | 13.0 | 0.0 | | | 3.8 | | 1.0 | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | 1 | | | | | | 1 | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | 1 | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | 1 | 1 | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|---|--|---|--|--|--|---|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | 1 | | 1 | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | 4 | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | 2 | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|---|----|---|--|--|--|--|---|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | 6 | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | 1 | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | 1 | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | 4 | 11 | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | 1 | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|----|--|--|--|--|--|---|--|---|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | 1 | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | 20 | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | 2 | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | 3 | | 2 | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | 2 | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | | | | | | | | | |
|--------|----------------------------------|--|--|--|--|--|--|--|--|
| GCSO-P | Gas cylinder shot off at proof | | | | | | | | |
| GRSO-P | Guide ring shot off at proof | | | | | | | | |
| MCSO-P | Magazine cap shot off at proof | | | | | | | | |
| MSI-P | Magnaflex stamp illegible or bbl | | | | | | | | |
| MSM-P | Magnaflex stamp missing or bbl | | | | | | | | |
| PP-P | Pierced primer at proof | | | | | | | | |
| SCB-P | Stock cracked or broken at proof | | | | | | | | |
| UNCM-P | Uncoded proof malfunctions | | | | | | | | |

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible]

ILE00088923

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

Test Date:

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

| <i>Test Date:</i> | | | | | |
|--------------------------|---|---|---|---|---|
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|-----------------------------|-----------|---|
| Total Test + Proof Failures | | 0 |
| Total Rejected: | | 0 |
| Overall Reject Rate: | | |
| Proof | Shot: | |
| | Rejected: | 0 |
| | Percent: | |
| Test | Shot: | |
| | Rejected: | 0 |
| | Percent: | |
| Target | Shot: | |
| | Rejected: | 0 |
| | Percent: | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

| | | | | | |
|------------|---|---|---|---|---|
| Test Date: | | | | | |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | | | | | |
|-------------------|---|---|---|---|---|
| Test Date: | | | | | |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 |

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

Test Date:

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

[illegible]

ILE00089043

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

| | | | | | | | | | | | |
|---------------|-----------|---|---|---|---|---|---|---|---|---|---|
| Proof | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Test | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |
| Target | Shot: | | | | | | | | | | |
| | Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| | Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

| | | | | | | | | | | |
|--------|--|----------------------------------|--|--|--|--|--|--|--|--|
| GCSO-P | | Gas cylinder shot off at proof | | | | | | | | |
| GRSO-P | | Guide ring shot off at proof | | | | | | | | |
| MCSO-P | | Magazine cap shot off at proof | | | | | | | | |
| MSI-P | | Magnaflex stamp illegible or bbl | | | | | | | | |
| MSM-P | | Magnaflex stamp missing or bbl | | | | | | | | |
| PP-P | | Pierced primer at proof | | | | | | | | |
| SCB-P | | Stock cracked or broken at proof | | | | | | | | |
| UNCM-P | | Uncoded proof malfunctions | | | | | | | | |

[illegible][illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

| | | |
|----------------|------------------------------------|----------|
| Summary | Total Test + Proof Failures | 0 |
| | Total Rejected: | 0 |
| | Overall Reject Rate: | |

Proof

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Test

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

Target

| | | | | | | | | | | |
|-----------|---|---|---|---|---|---|---|---|---|---|
| Shot: | | | | | | | | | | |
| Rejected: | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Percent: | | | | | | | | | | |

| CODE | MALFUNCTION INDEX | 1187 Super Mag | 1187 12Ga | 1187 20Ga | 1100 12Ga | 1100 16Ga | 1100 20Ga | 1100 28Ga | 1100 410Ga | 870 12Ga | 870 16Ga |
|-------|--|----------------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|-------------|-------------|
| | | | | | | | | | | | |
| AB | Action binds | | | | | | | | | | |
| ASFB | Action spring follower binds | | | | | | | | | | |
| BABS | Bulge at body shoulder | | | | | | | | | | |
| BAC | Burr at chamber | | | | | | | | | | |
| BB | Bolt binds/catches | | | | | | | | | | |
| BCOE | Bolt catches on ejector | | | | | | | | | | |
| BC | Blows cases | | | | | | | | | | |
| BLOP | Bar lock or disconnecter out of position | | | | | | | | | | |
| BSCO | Barrel support came out | | | | | | | | | | |
| CBS-F | Shells catch on bbl support-feeding | | | | | | | | | | |
| CBS-L | Shells catch on bbl support-loading | | | | | | | | | | |
| CC | Carrier catches on shells,mag,receiver | | | | | | | | | | |
| CD | Case dented | | | | | | | | | | |
| CH | Closes hard | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|--------------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| CHAB | Carrier hits action bar | | | | | | | | | | | |
| CLM | Can't load magazine | | | | | | | | | | | |
| CO | Cut-off | | | | | | | | | | | |
| CR | Cuts rim | | | | | | | | | | | |
| CS | Cases swell | | | | | | | | | | | |
| CTOG | Chamber torn or gouged | | | | | | | | | | | |
| CTP | Creepy trigger pull | | | | | | | | | | | |
| CWSB | Cams wrong side of action bar | | | | | | | | | | | |
| DBB | Doesn't blow back | | | | | | | | | | | |
| DCS | Double click in safety switch | | | | | | | | | | | |
| DCT | Double click in trigger | | | | | | | | | | | |
| DCU | Doesn't close-up | | | | | | | | | | | |
| DE | Doesn't eject | | | | | | | | | | | |
| DEL | Doesn't eject live round | | | | | | | | | | | |
| DFU | Doesn't feed up | | | | | | | | | | | |
| DLO | Doesn't lock open (after last shell) | | | | | | | | | | | |
| DLU | Doesn't lock-up | | | | | | | | | | | |
| DS | Dead safe | | | | | | | | | | | |
| DSM | Drops shell-magazine | | | | | | | | | | | |
| DTL | Doesn't trip latch | | | | | | | | | | | |
| DX | Doesn't extract | | | | | | | | | | | |
| DXL | Doesn't extract live round | | | | | | | | | | | |
| EDS | Extractor drops shell | | | | | | | | | | | |
| ESB | Ejector sticks back | | | | | | | | | | | |
| ESS | Extractor stems shell | | | | | | | | | | | |
| FA | Fires automatically | | | | | | | | | | | |
| FB | Follower binds | | | | | | | | | | | |

| | | | | | | | | | | | | |
|------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| FC | Fails to connect | | | | | | | | | | | |
| FCB | Fore-end cracked or broken | | | | | | | | | | | |
| FD | Follows-down | | | | | | | | | | | |
| FF | Fails to fire | | | | | | | | | | | |
| FFM | Fails to feed from magazine | | | | | | | | | | | |
| FFP | Flat firing pin | | | | | | | | | | | |
| FOS | Fires on safe | | | | | | | | | | | |
| FSR | Fires when safe is released | | | | | | | | | | | |
| GCSO | Gas cyl shot off | | | | | | | | | | | |
| GRSO | Guide ring shot off | | | | | | | | | | | |
| HPA | High pressure ammo | | | | | | | | | | | |
| HUE | Hard under extractor | | | | | | | | | | | |
| ILOP | Int. latch out of position | | | | | | | | | | | |
| ILRM | Int. latch ret. Missing | | | | | | | | | | | |
| ILSB | Int. latch stud broken | | | | | | | | | | | |
| ILSP | Int. latch spring out of position | | | | | | | | | | | |
| JL | Jumps latch | | | | | | | | | | | |
| JO | Jars off | | | | | | | | | | | |
| LB | Light blow | | | | | | | | | | | |
| MCSO | Magazine cap shot off | | | | | | | | | | | |
| MCW | Magazine capacity wrong | | | | | | | | | | | |
| MFA | Misfires (ammo) | | | | | | | | | | | |
| MFOP | Magazine follower out of position | | | | | | | | | | | |
| MLH | Magazine loads hard | | | | | | | | | | | |
| OH | Opens hard | | | | | | | | | | | |
| PH | Pulls hard | | | | | | | | | | | |
| PSI | Proof stamp illegible | | | | | | | | | | | |

| | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|--|--|--|--|--|--|--|--|
| PSM | Proof stamp missing | | | | | | | | | | | |
| RBOC | Rings and bulges on case | | | | | | | | | | | |
| RDW | (Action) release doesn't work | | | | | | | | | | | |
| RIC | Rings in chamber | | | | | | | | | | | |
| SBC | Stems bottom chambers | | | | | | | | | | | |
| SBCL | Shell binds carrier latch | | | | | | | | | | | |
| SBE | Stems bbl extension | | | | | | | | | | | |
| SCB | Stock cracked or broken | | | | | | | | | | | |
| SCX | Shell catches | | | | | | | | | | | |
| SHI | Short indent | | | | | | | | | | | |
| SIC | Stems in chamber | | | | | | | | | | | |
| SL | shaves lead | | | | | | | | | | | |
| SLC | Stems left side of chamber | | | | | | | | | | | |
| SMOC | Stretch marks on case | | | | | | | | | | | |
| SRC | Stems right side of chamber | | | | | | | | | | | |
| SRIC | Specific rings in chamber | | | | | | | | | | | |
| SSC | shell stems carrier | | | | | | | | | | | |
| STC | Stems top chamber | | | | | | | | | | | |
| SWE | Safety switch works too easily | | | | | | | | | | | |
| SWH | Safety switch works too hard | | | | | | | | | | | |
| SWW | Safety ewitxh won't work | | | | | | | | | | | |
| TD | Tips down | | | | | | | | | | | |
| TU | Tips up | | | | | | | | | | | |
| TWP | Trigger won't pull | | | | | | | | | | | |
| TWR | Trigger won't retract | | | | | | | | | | | |
| UNCN-T | Uncoded | | | | | | | | | | | |
| XH | Extracts hard | | | | | | | | | | | |

| | | | | | | | | | | | | | |
|--------|-----------------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| XHB | Extractor hits bbl | | | | | | | | | | | | |
| HI | High | | | | | | | | | | | | |
| LO | Low | | | | | | | | | | | | |
| LEFT | Left | | | | | | | | | | | | |
| RIGHT | Right | | | | | | | | | | | | |
| DG | Doesn't Group | | | | | | | | | | | | |
| FSST | Front sight tipped | | | | | | | | | | | | |
| RSTT | Rear sight tipped | | | | | | | | | | | | |
| RSBR | Rear sight base raised | | | | | | | | | | | | |
| FSTR | Front sight raised | | | | | | | | | | | | |
| FSTL | Front sight loose | | | | | | | | | | | | |
| RSTL | Rear sight loose | | | | | | | | | | | | |
| MGPT-G | Missing parts at target | | | | | | | | | | | | |
| UNCN-G | Uncoded nonconformity at target | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| AI-P | Assembly incomplete at proof | | | | | | | | | | | | |
| BC-P | Blows cases at proof | | | | | | | | | | | | |
| BEB-P | Barrel extension broken at proof | | | | | | | | | | | | |
| BLP-P | Blanked primer at proof | | | | | | | | | | | | |
| BP-P | Blown primer at proof | | | | | | | | | | | | |
| BS-P | Barrel split at proof | | | | | | | | | | | | |
| DLOS-P | Doesn't lock over shells at proof | | | | | | | | | | | | |
| ESB-P | Ejector sticks back at proof | | | | | | | | | | | | |
| FCB-P | Fore-end cracked at proof | | | | | | | | | | | | |
| FESO-P | Fore-end shot off at proof | | | | | | | | | | | | |
| FF-P | Fails to fire at proof | | | | | | | | | | | | |

[illegible]

Test Date:

The diagram consists of four horizontal rows of rectangular blocks. The top row contains 10 blocks, the second row contains 9 blocks, the third row contains 8 blocks, and the bottom row contains 7 blocks. The blocks are arranged in a staggered pattern, with each row shifted to the right relative to the one above it. The blocks are labeled with '0' and '1' in a specific pattern.

[illegible]

| | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |