Summary	-	Total Tested	563 19								
		Total Rejected: all Reject Rate:	19 3.37								totals
	0.074	Shot:	286	95	87	96				1	564
	Proof	Rejected:	0	0	1	0	0	0	0	0	1
		Percent:	0.0	0.0	1.1	0.0					0.2
	_ ,	Shot: [Rejected:	286 12	95 3	87 0	95 3	0	0	0	0	563 18
	Test	Rejected. Percent:	4.2	3.2	0.0	3.2	U	U	U	O	3.2
		Shot:	27	9	4	10				1	50
	Target	Rejected:	0	0	0	0	0	0	0	0	0
	_	Percent:	0.0	0.0	0.0	0.0					0.0
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches		2								2
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	h									
BLOP	Bar lock or disconnector of	out of position									
BLSO	Barrel lug shot off										
ВРО	Bolt pulls out										
BSSM	Bolt stems shell in magaz	tine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full r	magazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine										
co	Cut-off										
CR	Cuts rim										
CS	Cases swell										

стос	Chamber torn or gouged						
СТР	Creepy trigger pull						
CWSB	Cams wrong side of action bar						
DBB	Doesn't blow back						
DCS	Double click in safety switch						
DCT	Double click in trigger						
DCU	Doesn't close-up						
DE	Doesn't eject						
DEL	Doesn't eject live round						
DFB	Doesn't feed back						
DFU	Doesn't feed up						
DLO	Doesn't lock open (after last shell)						
DLU	Doesn't lock-up						
DS	Dead safe						
DX	Doesn't extract	3		2			5
DXL	Doesn't extract live round						
EDS	Extractor drops shell	3					3
ESB	Ejector sticks back						
ESCR	Empty shell catches receiver						
ESS	Extractor stems shell						
FA	Fires automatically						
FB	Follower binds						
FC	Fails to connect						
FCB	Fore-end cracked or broken						
FD	Follows-down						
FF	Fails to fire						
FFP	Flat firing pin						
FOS	Fires on safe						
FPHB	Firing pin hits bbl						
FPHI	Firing pin hits inside rim						
FPO	Floor plate opens		2				2
FPOH	Floor plate opens hard						
FSR	Fires when safe is released						
FT	Follower tips						
GCSO	Gas cyl shot off						

HBL	Heavy bolt lift						
HMSC	Heading mismatch-steps on case						
НРА	High pressure ammo						
HUR	Hard under rail	1					1
JCS	Jumps cartridge						
JM	Jumps magazine						
JO	Jars off						
LB	Light blow						
MAH	Magazine assembles hard						
MCW	Magazine capacity wrong						
MFA	Misfires (ammo)						
MFOP	Magazine follower out of position						
ML	Magazine loose						
MLH	Magazine loads hard						
MRH	Magazine removes hard						
ОН	Opens hard	2					2
OR	Over-rides		1				1
PH	Pulls hard						
PSI	Proof stamp illegible						
PSM	Proof stamp missing						
RBOC	Rings and bulges on case						
RDW	(Action) release doesn't work						
RIC	Rings in chamber						
RIS	Ring in sholder						
RS	Rim srem						
SBC	Stems bottom chambers	1					1
SBE	Stems bbl extension						
SCB	Stock cracked or broken						
SCX	Shell catches						
SHI	Short indent						
SI	Stems incline						
SIC	Stems in chamber						
SL	shaves lead						
SLC	Stems left side of chamber						
SMOC	Stretch marks on case						

SOR	Stem over-ride		1			1
SP			<u> </u>			.}
	Stems port					
SR	Shoulder rough					
SRC	Stems right side of chamber					
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
swн	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
XH	Extracts hard					
ні	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target					
AI-P	Assembly incompleye at proof					
BBB	Barrel bracket cracked or broken at proof					
ВС-Р	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

BLP-P	Blanked primer at proof					
BLSO-P	Barrel lug shot off at proof					
BP-P	Blown primer at proof					
BS-P	Barrel split at proof					
DBF-P	Damaged Bolt Face		1			1
DLOS-P	Doesn't lock over shells at proof					
ESBBP-P	Ejector sticks back -Blown Primer cup					
ESBEC-P	Ejector sticks back - Ejector Cresent					
FCB-P	Fore-end cracked at proof					
FESO-P	Fore-end shot off at proof					
FF-P	Fails to fire at proof					
GCSO-P	Gas cylinder shot off at proof					
MSI-P	Magnaflux stamp illegible on bbl					
MSM-P	Magnaflux stamp missing on bbl					
PP-P	Pierced primer at proof					
SCB-P	Stock cracked or broken at proof					
UNCM-P	Uncoded proof malfunctions					

Summary	-	Total Tested	879 36								
		Total Rejected: all Reject Rate:	36 4.10								totals
	Overe	Shot:	131	79	347	145	45	2		1	749
	Proof	Rejected:	0	0	5	0	0	0	0	0	5
		Percent:	0.0	0.0	1.4	0.0	0.0	0.0			0.7
		Shot:	167	103	338	160	76	2		33	879
	Test	Rejected: Percent:	5 3.0	2 1.9	14 4.1	3 1.9	<i>4</i> 5.3	0 0.0	0	3 9.1	31 3.5
		Shot:	15	10	34	13	7	1	T	V. 7	79
	Target	Rejected:	0	0	0	0	0	0	0	0	0
	, u, g = 1	Percent:	0.0	0.0	0.0	0.0	0.0				0.0
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds									1	1
BABS	Bulge at body shoulder										_
BAC	Burr at chamber										
BBMA	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches		1		3						4
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	h									
BLOP	Bar lock or disconnector	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magaz	ine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full r	magazine									
CD	Case dented										
СН	Closes hard		2		2						å,
CLM	Can't load magazine				1	1					2
co	Cut-off										
CR	Cuts rim										
CS	Cases swell										

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
CTOG	Chamber torn or gouged									
CTP	Creepy trigger pull									
CWSB	Cams wrong side of action bar									
DBB	Doesn't blow back									
DCS	Double click in safety switch									
DCT	Double click in trigger									
DCU	Doesn't close-up									
DE	Doesn't eject									
DEL	Doesn't eject live round									
DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up								1	1
DS	Dead safe									
DX	Doesn't extract	1	2		1					Ą
DXL	Doesn't extract live round									
EDS	Extractor drops shell			4						å,
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect								1	4
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens			2		4				6
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
FT	Follower tips									
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift	1								1
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail			1						1
JCS	Jumps cartridge									
JM	Jumps magazine									
JO	Jars off									
LB	Light blow									
MAH	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard			1	1					2
OR	Over-rides									
PH	Pulls hard									
PSI	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									
RDW	(Action) release doesn't work									
RIC	Rings in chamber									
RIS	Ring in sholder									
RS	Rim srem									
SBC	Stems bottom chambers									
SBE	Stems bbl extension									
SCB	Stock cracked or broken									
scx	Shell catches									
SHI	Short indent									
SI	Stems incline									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard									
ні	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
ввв	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face									
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof									
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions			5						5

Summary		Total Tested Total Rejected:	468 21								
	Over	all Reject Rate:	4.49								totals
		Shot:	259	23	100		18	28	41		469
	Proof	Rejected: ⁻ Percent:	1 0.4	0 0.0	0 0.0	0	0 0.0	0 0.0	0 0.0	0	1 0.2
		Shot:	258	23	74		18	28	67		468
	Test	Rejected:	12	5	0	0	0	1	2	0	20
		Percent:	4.7	21.7	0.0		0.0	3.6	3.0		4.3
		Shot:	24		3		2	27	7		63
	Target	Rejected: Percent:	0 0.0	0	0 0.0	0	0 0.0	0 0.0	0 0.0	0	0 0.0
CODE	MALFUNCTIO	N INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignmen	t									
ВВ	Bolt binds/catches	•	3					1			4
ВСОАВ	Bolt catches on anti-bind		•								,
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
ВС	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	ch									
BLOP	Bar lock or disconnector										
BLSO	Barrel lug shot off										
ВРО	Bolt pulls out										
BSSM	Bolt stems shell in maga	zine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full	magazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine										
co	Cut-off										
CR	Cuts rim										
cs	Cases swell										
	1 - 4000 0 0 !!								l		l

	Tax in the second second			1		
CTOG	Chamber torn or gouged					
СТР	Creepy trigger pull					
CWSB	Cams wrong side of action bar					
DBB	Doesn't blow back					
DCS	Double click in safety switch					
DCT	Double click in trigger					
DCU	Doesn't close-up					
DE	Doesn't eject					
DEL	Doesn't eject live round					
DFB	Doesn't feed back					
DFU	Doesn't feed up					
DLO	Doesn't lock open (after last shell)					
DLU	Doesn't lock-up					
DS	Dead safe					
DX	Doesn't extract	5			1	8
DXL	Doesn't extract live round					
EDS	Extractor drops shell					
ESB	Ejector sticks back					
ESCR	Empty shell catches receiver					
ESS	Extractor stems shell					
FA	Fires automatically					
FB	Follower binds					
FC	Fails to connect					
FCB	Fore-end cracked or broken					
FD	Follows-down					
FF	Fails to fire					
FFP	Flat firing pin					
FOS	Fires on safe					
FPHB	Firing pin hits bbl					
FPHI	Firing pin hits inside rim					
FPO	Floor plate opens					
FPOH	Floor plate opens hard					
FSR	Fires when safe is released					
FT	Follower tips					
GCSO	Gas cyl shot off					

HBL	Heavy bolt lift	2				2
нмѕс	Heading mismatch-steps on case					
НРА	High pressure ammo					
HUR	Hard under rail					
JCS	Jumps cartridge					
JM	Jumps magazine					
10	Jars off					
LB	Light blow					
МАН	Magazine assembles hard					
MCW	Magazine capacity wrong					
MFA	Misfires (ammo)					
MFOP	Magazine follower out of position					
ML	Magazine loose					
MLH	Magazine loads hard					
MRH	Magazine removes hard					
ОН	Opens hard					
OR	Over-rides					
PH	Pulls hard					
PSI	Proof stamp illegible					
PSM	Proof stamp missing					
RBOC	Rings and bulges on case					
RDW	(Action) release doesn't work					
RIC	Rings in chamber					
RIS	Ring in sholder					
RS	Rim srem					
SBC	Stems bottom chambers					
SBE	Stems bbl extension					
SCB	Stock cracked or broken					
scx	Shell catches					
SHI	Short indent					
SI	Stems incline					
SIC	Stems in chamber				1	1
SL	shaves lead					
SLC	Stems left side of chamber					
SMOC	Stretch marks on case					

SOR	Stom over ride	4		I	I		4
SP	Stem over-ride	4					e¢.
	Stems port						
SR	Shoulder rough						
SRC	Stems right side of chamber		-				
SRIC	Specific rings in chamber						
ssoc	Surface scratches on case						
STC	Stems top chamber	3					3
SWE	Safety switch works too easily						
swH	Safety switch works too hard						
sww	Safety Switch won't work						
TD	Tips down						
TU	Tips up						
TWP	Trigger won't pull						
TWR	Trigger won't retract						
UNCN-T	Uncoded						
XH	Extracts hard						
HI	High						
LO	Low						
LEFT	Left						
RIGHT	Right						
DG	Doesn't Group						
FSST	Front sight tipped						
RSTT	Rear sight tipped						
RSBR	Rear sight base raised						
FSTR	Front sight raised						
FSTL	Front sight loose						
RSTL	Rear sight loose						
MGPT-G	Missing parts at target						
UNCN-G	Uncoded nonconformity at target						
AI-P	Assembly incompleye at proof						
BBB	Barrel bracket cracked or broken at proof						
ВС-Р	Blows cases at proof						
BEB-P	Barrel extension broken at proof						

BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DBF-P	Damaged Bolt Face	1						1
DLOS-P	Doesn't lock over shells at proof							
ESBBP-P	Ejector sticks back -Blown Primer cup							
ESBEC-P	Ejector sticks back - Ejector Cresent							
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof							
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions		_	_		_		
	•							

Summary		Total Tested Total Rejected: all Reject Rate:	527 26 4.93								totals
		Shot:	249	78	33	52		104			516
	Proof	Rejected:	0	1	0	0	0	5	0	0	ő
		Percent:	0.0	1.3	0.0	0.0	T	4.8	T		1.2
	Test	Shot: L Rejected:	246 1	104 9	46 0	32 10	0	99 0	0	0	527 20
	rest	Percent:	0.4	8.7	0.0	31.3	ŭ	0.0	Ū	Ü	3.8
		Shot:	21	11	3	3		99			137
	Target	Rejected:	0	0	0	0	0	0	0	0	0
	_	Percent:	0.0	0.0	0.0	0.0		0.0	•	,	0.0
CODE	MALFUNCTIO	N INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment	t									
ВВ	Bolt binds/catches			5							5
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
вс	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	ch .									
BLOP	Bar lock or disconnector	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in maga:	zine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full	magazine									
CD	Case dented										
СН	Closes hard			1							*}
СГМ	Can't load magazine			2		2					å,
со	Cut-off										
CR	Cuts rim										
cs	Cases swell										

0.700	Tay is a second		I		1	l	
CTOG	Chamber torn or gouged						
СТР	Creepy trigger pull						
CWSB	Cams wrong side of action bar						
DBB	Doesn't blow back						
DCS	Double click in safety switch						
DCT	Double click in trigger						
DCU	Doesn't close-up						
DE	Doesn't eject						
DEL	Doesn't eject live round						
DFB	Doesn't feed back						
DFU	Doesn't feed up						
DLO	Doesn't lock open (after last shell)						
DLU	Doesn't lock-up						
DS	Dead safe		1				ń
DX	Doesn't extract						
DXL	Doesn't extract live round						
EDS	Extractor drops shell	1					*
ESB	Ejector sticks back						
ESCR	Empty shell catches receiver						
ESS	Extractor stems shell						
FA	Fires automatically						
FB	Follower binds						
FC	Fails to connect						
FCB	Fore-end cracked or broken						
FD	Follows-down						
FF	Fails to fire						
FFP	Flat firing pin						
FOS	Fires on safe						
FPHB	Firing pin hits bbl						
FPHI	Firing pin hits inside rim						
FPO	Floor plate opens						
FPOH	Floor plate opens hard						
FSR	Fires when safe is released						
FT	Follower tips						
GCSO	Gas cyl shot off						

				ı		
HBL	Heavy bolt lift					
нмѕс	Heading mismatch-steps on case					
НРА	High pressure ammo					
HUR	Hard under rail					
JCS	Jumps cartridge					
JM	Jumps magazine					
JO	Jars off					
LB	Light blow					
MAH	Magazine assembles hard					
MCW	Magazine capacity wrong					
MFA	Misfires (ammo)					
MFOP	Magazine follower out of position					
ML	Magazine loose					
MLH	Magazine loads hard					
MRH	Magazine removes hard					
ОН	Opens hard					
OR	Over-rides					
PH	Pulls hard					
PSI	Proof stamp illegible					
PSM	Proof stamp missing					
RBOC	Rings and bulges on case					
RDW	(Action) release doesn't work					
RIC	Rings in chamber					
RIS	Ring in sholder					
RS	Rim srem					
SBC	Stems bottom chambers					
SBE	Stems bbl extension					
SCB	Stock cracked or broken					
scx	Shell catches					
SHI	Short indent					
SI	Stems incline					
SIC	Stems in chamber					
SL	shaves lead					
SLC	Stems left side of chamber					
SMOC	Stretch marks on case					

		ı			1	
SOR	Stem over-ride		8			8
SP	Stems port					
SR	Shoulder rough					
SRC	Stems right side of chamber					
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
SWH	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
ХН	Extracts hard					
н	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target					
AI-P	Assembly incompleye at proof					
ВВВ	Barrel bracket cracked or broken at proof					
ВС-Р	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

BLP-P	Blanked primer at proof						
BLSO-P	Barrel lug shot off at proof						
BP-P	Blown primer at proof						
BS-P	Barrel split at proof						
DBF-P	Damaged Bolt Face	1			5		6
DLOS-P	Doesn't lock over shells at proof						
ESBBP-P	Ejector sticks back -Blown Primer cup						
ESBEC-P	Ejector sticks back - Ejector Cresent						
FCB-P	Fore-end cracked at proof						
FESO-P	Fore-end shot off at proof						
FF-P	Fails to fire at proof						
GCSO-P	Gas cylinder shot off at proof						
MSI-P	Magnaflux stamp illegible on bbl						
MSM-P	Magnaflux stamp missing on bbl						
PP-P	Pierced primer at proof						
SCB-P	Stock cracked or broken at proof						
UNCM-P	Uncoded proof malfunctions			_			

Summary	Т	Total Tested otal Rejected:	587 19								
		II Reject Rate:	3.24								totals
		Shot: [391	43	169	88	64				755
	Proof	Rejected:	0	0	1	5 5.7	0	0	0	0	ð
		Percent: Shot: [0.0 288	0.0 24	0.6 169	5.7 71	0.0	_	Г	1	0.8 587
	Test	Snot: [Rejected:	288	<u>24</u> 5	4	2	0	0	<u> </u>	0	13
	7031	Percent:	0.7	20.8	2.4	2.8	0.0				2.2
		Shot:		2	15	5	4				26
	Target	Rejected: Percent:	0	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0 0.0
CODE	MALFUNCTION		700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
				3	ADL						
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber		1								1
ВВМА	BBL-to-bolt misalignment										
вв	Bolt binds/catches			2	2	1					5
BCOAB	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
ВС	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	ı									
BLOP	Bar lock or disconnector o	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magazi	ine									
BWCD	Bolt won't cam down		1								1
BWCFM	Bolt won't close over full m	nagazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine										
co	Cut-off										
CR	Cuts rim										
cs	Cases swell										

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
стос	Chamber torn or gouged									
СТР	Creepy trigger pull									
CWSB	Cams wrong side of action bar									
DBB	Doesn't blow back									
DCS	Double click in safety switch									
DCT	Double click in trigger									
DCU	Doesn't close-up									
DE	Doesn't eject									
DEL	Doesn't eject live round									
DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract		2							2
DXL	Doesn't extract live round									
EDS	Extractor drops shell			1						1
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens									
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
FT	Follower tips									
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift									
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine									
JO	Jars off									
LB	Light blow									
MAH	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard		1	1						2
OR	Over-rides				1					ż
PH	Pulls hard									
PSI	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									
RDW	(Action) release doesn't work									
RIC	Rings in chamber									
RIS	Ring in sholder									
RS	Rim srem									
SBC	Stems bottom chambers									
SBE	Stems bbl extension									
SCB	Stock cracked or broken									
SCX	Shell catches									
SHI	Short indent									
SI	Stems incline									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard									
ні	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
ввв	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face			1						1
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl							_		
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof							_		
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions				5					5

Summary		Total Tested	691								
		tal Rejected:	21								# - # - C -
	Overaii	Reject Rate:	3.04						<u> </u>	•	totals
	Proof	Shot: [Rejected:	335 1	248 0	124 1	0	0	19 0	0	0	726 2
	71001	Percent:	0.3	0.0	0.8	v	Ü	0.0	Ü	Ü	0.3
		Shot:	333	216	123			19			691
	Test	Rejected: ¯ Percent:	5 1.5	11 5.1	3 2. <i>4</i>	0	0	0 0.0	0	0	16 2.3
		Shot:	1.3	5. <i>1</i>	14		T	19	Γ	I	58
	Target	Rejected:	0	0	0	0	0	0	0	0	0
	rarget	Percent:	0.0	0.0	0.0			0.0			0.0
CODE	MALFUNCTION I	NDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches		1								1
ВСОАВ	Bolt catches on anti-bind			1	2						
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch										
BLOP	Bar lock or disconnector ou	t of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magazin	е									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full ma	agazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine			2							2
co	Cut-off										
CR	Cuts rim										
cs	Cases swell										

0.700	Tour i		I		1	l	
CTOG	Chamber torn or gouged						
СТР	Creepy trigger pull						
CWSB	Cams wrong side of action bar						
DBB	Doesn't blow back						
DCS	Double click in safety switch						
DCT	Double click in trigger						
DCU	Doesn't close-up						
DE	Doesn't eject						
DEL	Doesn't eject live round						
DFB	Doesn't feed back						
DFU	Doesn't feed up						
DLO	Doesn't lock open (after last shell)						
DLU	Doesn't lock-up						
DS	Dead safe						
DX	Doesn't extract		1				4
DXL	Doesn't extract live round						
EDS	Extractor drops shell	4					4
ESB	Ejector sticks back						
ESCR	Empty shell catches receiver						
ESS	Extractor stems shell						
FA	Fires automatically						
FB	Follower binds						
FC	Fails to connect						
FCB	Fore-end cracked or broken						
FD	Follows-down						
FF	Fails to fire						
FFP	Flat firing pin						
FOS	Fires on safe						
FPHB	Firing pin hits bbl						
FPHI	Firing pin hits inside rim						
FPO	Floor plate opens						
FPOH	Floor plate opens hard						
FSR	Fires when safe is released						
FT	Follower tips						
GCSO	Gas cyl shot off						

HBL	Heavy bolt lift					
нмѕс	Heading mismatch-steps on case					
НРА	High pressure ammo					
HUR	Hard under rail					
JCS	Jumps cartridge					
JM	Jumps magazine					
JO	Jars off					
LB	Light blow					
MAH	Magazine assembles hard					
MCW	Magazine capacity wrong					
MFA	Misfires (ammo)					
MFOP	Magazine follower out of position					
ML	Magazine loose					
MLH	Magazine loads hard					
MRH	Magazine removes hard	3				3
ОН	Opens hard		1			1
OR	Over-rides	4				4
PH	Pulls hard					
PSI	Proof stamp illegible					
PSM	Proof stamp missing					
RBOC	Rings and bulges on case					
RDW	(Action) release doesn't work					
RIC	Rings in chamber					
RIS	Ring in sholder					
RS	Rim srem					
SBC	Stems bottom chambers					
SBE	Stems bbl extension					
SCB	Stock cracked or broken					
SCX	Shell catches					
SHI	Short indent					
SI	Stems incline					
SIC	Stems in chamber					
SL	shaves lead					
SLC	Stems left side of chamber					
SMOC	Stretch marks on case					

SOR	Stem over-ride					
SP	Stems port					
SR	Shoulder rough					
SRC	Stems right side of chamber					
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
SWH	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
хн	Extracts hard					
н	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target					
AI-P	Assembly incompleye at proof					
ВВВ	Barrel bracket cracked or broken at proof					
BC-P	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

		1				
BLP-P	Blanked primer at proof					
BLSO-P	Barrel lug shot off at proof					
BP-P	Blown primer at proof					
BS-P	Barrel split at proof					
DBF-P	Damaged Bolt Face		1			1
DLOS-P	Doesn't lock over shells at proof					
ESBBP-P	Ejector sticks back -Blown Primer cup					
ESBEC-P	Ejector sticks back - Ejector Cresent					
FCB-P	Fore-end cracked at proof					
FESO-P	Fore-end shot off at proof					
FF-P	Fails to fire at proof					
GCSO-P	Gas cylinder shot off at proof					
MSI-P	Magnaflux stamp illegible on bbl					
MSM-P	Magnaflux stamp missing on bbl					
PP-P	Pierced primer at proof					
SCB-P	Stock cracked or broken at proof					
UNCM-P	Uncoded proof malfunctions	1				1

Summary		Total Tested	432								
		Total Rejected: all Reject Rate:	9 2.08								totals
	Overa	Shot:	205	I 40	18	E0	15	1 1	06	T	
	Proof	Snot: [Rejected:	205 	49 1	0	50 0	15 0	0	96 <i>0</i>	0	434 1
	11001	Percent:	0.0	2.0	0.0	0.0	0.0	0.0	0.0	-	0.2
		Shot:	205	48	18	50	15	1	95		432
	Test	Rejected:	6 2.9	1 2.1	0 0.0	0 0.0	0 0.0	0 0.0	1 1.1	0	8 1.9
		Percent: Shot: [2.9	1	2	5	0.0 1	0.0 T 1	9	1	39
	Target	Rejected:	0	0	0	0	0	0	0	0	0
	rarget	Percent:	0.0	0.0	0.0	0.0	0.0	0.0	0.0		0.0
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber		1								3
ВВМА	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches										
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	h									
BLOP	Bar lock or disconnector of	out of position									
BLSO	Barrel lug shot off										
ВРО	Bolt pulls out								1		1
BSSM	Bolt stems shell in magaz	rine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full r	magazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine										
СО	Cut-off										
CR	Cuts rim										
CS	Cases swell										

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
стос	Chamber torn or gouged									
СТР	Creepy trigger pull									
CWSB	Cams wrong side of action bar									
DBB	Doesn't blow back									
DCS	Double click in safety switch									
DCT	Double click in trigger									
DCU	Doesn't close-up									
DE	Doesn't eject									
DEL	Doesn't eject live round									
DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract	1	1							2
DXL	Doesn't extract live round									
EDS	Extractor drops shell									
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens									
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
FT	Follower tips									
gcso	Gas cyl shot off									
HBL	Heavy bolt lift									
нмѕс	Heading mismatch-steps on case									
НРА	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine									
lo	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
МБОР	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard									
OR	Over-rides	4								4
PH	Pulls hard									
PSI	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									
RDW	(Action) release doesn't work									
RIC	Rings in chamber									
RIS	Ring in sholder									
RS	Rim srem									
SBC	Stems bottom chambers									
SBE	Stems bbl extension									
SCB	Stock cracked or broken									
scx	Shell catches									
SHI	Short indent									
SI	Stems incline									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard									
ні	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
ввв	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face		1							1
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof									
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

Summary		Total Tested Total Rejected: all Reject Rate:	646 20 3.10								totals
		Shot: [247	5	260	14	96	46			668
	Proof	Rejected:	0	0	0	0	0	0	0	0	0
		Percent:	0.0	0.0	0.0	0.0	0.0	0.0		1	0.0
	Test	Shot: [Rejected:	269 1	5 0	260 14	14 1	96 4	0	0	0	646 20
	rest	Percent:	0.4	0.0	5.4	7.1	4.2	0.0	Ū	· ·	3.1
		Shot:	63		22		9	2			96
	Target	Rejected:	0	0	0	0	0	0	0	0	0
		Percent:	0.0	700 000	0.0		0.0	0.0			0.0
CODE	MALFUNCTION	NINDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment	:									
BB	Bolt binds/catches		1		4		1				8
BCOAB	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switc	h									
BLOP	Bar lock or disconnector	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magaz	zine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full	magazine									
CD	Case dented										
СН	Closes hard										
CLM	Can't load magazine				1		2				3
co	Cut-off										
CR	Cuts rim										
cs	Cases swell										

стоб	Chamber torn or gouged					
СТР	Creepy trigger pull					
CWSB	Cams wrong side of action bar					
DBB	Doesn't blow back					
DCS	Double click in safety switch					
DCT	Double click in trigger					
DCU	Doesn't close-up					
DE	Doesn't eject		5			5
DEL	Doesn't eject live round					
DFB	Doesn't feed back					
DFU	Doesn't feed up					
DLO	Doesn't lock open (after last shell)					
DLU	Doesn't lock-up					
DS	Dead safe					
DX	Doesn't extract			1		1
DXL	Doesn't extract live round					
EDS	Extractor drops shell		1			1
ESB	Ejector sticks back					
ESCR	Empty shell catches receiver					
ESS	Extractor stems shell					
FA	Fires automatically					
FB	Follower binds					
FC	Fails to connect					
FCB	Fore-end cracked or broken					
FD	Follows-down					
FF	Fails to fire					
FFP	Flat firing pin					
FOS	Fires on safe					
FPHB	Firing pin hits bbl					
FPHI	Firing pin hits inside rim					
FPO	Floor plate opens					
FPOH	Floor plate opens hard					
FSR	Fires when safe is released					
FT	Follower tips					
GCSO	Gas cyl shot off					

HBL	Heavy bolt lift						
HMSC	Heading mismatch-steps on case						
НРА	High pressure ammo						
HUR	Hard under rail						
JCS	Jumps cartridge						
JM	Jumps magazine		1				1
JO	Jars off						
LB	Light blow						
MAH	Magazine assembles hard						
MCW	Magazine capacity wrong						
MFA	Misfires (ammo)						
MFOP	Magazine follower out of position						
ML	Magazine loose						
MLH	Magazine loads hard						
MRH	Magazine removes hard						
ОН	Opens hard						
OR	Over-rides			1			1
PH	Pulls hard						
PSI	Proof stamp illegible						
PSM	Proof stamp missing						
RBOC	Rings and bulges on case						
RDW	(Action) release doesn't work						
RIC	Rings in chamber						
RIS	Ring in sholder						
RS	Rim srem						
SBC	Stems bottom chambers						
SBE	Stems bbl extension						
SCB	Stock cracked or broken						
SCX	Shell catches						
SHI	Short indent						
SI	Stems incline		2				2
sic	Stems in chamber						
SL	shaves lead						
SLC	Stems left side of chamber						
SMOC	Stretch marks on case						

SOR	Stem over-ride					
SP	Stems port					
SR	Shoulder rough					
SRC	Stems right side of chamber					
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
SWH	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
ХН	Extracts hard					
н	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target					
AI-P	Assembly incompleye at proof					
ВВВ	Barrel bracket cracked or broken at proof					
BC-P	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

DI D D	Diaminal mains and a second					
BLP-P	Blanked primer at proof					
BLSO-P	Barrel lug shot off at proof					
BP-P	Blown primer at proof					
BS-P	Barrel split at proof					
DBF-P	Damaged Bolt Face					
DLOS-P	Doesn't lock over shells at proof					
ESBBP-P	Ejector sticks back -Blown Primer cup					
ESBEC-P	Ejector sticks back - Ejector Cresent					
FCB-P	Fore-end cracked at proof					
FESO-P	Fore-end shot off at proof					
FF-P	Fails to fire at proof					
GCSO-P	Gas cylinder shot off at proof					
MSI-P	Magnaflux stamp illegible on bbl					
MSM-P	Magnaflux stamp missing on bbl					
PP-P	Pierced primer at proof					
SCB-P	Stock cracked or broken at proof					
UNCM-P	Uncoded proof malfunctions					

Summary	_	Total Tested	582								
		otal Rejected: Il Reject Rate:	39 6.70								totals
	Overa	Shot:	244	70	195	157	12	1		T	682
	Proof	Snot: [Rejected:	4	4	0	0	0	0	0	0	982 8
	, , , , , ,	Percent:	1.6	5.7	0.0	0.0	0.0		0.0		1.2
		Shot:	214	60	185	107	12		4		582
	Test	Rejected: ⁻ Percent:	15 7.0	0 0.0	12 6.5	<i>4</i> 3.7	0 0.0	0	0 0.0	0	31 5.3
		Shot: [23	5 5	18	10	2	1	0.0		58
	Target	Rejected:	0	0	0	0	0	0	0	0	0
	, a, got	Percent:	0.0	0.0	0.0	0.0	0.0				0.0
CODE	MALFUNCTION	INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	Rimfire	totals
AB	Action binds										
BABS	Bulge at body shoulder										
BAC	Burr at chamber										
ВВМА	BBL-to-bolt misalignment										
ВВ	Bolt binds/catches		2		3						5
ВСОАВ	Bolt catches on anti-bind										
BCOBS	Bolt catches on bolt stop										
BCOF	Bolt catches on follower										
BC	Blows cases										
BHR	Bolt hits receiver										
BHS	Bolt plug hits safety switch	ı									
BLOP	Bar lock or disconnector of	out of position									
BLSO	Barrel lug shot off										
вро	Bolt pulls out										
BSSM	Bolt stems shell in magaz	ine									
BWCD	Bolt won't cam down										
BWCFM	Bolt won't close over full n	nagazine									
CD	Case dented										
СН	Closes hard		7								7
CLM	Can't load magazine										
co	Cut-off										
CR	Cuts rim										
cs	Cases swell										

стоб	Chamber torn or gouged						
СТР	Creepy trigger pull						
CWSB	Cams wrong side of action bar						
DBB	Doesn't blow back						
DCS	Double click in safety switch						
DCT	Double click in trigger						
DCU	Doesn't close-up						
DE	Doesn't eject						
DEL	Doesn't eject live round						
DFB	Doesn't feed back						
DFU	Doesn't feed up						
DLO	Doesn't lock open (after last shell)						
DLU	Doesn't lock-up						
DS	Dead safe						
DX	Doesn't extract	2	1	1			đ,
DXL	Doesn't extract live round						
EDS	Extractor drops shell		3	1			4
ESB	Ejector sticks back	1					1
ESCR	Empty shell catches receiver						
ESS	Extractor stems shell						
FA	Fires automatically						
FB	Follower binds						
FC	Fails to connect						
FCB	Fore-end cracked or broken						
FD	Follows-down						
FF	Fails to fire						
FFP	Flat firing pin						
FOS	Fires on safe						
FPHB	Firing pin hits bbl						
FPHI	Firing pin hits inside rim						
FPO	Floor plate opens	1					1
FPOH	Floor plate opens hard						
FSR	Fires when safe is released						
FT	Follower tips						
GCSO	Gas cyl shot off						

HBL	Heavy bolt lift						
HMSC	Heading mismatch-steps on case						
HPA	High pressure ammo						
HUR	Hard under rail						
JCS	Jumps cartridge						
JM	Jumps magazine						
JO	Jars off						
LB	Light blow						
MAH	Magazine assembles hard						
MCW	Magazine capacity wrong						
MFA	Misfires (ammo)						
MFOP	Magazine follower out of position						
ML	Magazine loose						
MLH	Magazine loads hard						
MRH	Magazine removes hard						
ОН	Opens hard	2	1				3
OR	Over-rides						
PH	Pulls hard						
PSI	Proof stamp illegible						
PSM	Proof stamp missing						
RBOC	Rings and bulges on case						
RDW	(Action) release doesn't work						
RIC	Rings in chamber						
RIS	Ring in sholder						
RS	Rim srem						
SBC	Stems bottom chambers		3	2			5
SBE	Stems bbl extension						
SCB	Stock cracked or broken						
scx	Shell catches						
SHI	Short indent						
SI	Stems incline						
sic	Stems in chamber						
SL	shaves lead						
SLC	Stems left side of chamber						
SMOC	Stretch marks on case						

SOR	Stem over-ride					
SP	Stems port					
SR	Shoulder rough					
SRC	Stems right side of chamber					
SRIC	Specific rings in chamber					
ssoc	Surface scratches on case					
STC	Stems top chamber					
SWE	Safety switch works too easily					
SWH	Safety switch works too hard					
sww	Safety Switch won't work					
TD	Tips down					
TU	Tips up					
TWP	Trigger won't pull					
TWR	Trigger won't retract					
UNCN-T	Uncoded					
хн	Extracts hard		1			1
н	High					
LO	Low					
LEFT	Left					
RIGHT	Right					
DG	Doesn't Group					
FSST	Front sight tipped					
RSTT	Rear sight tipped					
RSBR	Rear sight base raised					
FSTR	Front sight raised					
FSTL	Front sight loose					
RSTL	Rear sight loose					
MGPT-G	Missing parts at target					
UNCN-G	Uncoded nonconformity at target					
AI-P	Assembly incompleye at proof					
ВВВ	Barrel bracket cracked or broken at proof					
ВС-Р	Blows cases at proof					
BEB-P	Barrel extension broken at proof					

		1					
BLP-P	Blanked primer at proof						
BLSO-P	Barrel lug shot off at proof						
BP-P	Blown primer at proof						
BS-P	Barrel split at proof						
DBF-P	Damaged Bolt Face	3					3
DLOS-P	Doesn't lock over shells at proof						
ESBBP-P	Ejector sticks back -Blown Primer cup						
ESBEC-P	Ejector sticks back - Ejector Cresent						
FCB-P	Fore-end cracked at proof						
FESO-P	Fore-end shot off at proof						
FF-P	Fails to fire at proof						
GCSO-P	Gas cylinder shot off at proof						
MSI-P	Magnaflux stamp illegible on bbl						
MSM-P	Magnaflux stamp missing on bbl						
PP-P	Pierced primer at proof						
SCB-P	Stock cracked or broken at proof						
UNCM-P	Uncoded proof malfunctions	1	4				5