Summary		Proof Failures Total Rejected:	642 88								Test Date:	
		all Reject Rate:	13.71									
		Shot:	3	135	43	19	203	115	8			
	Proof	Rejected:	1	7	4	0	8	0	0	0	0	0
		Percent:	33.3	5.2	9.3	0.0	3.9	0.0	0.0			
		Shot:	176	103			165	169	9			
	Test	Rejected:	25	8	0	0	7	21	0	0	0	0
		Percent:	14.2	7.8			4.2	12.4	0.0			
		Shot:	69		18		72	12				
	Target	Rejected:	0	6	1	0	0	0	0	0	0	0
	· ··· 3 · ·	Percent:	0.0		5.6		0.0	0.0				
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
4.5												
AB	Action binds											
ASFB	Action spring follower bind	ls										
BABS	Bulge at body shoulder						- 1					
BAC BBMA	Burr at chamber BBL-to-bolt misalignment						1					
BBINIA	Bolt binds/catches						2					
BCOBS	Bolt catches on bolt stop						2					
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch	1										
BLOP	Bar lock or disconnector o											
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazi	ine										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full n											
CBS-F	Shells catch on bbl suppo											
CBS-L	Shells catch on bbl suppo											
cc	Carrier catches on shells,	mag,receiver										
CD	Case dented											
СН	Closes hard		1	2			1					
CHAB	Carrier hits action bar											
CLM	Can't laod magazine											
CO	Cut-off											
CR	Cuts rim											
CS CTOG	Cases swell Chamber torn or gouged											
CTP												
CWSB	Creepy trigger pull Cams wrong side of action	a har										
DBB	Doesn't blow back							2				

DCT Double click intrigger Image: state interpretation of the state int	DCS	Double click in safety switch								
DCU Desirt close up Image: marked bit is and the set of the form of the set of the	DCT	Double click in trigger								
DE Doesn'elective round Image: section of the section		Doesn't close-up								
DEL Deerrie let live nund Image: live nund DFB Doesn't led back Image: live nund Image: live nund <td></td> <td></td> <td></td> <td></td> <td> </td> <td></td> <td></td> <td></td> <td></td> <td></td>					 					
DFB Deers field back Image: state in the state in th	DEI	Doesn't eject live round								
DFU Deem'tedu y Image: Second table specific trans shell) Image: Second table specific trans shell Image: Second table specific trans s	DEB									
DLO Doesn't lock open (after last shell) Image: constraint of the shell of the										
DLU Desention-up 3 6 6 DS Dead safe					 					
DSM Drops shell-magazine Image: Construction of the second secon							3			
DSM Drops shell-magazine Image: constraint of the constraint of										
DTL Doesn't kritaci Image: state transmitter of the state transm										
DX Desart strated Image: Constraint of the provide of		Doesn't trip latch								
DXL Desent extract live round Image: constraint live roun							16			
EDS Extractor drops shell 5										
ESB Ejector stoks back 1				5						
ESCR Empty shell aches receiver Image: shell in the	ESB									
ESS Extractor stems shell Image: standard strain and	ESCR		1	· · · · · · · · · · · · · · · · · · ·				1		l1
FA Fires automatically Image: constant of the second seco	ESS									
FB Follower binds Image: Constant of the second state of the second s	FA									
FC Fails to connect Image: connect of proceed or acked or broken Image: connect of connect										
FCB Fore-end cracked or broken Image: Constraint of the constra	FC									
FD Follows-down Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target is released Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target is released Image: Constraint of the state is released Image: Constraint of the state is released Image: Constraint of the state is released FTA Follows-target is released Image: Constraint of the state is released Image: Constarget is released Image: Constarget is release	FCB									
FFFails to freeImage in the second sec										
FFM Fails fored from magazine Image in the second	FF									
FFPFlat fining pinImage: state of the state of th	FFM	Fails to feed from magazine								
FOSFires on safeImage: constraint of the state of	FFP	Flat firing pin								
FPHBFiring pin hits bilImage: state st	FOS									
FPHI Firing pin hits inside rim Image: constraint of the opens hard Image: constraint opens hard Ima	FPHB									
FPO Flor plate opens Image: constraint of the set of	FPHI	Firing pin hits inside rim								
FPOHFloor plate opens hardImage: seleasedImage: seleasedImage: seleasedImage: seleasedFXFires when safe is released1Image: seleasedImage: seleasedImage: seleasedImage: seleasedFTFollower tips1Image: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedGCSOGas cyl shot offImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedGRSOGuide ring shot offImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedHBLHeavy bolt lift3Image: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedHMSCHeading mismatch-steps on caseImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedHVAHigh pressure ammoImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedHUEHard under extractorImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedHURHard under ratiImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedILOPInt. latch sub orkenImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedImage: seleasedILSPInt. latch sub orken <td></td>										
FSRFires when safe is released1212GCSOGas cyl shot off1211GRSOGas cyl shot off11211HBLHeavy bolt lift31111HBLHeavy bolt lift31111HPAHigh pressure anmo11111HUEHard under extractor11111HURHard under rail11111ILOPInt. latch out of position11111ILSBInt. latch stud broken11111ILSPInt. latch stud broken11111JL<	FPOH	Floor plate opens hard								
GCSOGas cyl shot offImage: shot off	FSR	Fires when safe is released								
GCSOGas cyl shot offImage: shot off	FT	Follower tips	1			2				
GRSOGuide ring shot offImage: shot off<	GCSO	Gas cyl shot off								
HMSCHeading mismatch-steps on caseImage: mean problemImage: mean proble	GRSO	Guide ring shot off								
HPAHigh pressure ammoImage: solution of the structorImage: solution of the structor	HBL	Heavy bolt lift	3							
HPAHigh pressure ammoImage: solution of the structorImage: solution of the structor	HMSC	Heading mismatch-steps on case								
HUEHard under extractorImage: starting st	HPA	High pressure ammo								
HURHard under railImage: state of the state of th	HUE	Hard under extractor								
ILOPInt. latch out of positionInt. latch ret. MissingInt. latch ret. MissingInt. latch ret. MissingInt. latch ret. MissingInt. latch stud brokenInt. latch stud brokenInt. latch stud brokenInt. latch spring out of positionInt. latch spring out of position<	HUR	Hard under rail								
ILSB Int. latch stud broken Int. latch spring out of position <	ILOP	Int. latch out of position								
ILSBInt. latch stud brokenInt. latch spring out of positionInt. latch s										
JCS Jumps cartridge Image: cartridge <	ILSB	Int. latch stud broken								
JL Jumps latch Image: Constraint of the state of the	ILSP	Int. latch spring out of position								
JM Jumps magazine 5 <th< th=""></th<>	JCS	Jumps cartridge								
JO Jars off	JL	Jumps latch								
JO Jars off	JM	Jumps magazine	5							
LB Light blow	JO	Jars off								
	LB	Light blow								

МАН	Magazine assembles hard							
MCSO	Magazine cap shot off							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
он	Opens hard	1						
OR	Over-rides	7						
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber							
RIS	Ring in sholder							
RS	Rim srem							
SBC	Stems bottom chambers							
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
SCX	Shell catches							
SHI	Short indent							
SI	Stems incline	2						
SIC	Stems in chamber							
SL	shaves lead							
SLC	Stems left side of chamber							
SMOC	Stretch marks on case							
SOR	Stem over-ride							
SP	Stems port							
SR	Shoulder rough							
SRC	Stems right side of chamber							
SRIC	Specific rings in chamber							
SSC	shell stems carrier							
SSOC	Surface scratches on case							
STC	Stems top chamber	2						
SWE	Safety switch works too easily							
SWH	Safety switch works too hard							
SWW	Safety ewitxh won't work							
TD	Tips down							
TU	Tips up							
TWP	Trigger won't pull							
TWR	Trigger won't retract							
UNCN-T	Uncoded							
ХН	Extracts hard	3			1			
ХНВ	Extractor hits bbl							
Н	Lliah							
	High							

LO	Low								
LEFT	Left								
	Right								
	Doesn't Group		6	1					
	Front sight tipped		<u> </u>						
	Rear sight tipped								
	Rear sight base raised								
	Front sight raised								
	Front sight loose								
	Rear sight loose								
	Missing parts at target								
	Uncoded nonconformity at target								
	Sheeded hencemennity at larget								
AI-P	Assembly incompleye at proof								
	Barrel bracket cracked or broken at proof								
	Blows cases at proof								
	Barrel extension broken at proof								
	Blanked primer at proof								
	Barrel lug shot off at proof								
	Blown primer at proof								
	Barrel split at proof								
	Doesn't lock over shells at proof								
	Ejector sticks back at proof								
	Fore-end cracked at proof								
	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
	Gas cylinder shot off at proof								
	Guide ring shot off at proof								
	Magazine cap shot off at proof								
	Magnaflux stamp illegible on bbl								
	Magnaflux stamp missing on bbl								
	Pierced primer at proof	1	1	4					
	Stock cracked or broken at proof								
	Uncoded proof malfunctions		6			8			
			-	1	1	-		I	

Summary		Proof Failures otal Rejected:	23948 3754								Month:	
		Il Reject Rate:	15.68									
		Shot:	11813	3849	3675001 -	Test _{63b} arget	1303	2102	463			
	Proof	Rejected:	44	56	105	1	13	32	4	0	0	0
	11001	Percent:	0.4	1.5	2.9	0.2	1.0	1.5	0.9	-	-	-
		Shot:	12451	3944	2431	97	1191	2156	592	165	666	
	Test	Rejected:	1517	496	439	106	116	256	55	23	1	0
		Percent:	12.2	12.6	18.1	109.3	9.7	11.9	9.3	13.9	0.2	
		Shot:	7521	2101	3115	676	1586	172		24		
	Target	Rejected:	161	31	114	0	184	0	0	0	0	0
	-	Percent:	2.1	1.5	3.7	0.0	11.6	0.0		0.0		
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 M/L	
AB	Action binds							4	42			
ASFB	Action spring follower bind	ls										
BABS	Bulge at body shoulder		1									
BAC	Burr at chamber		93	165	40	5	7					
BBMA	BBL-to-bolt misalignment		3	1	3							
BB	Bolt binds/catches		129	28	45	7	11				1	
BCOBS	Bolt catches on bolt stop											
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases									1		
BHR	Bolt hits receiver											
BHS BLOP	Bolt plug hits safety switch											
BLSO	Bar lock or disconnector o	out of position										
BPO	Barrel lug shot off Bolt pulls out				1							
BSCO	Barrel support came out				1							
BSSM	Bolt stems shell in magazi	ne	1				1					
BWCD	Bolt won't cam down		19	4	6		2					
BWCFM	Bolt won't close over full m	nagazine	17	•	30							
CBS-F	Shells catch on bbl suppor											
CBS-L	Shells catch on bbl suppor	rt-loading										
CC	Carrier catches on shells,r				3							
CD	Case dented			1								
СН	Closes hard		95	48	32	1	9					
СНАВ	Carrier hits action bar											
CLM	Can't laod magazine			1								
со	Cut-off											
CR	Cuts rim							ļ				
CS	Cases swell											
CTOG	Chamber torn or gouged		3									
CTP	Creepy trigger pull											
CWSB	Cams wrong side of action	n par										
DBB	Doesn't blow back	- h						32		1		
DCS	Double click in safety swite	UII								1		
DCT DCU	Double click in trigger Doesn't close-up							4				
DEU	Doesn't eject		8	3	4	10		28			<u> </u>	
DEL	Doesn't eject live round		2	3	4	10		20		ł	<u> </u>	<u> </u>
DFB	Doesn't feed back		<u> </u>								<u> </u>	<u> </u>
DFU	Doesn't feed up									1		
DLO	Doesn't lock open (after la	et shell)								<u> </u>		

DLU	Doesn't lock-up			1			42	I	2	1	
DS	Dead safe	3		2	1	2	42		2		
DSM	Drops shell-magazine	3			armonaa						
DSM	Doesn't trip latch		G	allery Perf	onnance	Repon	1				
DX			3	- Proof -	Test - Target		54		1		
DXL	Doesn't extract Doesn't extract live round	3	3	1			- 54		1		
EDS		44	4	45	50	2			10		
EDS	Extractor drops shell	11	4	15	52	2			10		
ESB	Ejector sticks back	6	1	1		1					
ESCR	Empty shell catches receiver	_				1					
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds	1									
FC	Fails to connect						10				
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire	6		4		3	1				
FFM	Fails to feed from magazine		2				3				
FFP	Flat firing pin										
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens	1	2	4	1						
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	188	2	1		9					
GCSO	Gas cyl shot off										
GRSO	Guide ring shot off										
HBL	Heavy bolt lift	71	18	45		28					
HMSC	Heading mismatch-steps on case										
НРА	High pressure ammo										
HUE	Hard under extractor										
HUR	Hard under rail	7		16	4						
ILOP	Int. latch out of position										
ILRM	Int. latch ret. Missing										
ILSB	Int. latch stud broken										
ILSP	Int. latch spring out of position										
JCS	Jumps cartridge										
JL	Jumps latch										
JM	Jumps magazine	23	37	9	8			5			
JO	Jars off	25	51		<u> </u>						
LB	Light blow			1		1			4		┼────┤
MAH	Magazine assembles hard			 '			{	+	+ +	 	╂────┤
MCSO	Magazine cap shot off	+		 							┼───┤
MCSO			7		2						┥────┤
	Magazine capacity wrong		1		2						
MFA MFOP	Misfires (ammo) Magazine follower out of position										<u> </u>
							<u> </u>				
ML	Magazine loose						3				<u> </u>
MLH	Magazine loads hard			 			<u> </u>	-		ł	┞────┤
MRH	Magazine removes hard		2				1	2			<u> </u>
ОН	Opens hard	38	35	23	1	4		l		l	
OR	Over-rides	189	14	3	13	3	16				ļ
PH	Pulls hard			ļ			ļ	ļ			
PSI	Proof stamp illegible										
PSM	Proof stamp missing			ļ							
RBOC	Rings and bulges on case							L			
RDW	(Action) release doesn't work	4									
RIC	Rings in chamber	313	66	76	1	18					

RIS	Ring in sholder	167		18			1				
	Rim srem	107		2							
SBC	Stems bottom chambers	14	15 G	allery Per	ormance	Report					
	Stems bbl extension					Среп					
SCB	Stock cracked or broken	1		Proot -	Hest - Hargei						
SCX	Shell catches										
	Short indent	1									
	Stems incline	33	5			1	2				
	Stems in chamber										
	shaves lead								3		
	Stems left side of chamber	5	1	1							
	Stretch marks on case										
	Stem over-ride	1		1			46	4			
	Stems port										
	Shoulder rough										
SRC	Stems right side of chamber	16	1			1					
	Specific rings in chamber		20								
	shell stems carrier										
	Surface scratches on case										
	Stems top chamber	6	1				9	2			
	Safety switch works too easily	2				1					
	Safety switch works too hard	1									
	Safety ewitxh won't work										
	Tips down										
ΤU	Tips up										
TWP	Trigger won't pull										
	Trigger won't retract										
	Uncoded	14	2	10		5					
	Extracts hard	21	6	42		6					
ХНВ	Extractor hits bbl		1								
ні	High										
LO	Low										
LEFT	Left										
	Right										
DG	Doesn't Group	161	31	114		184					
	Front sight tipped	101				101					
RSTT	Rear sight tipped			1			1				
	Rear sight base raised								1		
	Front sight raised						1				
	Front sight loose			1			1				
	Rear sight loose						1				
	Missing parts at target						1				
UNCN-G	Uncoded nonconformity at target						1				
	, at larger										
AI-P	Assembly incompleye at proof										
BBB	Barrel bracket cracked or broken at proof										
BC-P	Blows cases at proof										
BEB-P	Barrel extension broken at proof										
BLP-P	Blanked primer at proof										
	Barrel lug shot off at proof										
	Blown primer at proof						1				
	Barrel split at proof										
DLOS-P	Doesn't lock over shells at proof										
	Ejector sticks back at proof						19				
	Procession and Procession					•				•	

FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof		1 G	allerv Per	formance	Report	3	4		
GCSO-P	Gas cylinder shot off at proof				Test - Targe					
GRSO-P	Guide ring shot off at proof			1 1001 -		4				
MCSO-P	Magazine cap shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl			3						
MSM-P	Magnaflux stamp missing on bbl	7	1	1						
PP-P	Pierced primer at proof	21	50	36		5	1			
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions	16	4	65	1	8	9			

Summary	Total Test +	Proof Failures	1238								Test Date:	
_	-	Total Rejected:	227									
	Overa	all Reject Rate:	18.34									
		Shot:	185	670	198	45	1	169	1			
	Proof	Rejected:	0	2	6	0	0	0	0	0	0	0
		Percent:	0.0	0.3	3.0	0.0	0.0	0.0	0.0			
		Shot:	248	674	126			26			156	
	Test	Rejected:	35	134	41	0	0	7	0	0	1	0
	1001	Percent:	14.1	19.9	32.5			26.9			0.6	
		Shot:	52	164	124		10	3				
	Target	Rejected:	1	0	0	0	0	0	0	0	0	0
	, u, got	Percent:	1.9	0.0	0.0		0.0	0.0				
CODE	MALFUNCTION		700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
AB	Action binds											
ASFB	Action spring follower bind	ds										
BABS	Bulge at body shoulder											
BAC	Burr at chamber		1	46	9							
BBMA	BBL-to-bolt misalignment											
BB	Bolt binds/catches				2							
BCOBS	Bolt catches on bolt stop											
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch											
BLOP	Bar lock or disconnector of	out of position										
BLSO	Barrel lug shot off											
BPO	Bolt pulls out		1									
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magaz	ine		-								
BWCD	Bolt won't cam down			3								
BWCFM	Bolt won't close over full n											
CBS-F	Shells catch on bbl suppo	ort-reeding										
CBS-L	Shells catch on bbl suppo											
	Carrier catches on shells,	mag,receiver										
CD CH	Case dented		1	3	1							
	Closes hard		1	8	ï							
CHAB CLM	Carrier hits action bar											
	Can't laod magazine											
CO CR	Cut-off Cuts rim											
CR CS	Cuts rim Cases swell											
CS CTOG	Cases swell Chamber torn or gouged											
CTP CWSB	Creepy trigger pull	n har										
DBB	Cams wrong side of action Doesn't blow back	li Dal						2				
	Loesin blow back							۷				

DCT Doul DCU Does DE Does DEL Does DFB Does DFU Does	uble click in safety switch uble click in trigger esn't close-up esn't eject esn't feed back								
DCU Does DE Does DEL Does DFB Does DFU Does	esn't close-up esn't eject esn't eject live round esn't feed back								
DE Does DEL Does DFB Does DFU Does	esn't eject esn't eject live round esn't feed back								
DEL Does DFB Does DFU Does	esn't eject live round esn't feed back								
DFB Does DFU Does	esn't feed back								
DFU Does									
	esn't feed up								
	esn't lock open (after last shell)								
	esn't lock-up					5			
	ad safe								
DSM Drop	ops shell-magazine								
	esn't trip latch								
	esn't extract		13						
DXL Does	esn't extract live round		1						
EDS Extra	ractor drops shell		10						
	ctor sticks back	1	3						
	pty shell catches receiver		-						
	ractor stems shell								
	es automatically								
	lower binds								
	Is to connect								
	e-end cracked or broken								
	lows-down								
	Is to fire							1	
FFM Fails	Is to feed from magazine								
	t firing pin								
	es on safe								
	ng pin hits bbl								
	ng pin hits inside rim								
FPO Floo	or plate opens								
	or plate opens hard								
	es when safe is released								
	lower tips	4							
GCSO Gas	s cyl shot off								
GRSO Guid	ide ring shot off								
HBL Heav	avy bolt lift			2					
HMSC Head	ading mismatch-steps on case								
HPA High	h pressure ammo								
HUE Harc	rd under extractor								
HUR Hard	rd under rail								
ILOP Int. la	latch out of position								
ILRM Int. la	latch ret. Missing								
ILSB Int. la	latch stud broken								
ILSP Int. la	latch spring out of position								
JCS Jum	nps cartridge								
JL Jum	nps latch								
JM Jum	nps magazine	1	23						
JO Jars	s off								
LB Light	ht blow								

MAH	Magazine assembles hard							
MCSO	Magazine cap shot off							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
он	Opens hard	2						
OR	Over-rides	7	13					
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber	1	2	17				
RIS	Ring in sholder							
RS	Rim srem							
SBC	Stems bottom chambers		5					
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
SCX	Shell catches							
SHI	Short indent							
SI	Stems incline	16						
SIC	Stems in chamber							
SL	shaves lead							
SLC	Stems left side of chamber							
SMOC	Stretch marks on case							
SOR	Stem over-ride							
SP	Stems port							
SR	Shoulder rough							
SRC	Stems right side of chamber							
SRIC	Specific rings in chamber							
SSC	shell stems carrier							
SSOC	Surface scratches on case							
STC	Stems top chamber							
SWE	Safety switch works too easily							
SWH	Safety switch works too hard							
SWW	Safety ewitxh won't work							
TD	Tips down							
TU	Tips up							
TWP	Trigger won't pull							
TWR	Trigger won't retract							
UNCN-T	Uncoded		3					
ХН	Extracts hard		1					
ХНВ	Extractor hits bbl			10				
HI	High							
							1	

	1								
	Low								
LEFT	Left								
	Right								
	Doesn't Group	1							
FSST	Front sight tipped								
	Rear sight tipped								
	Rear sight base raised								
	Front sight raised								
	Front sight loose								
	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
	Barrel split at proof								
	Doesn't lock over shells at proof								
	Ejector sticks back at proof								
	Fore-end cracked at proof								
	Fore-end shot off at proof								
	Fails to fire at proof								
	Gas cylinder shot off at proof								
	Guide ring shot off at proof								
	Magazine cap shot off at proof								
	Magnaflux stamp illegible on bbl								
	Magnaflux stamp missing on bbl		1						
	Pierced primer at proof		1						
	Stock cracked or broken at proof								
	Uncoded proof malfunctions			6					
	eneoudu proor mananoliono			3	1	1	I	1	

Summary		Proof Failures	20020								Month:	
		otal Rejected:	3804 19.00									
		Shot:	1850	9768	I ⊿3िद्याप्रिया -	Tests ₁₈₄ arget	524	1729	858	69		
	Proof	Rejected:	19	173	72	5	6	2	0000	1	0	0
	11001	Percent:	1.0	1.8	1.7	0.0	1.1	0.1	0.0	1.4	· ·	Ū
		Shot:	3089	9547	3479	290	580	1599	914	244		
	Test	Rejected:	388	979	495	110	107	141	7	27	0	0
		Percent:	12.6	10.3	14.2	37.9	18.4	8.8	0.8	11.1		
		Shot:	1772	9060	1978	817	317	33	33			
	Target	Rejected:	198	724	191	125	34	0	0	0	0	0
		Percent:	11.2	8.0	9.7	15.3	10.7	0.0	0.0			
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 M/L	
AB	Action binds							1	6			
ASFB	Action spring follower bind	ls										
BABS	Bulge at body shoulder		4	~~~								
BAC	Burr at chamber		22	27	14	23						
BBMA	BBL-to-bolt misalignment		1	2	1	1						
BB BCOBS	Bolt binds/catches		67	96	87	10	2	2				
	Bolt catches on bolt stop											
BCOE BCOF	Bolt catches on ejector											
BCOF	Bolt catches on follower Blows cases											
BHR	Bolt hits receiver				1							
BHS	Bolt plug hits safety switch											
BLOP	Bar lock or disconnector c											
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazi	ine		2								
BWCD	Bolt won't cam down		2	11	2							
BWCFM	Bolt won't close over full n	nagazine	10	3	5							
CBS-F	Shells catch on bbl suppo	rt-feeding										
CBS-L	Shells catch on bbl suppo	rt-loading										
CC	Carrier catches on shells,	mag,receiver										
CD	Case dented				1							
СН	Closes hard		43	104	66	1	2					
CHAB	Carrier hits action bar											
CLM	Can't laod magazine				l					l	l	
CO	Cut-off				l					l	l	
CR	Cuts rim											
CS CTOC	Cases swell			4		7						
CTOG CTP	Chamber torn or gouged			1		7						
CWSB	Creepy trigger pull Cams wrong side of action	n har			<u> </u>							
DBB	Doesn't blow back				<u> </u>			7				
DCS	Double click in safety swit	ch						· · · · · · · · · · · · · · · · · · ·				
DCT	Double click in trigger	<u>, , , , , , , , , , , , , , , , , , , </u>			<u> </u>							
	Doesn't close-up			1								
DE	Doesn't eject		14	78	22		1	13		1	1	
DEL	Doesn't eject live round		3	9	33			<u>.</u>		1	1	
DFB	Doesn't feed back									1	1	
DFU	Doesn't feed up				1					9		
DLO	Doesn't lock open (after la	ast shell)								-		

DLU	Doesn't lock-up						33				
	Dead safe		2				55				
	Drops shell-magazine		<u> </u>	bllony Dorf	ormance	Penart					
	Doesn't trip latch					report					
	Doesn't extract	3	6	allery Perf	Hest - Fargel		19	1			
	Doesn't extract live round	-	2	4					2		
	Extractor drops shell	13	79	56		4			6		
	Ejector sticks back	11	33	7					-		
	Empty shell catches receiver	1	1								
	Extractor stems shell										
	Fires automatically										
	Follower binds		1								
	Fails to connect						1				
	Fore-end cracked or broken										
	Follows-down		2								
	Fails to fire	1	30	10							
	Fails to feed from magazine										
	Flat firing pin										
	Fires on safe			1							
FPHB	Firing pin hits bbl	1					1	1			
FPHI	Firing pin hits inside rim										
	Floor plate opens	1 1	3	5	1		1	1			
FPOH	Floor plate opens hard	1 1	-		· · ·		1	1			
	Fires when safe is released										
	Follower tips	63	11	28		5					
GCSO	Gas cyl shot off										
	Guide ring shot off										
HBL	Heavy bolt lift	23	44	64	10	42					
	Heading mismatch-steps on case										
	High pressure ammo										
	Hard under extractor								5		
	Hard under rail		1	7					_		
	Int. latch out of position										
	Int. latch ret. Missing										
	Int. latch stud broken										
	Int. latch spring out of position										
	Jumps cartridge										
JL	Jumps latch										
JM	Jumps magazine	6	137	5		13	3	1			
JO	Jars off							1			
	Light blow			1							
	Magazine assembles hard						3	1			
	Magazine cap shot off										
	Magazine capacity wrong	1		2		4					
	Misfires (ammo)										
MFOP	Magazine follower out of position										
	Magazine loose							1			
	Magazine loads hard										
MRH	Magazine removes hard						1	1			
	Opens hard	9	25	10			4				
	Over-rides	26	102	2		9	35	1			
	Pulls hard							1			
	Proof stamp illegible										
	Proof stamp missing										
	Rings and bulges on case										
	(Action) release doesn't work										
	Rings in chamber	16	38	20	52	2	1	1			
	1						1				

RIS	Ring in sholder	5	11	10							
	Rim srem		6	10							
	Stems bottom chambers	2	22 (Gallery Per	ormance	Report					
SBE	Stems bbl extension	_		Gallery Per		repen					
	Stock cracked or broken			Proot -	Hest - Harge						
SCX	Shell catches										
	Short indent		2								
	Stems incline	5	14	2		2	4				
SIC	Stems in chamber		8								
SL	shaves lead										
SLC	Stems left side of chamber	3	4			5					
	Stretch marks on case										
SOR	Stem over-ride		6				15				
SP	Stems port										
	Shoulder rough										
SRC	Stems right side of chamber	14	8			1					
SRIC	Specific rings in chamber										
	shell stems carrier										
SSOC	Surface scratches on case										ļ
	Stems top chamber	1	1								
SWE	Safety switch works too easily										
	Safety switch works too hard										
SWW	Safety ewitxh won't work			_							
	Tips down			_							
TU	Tips up										
	Trigger won't pull										
	Trigger won't retract	16	17		5	15			5		
	Uncoded Extracts hard	16 3	17 29	22 5	5	15			5		
	Extractor hits bbl	3	29	5							
хпв											
ні	High										
LO	Low										
	Left										
	Right										
DG	Doesn't Group	198	700	191	125	34					
	Front sight tipped		24								
	Rear sight tipped							1			
RSBR	Rear sight base raised										
FSTR	Front sight raised										
FSTL	Front sight loose										
RSTL	Rear sight loose										
MGPT-G	Missing parts at target										
UNCN-G	Uncoded nonconformity at target										
AI-P BBB	Assembly incompleye at proof	6					1				
BBB	Barrel bracket cracked or broken at proof										
	Blows cases at proof										
	Barrel extension broken at proof										
	Blanked primer at proof					l					
	Barrel lug shot off at proof					l		ł		l	
	Blown primer at proof			8							├ ────┤
	Barrel split at proof					l					
	Doesn't lock over shells at proof					l	ļ			l	├ ────┤
ESB-P	Ejector sticks back at proof						1				

FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof		G	allerv Per	ormance	Report			
GCSO-P	Gas cylinder shot off at proof			,	Test - Targel				
GRSO-P	Guide ring shot off at proof			11001-	rest - raige				
MCSO-P	Magazine cap shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl		1						
PP-P	Pierced primer at proof	11	120	41	2	6			
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions	2	52	22	3			1	

Summary	Total Test +	Proof Failures	21636								Month:	
-		Total Rejected: all Reject Rate:	4448 20.56									
		Shot:	4766	8059		Test 616arget	17	2728	94	152		
	Proof	Rejected:	10	21	21	0	0	9	0	0	0	0
	11001	Percent:	0.2	0.3	0.4	0.0	0.0	0.3	0.0	0.0	Ũ	Ŭ
		Shot:	5579	7332	4632	756		2825	94	357		
	Test	Rejected:	620	462	309	30	0	474	1	45	0	0
		Percent:	11.1	6.3	6.7	4.0		16.8	1.1	12.6	1	
		Shot:	3715	9201	3189	756		37				
	Target	Rejected:	306	1587	272	281	0	0	0	0	0	0
		Percent:	8.2	17.2	8.5	37.2		0.0				
CODE	MALFUNCTION		700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 M/L	
AB	Action binds		1					2				
ASFB	Action spring follower bind	ds										
BABS	Bulge at body shoulder											
BAC	Burr at chamber		40	23	8	7						
BBMA	BBL-to-bolt misalignment			1	2							
BB	Bolt binds/catches		30	24	24	4						
BCOBS	Bolt catches on bolt stop				1	├ ────┤				l	l	
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower			2								
BCOF	Blows cases											
BHR BHS	Bolt hits receiver	h										<u> </u>
BLOP	Bolt plug hits safety switch Bar lock or disconnector of											<u> </u>
BLSO	Barrel lug shot off	out of position										
BPO	Bolt pulls out											<u> </u>
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magaz	zine									1	
BWCD	Bolt won't cam down		15	5	3							<u> </u>
BWCFM	Bolt won't close over full n	magazine	36	7	14							
CBS-F	Shells catch on bbl suppo			•								
CBS-L	Shells catch on bbl suppo	ort-loading										
cc	Carrier catches on shells,											
CD	Case dented		1	1	2							
СН	Closes hard		65	85	45	3						
СНАВ	Carrier hits action bar											
CLM	Can't laod magazine		1	1	1			1				
co	Cut-off											
CR	Cuts rim											Ļ
CS	Cases swell				L							
CTOG	Chamber torn or gouged			1	1							
CTP	Creepy trigger pull				L							
CWSB	Cams wrong side of action	n bar										
DBB	Doesn't blow back					ļ ļ		54		<u> </u>		
DCS	Double click in safety swit	tch				├ ────┤				3		
DCT	Double click in trigger					├ ──── │		ļ				
	Doesn't close-up				1			4		l		
DE	Doesn't eject		7	34	32	12		22				
DEL	Doesn't eject live round			11	1							
DFB	Doesn't feed back							12		27		l
DFU	Doesn't feed up	aat a hall)				├		13		27		
DLO	Doesn't lock open (after la	ast shell)				I		28		1		<u> </u>

DLU	Doesn't lock-up	I					54		1	1	
DS	Dead safe	1	7	7			54				
DSM	Drops shell-magazine		<u> </u>		armonaa	Donart					
DSM	Doesn't trip latch		G	allery Per	ormance	Repon					
DX	Doesn't extract	14	1	Proof -	Test - Target	l	5				
DXL	Doesn't extract live round	14	2	5			5		1		
		5		1							
EDS ESB	Extractor drops shell	5	8						2		
	Ejector sticks back	1	12	6							
ESCR	Empty shell catches receiver										
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds	1					1		1		
FC	Fails to connect						17		2		
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire	1	5	3			3	1	2		
FFM	Fails to feed from magazine										
FFP	Flat firing pin										
FOS	Fires on safe										
	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens		28		3						
	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	202	14	33							
GCSO	Gas cyl shot off										
GRSO	Guide ring shot off										
HBL	Heavy bolt lift	15	35	9							
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUE	Hard under extractor								1		
	Hard under rail	6	2								
ILOP	Int. latch out of position										
ILRM	Int. latch ret. Missing										
ILSB	Int. latch stud broken										
ILSP	Int. latch spring out of position										
JCS	Jumps cartridge										
JL	Jumps latch										
JM	Jumps magazine	3	12	11			15				
JO	Jars off										
LB	Light blow								4		
MAH	Magazine assembles hard									1	
	Magazine cap shot off										
	Magazine capacity wrong		2	2						1	
	Misfires (ammo)	1	_	_							
MFOP	Magazine follower out of position		1	1		1	1				
	Magazine loose		•	1		1	1			1	
	Magazine loads hard									1	
	Magazine removes hard						59				
OH	Opens hard	4	8	7			6			1	
OR	Over-rides	37	5	10	1		67			<u> </u>	
PH	Pulls hard		5		<u> </u>					<u> </u>	
PSI	Proof stamp illegible			1			1			+	
PSM	Proof stamp missing						1			<u> </u>	
	Rings and bulges on case										
RDW	(Action) release doesn't work		74	60							
RIC	Rings in chamber	99	71	69							

RIS	Ring in sholder		14						
	Rim srem		14						
SBC	Stems bottom chambers		G	allery Per	ormance	Report			
	Stems bbl extension		0	allery Per Proof		Report			
SCB	Stock cracked or broken		1	Proot -	Hest - Farge				
SCX	Shell catches								
	Short indent								
	Stems incline	14	26				19		
	Stems in chamber	2					4		
	shaves lead								
SLC	Stems left side of chamber						2		
	Stretch marks on case								
SOR	Stem over-ride	1	1	1			85		
SP	Stems port								
SR	Shoulder rough								
	Stems right side of chamber	2							
SRIC	Specific rings in chamber								
	shell stems carrier								
SSOC	Surface scratches on case								
STC	Stems top chamber		1				10		
	Safety switch works too easily								
SWH	Safety switch works too hard		1						
	Safety ewitxh won't work	1		1					
	Tips down								
	Tips up								
	Trigger won't pull								
	Trigger won't retract			4				4	
	Uncoded	1 7	3	1			3	1	
	Extracts hard	/	/	8					
	Extractor hits bbl								
ні	High								
LO	Low								
LEFT	Left								
	Right		1						
DG	Doesn't Group	306	1585	272	281				
	Front sight tipped		1						
RSTT	Rear sight tipped								
	Rear sight base raised								
	Front sight raised								
FSTL	Front sight loose								
RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof	3	1				1		
	Barrel bracket cracked or broken at proof								
	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
	Blanked primer at proof								
	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
	Barrel split at proof								
	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof	1					2		

FCB-P	Fore-end cracked at proof						1		
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof		1 G	allerv Per	ormance	Report	3		
GCSO-P	Gas cylinder shot off at proof				Test - Targel				
GRSO-P	Guide ring shot off at proof			1 1001 -	rest - raige				
MCSO-P	Magazine cap shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl	1							
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions	5	19	20			2		

Summary		Proof Failures	1123								Test Date:	7/31/2002
		Total Rejected: all Reject Rate:	183 16.30									
		Shot:	183	140	528		2		128			
	Proof	Rejected: Percent:	0 0.0	0 0.0	4 0.8	0	0 0.0	0		0	0	0
	Test	Shot: [Rejected:	192 26	113 9	596 102	0	43 0	0	128 2	0	47 2	0
		Percent:	13.5	8.0	17.1		0.0		1.6		4.3	
		Shot:	73	56	479		1		12			
	Target	Rejected: Percent:	0 0.0	0 0.0	38 7.9	0	0 0.0	0	0 0.0	0	0	0
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
АВ	Action binds											
ASFB	Action spring follower binc	19										
BABS	Bulge at body shoulder	10										
BAC	Burr at chamber		4	1	16							
BBMA	BBL-to-bolt misalignment											
BB	Bolt binds/catches				1							
BCOBS	Bolt catches on bolt stop											
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch	1 I										
BLOP	Bar lock or disconnector o	out of position										
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazi	ine										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full m				2							
CBS-F	Shells catch on bbl suppor											
CBS-L	Shells catch on bbl suppor											
CC	Carrier catches on shells,r	mag,receiver										
CD	Case dented											
СН	Closes hard				5							
CHAB	Carrier hits action bar											
	Can't laod magazine											
CO CR	Cut-off											
CS	Cuts rim Cases swell											
CS CTOG	Cases swell Chamber torn or gouged											
CTP	Creepy trigger pull											
CWSB	Cams wrong side of action	a har										
DBB	Doesn't blow back											
	Local Low back											

DCTDouble allek integerImageImageImageImageImageImageImageDEDesart led to indImageImageImageImageImageImageImageDEDesart led to kinImage </th <th>DCS</th> <th>Double click in safety switch</th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th>	DCS	Double click in safety switch							
DGU Deem tokes up Image: second in the law of									
DE Deskniegel vond I									
DEL DPBDesert Tech kay kayImage of the basic backImage of the back <t< td=""><td></td><td></td><td></td><td></td><td>1</td><td></td><td></td><td></td><td></td></t<>					1				
DFB Deent fleed back Image: second s	DEL	Doesn't eject live round			2				
DFU Doesn'leduy on (after last shell) Image: shell and shell Image: shell and sh	DFB	Doesn't feed back			_				
DLODoesn't lock open (after last shell)Image: shell magazineImage: shell magazine </td <td>DFU</td> <td>Doesn't feed up</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	DFU	Doesn't feed up							
DLUDoesn't lock-upImage in the set of the s	DLO	Doesn't lock open (after last shell)							
DSDead safeDead safeDea	DLU								
DSMDroge shell-magazineImage: shear of the shear									
DTL Doesn't kritaci Image: Second Se	DSM								
DXDoesn't strat live rundImage: strate of rops shellSImage: strate of rops shellImage: st									
DXL Desn't atriat live round Image: state live round							1		
EDSExtractor drops shell36 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>									
ESREjector stoks back131314161616ESCREntry shell actors receiver11111111ESSExtrador stems shell1111111111FBFries automatically111 <td< td=""><td>EDS</td><td></td><td>3</td><td></td><td>6</td><td></td><td></td><td></td><td></td></td<>	EDS		3		6				
ESCR Empty shell aches receiver Image Im	ESB	Ejector sticks back			13				
ESSExtractor stems shellImage: standard s	ESCR	Empty shell catches receiver							
FAFires automaticallyImage: sector of the sector of	ESS								
FB Follower binds Image: state in the st	FA								
FCFails to connectImage: starting of the sta	FB								
FCBFore-end cracked or brokenImage: Constraint of the stress of th	FC								
FD Follows-down Image: Constraint of the set		Fore-end cracked or broken							
FFFails to fireImage and the second se									
FFPFlat fring pinImage in the set of the se		Fails to fire							
FFPFlat fring pinImage in the set of the se	FFM	Fails to feed from magazine							
FOSFires on safeImage <td>FFP</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	FFP								
FPHBFiring pin hits boldImage in hits boldImage in hits inside rimImage in hits insinside rimImage in hi	FOS	Fires on safe							
FPHIFiring pin hits inside rimImage in the series of the series opens in the series opens hardImage in the series opens hard <t< td=""><td>FPHB</td><td>Firing pin hits bbl</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	FPHB	Firing pin hits bbl							
FPOHFloor plate opens hardImage: strain of the strai	FPHI	Firing pin hits inside rim							
FSRFires when safe is releasedImage: selection of the sel	FPO	Floor plate opens		1	7				
FSRFires when safe is releasedImage: selection of the sel	FPOH	Floor plate opens hard							
GCSOGas cyl shot offInternalInt	FSR	Fires when safe is released							
GRSOGuide ring shot offImage of the shot offImage offIma	FT	Follower tips			1				
GRSOGuide ring shot offImage of the shot offImage offIma	GCSO	Gas cyl shot off							
HMSCHeading mismatch-steps on caseImage of the steps	GRSO	Guide ring shot off							
HPAHigh pressure ammoImage of the structorImage of th	HBL	Heavy bolt lift			25				
HPAHigh pressure ammoImage of the structorImage of th	HMSC	Heading mismatch-steps on case							
HURHard under railIntervention <th< td=""><td>HPA</td><td>High pressure ammo</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>	HPA	High pressure ammo							
ILOPInt. latch out of positionInt. latch ret. MissingInt. latch stud brokenInt. latch spring out of positionInt. latch spring out of posi									
ILRMInt. latch ret. MissingInt. latch stud brokenInt. latch stud brokenInt. latch stud brokenInt. latch stud brokenInt. latch spring out of positionInt. latch sp	HUR								
ILSBInt. latch stud brokenInt. latch spring out of positionInt. latch s	ILOP	Int. latch out of position							
ILSPInt. latch spring out of positionImage: spring out of position <th< td=""><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></th<>									
JCS Jumps cartridge Image: constraint of the stress of th									
JL Jumps latch Image: Constraint of the system Image: Constand of the system Image: Constando	ILSP	Int. latch spring out of position							
JM Jumps magazine 3 1 9									
JM Jumps magazine 3 1 9	JL	Jumps latch							
JO Jars off	JM	Jumps magazine	3	1	9				
LB Light blow	JO	Jars off							
	LB	Light blow							

MAH	Magazine assembles hard								
MCSO	Magazine cap shot off								
MCW	Magazine capacity wrong								
MFA	Misfires (ammo)	1							
MFOP	Magazine follower out of position								
ML	Magazine loose								
MLH	Magazine loads hard								
MRH	Magazine removes hard								
он	Opens hard			1					
OR	Over-rides	12	3	5					
PH	Pulls hard								
PSI	Proof stamp illegible								
PSM	Proof stamp missing								
RBOC	Rings and bulges on case								
RDW	(Action) release doesn't work								
RIC	Rings in chamber		3	2					
RIS	Ring in sholder	2		1		1	1		
RS	Rim srem								
SBC	Stems bottom chambers								
SBE	Stems bbl extension								
SCB	Stock cracked or broken			3					
SCX	Shell catches								
SHI	Short indent								
SI	Stems incline								
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber						1		
SMOC	Stretch marks on case								
SOR	Stem over-ride								
SP	Stems port								
SR	Shoulder rough								
SRC	Stems right side of chamber								
SRIC	Specific rings in chamber								
SSC	shell stems carrier								
SSOC	Surface scratches on case								
STC	Stems top chamber								
SWE	Safety switch works too easily			1					
SWH	Safety switch works too hard								
SWW	Safety ewitxh won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
UNCN-T	Uncoded	1		1				2	
ХН	Extracts hard								
ХНВ	Extractor hits bbl								
н	 High								
НІ	High								

LO	Low						
	Left						
	Right					 	
	Doesn't Group		38				
			30				
	Front sight tipped						
	Rear sight tipped					 	
RSBR	Rear sight base raised						
	Front sight raised						
	Front sight loose						
	Rear sight loose						
MGPT-G	Missing parts at target						
UNCN-G	Uncoded nonconformity at target						
	Assembly incompleye at proof						
	Barrel bracket cracked or broken at proof						
	Blows cases at proof						
BEB-P	Barrel extension broken at proof						
BLP-P	Blanked primer at proof						
	Barrel lug shot off at proof						
	Blown primer at proof						
BS-P	Barrel split at proof						
	Doesn't lock over shells at proof						
	Ejector sticks back at proof						
	Fore-end cracked at proof						
	Fore-end shot off at proof						
	Fails to fire at proof		2				
	Gas cylinder shot off at proof						
	Guide ring shot off at proof						
	Magazine cap shot off at proof						
	Magnaflux stamp illegible on bbl						
	Magnaflux stamp missing on bbl						
	Pierced primer at proof		2				
	Stock cracked or broken at proof		4				
	Uncoded proof malfunctions						

Summary	Total Test + Pro	of Failures	216								Test Date:	6/29/2002
		l Rejected:	10									
	Overall R	eject Rate:	4.63									
		Shot:	35		73		63	64				
	Proof	Rejected:	0	0	0	0	0	0		0	0	0
		Percent:	0.0		0.0		0.0	0.0				
		Shot:	38	55			123					
	Teet	Rejected:	0	0	0	0	5	0	0	0	0	0
	Test	Percent:	0.0	0.0	Ŭ	v	4.1	Ŭ	Ũ	Ū	Ŭ	Ŭ
		Shot:					106					
	Torrat	Rejected:	0	0	0	0	5	0	0	0	0	0
	Target	Percent:	U	U	Ŭ	Ŭ	4.7	Ŭ	0	U	U	Ŭ
	MALFUNCTION IND		700 401	700 001	700.00	700 Del		7400	7000	Direction	700 ML	
CODE	MALFONCTION IND		700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire		
АВ	Action binds											
ASFB	Action spring follower binds											
BABS	Bulge at body shoulder											
BAC	Burr at chamber						1					
BBMA	BBL-to-bolt misalignment						•					
BB	Bolt binds/catches											
BCOBS	Bolt catches on bolt stop											
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch											
BLOP	Bar lock or disconnector out of	f position										
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazine											
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full maga								ļ			
CBS-F	Shells catch on bbl support-fee	eding							ļ			
CBS-L	Shells catch on bbl support-loa											
СС	Carrier catches on shells,mag,	,receiver										
CD	Case dented											
СН	Closes hard											
CHAB	Carrier hits action bar								 			
CLM	Can't laod magazine											
CO CR	Cut-off											
	Cuts rim											
CS CTOG	Cases swell											
CTP	Chamber torn or gouged								<u> </u>			
CWSB	Creepy trigger pull Cams wrong side of action bar	r l										
DBB	Doesn't blow back											
	LOGSITI NOW DOCK											

DCS	Double click in safety switch						
DCT	Double click in trigger						
	Doesn't close-up						
	Doesn't eject		 				
DEL	Doesn't eject live round						
	Doesn't feed back						
	Doesn't feed up		 				
	Doesn't lock open (after last shell)						
	Doesn't lock-up						
	Dead safe						
DSM	Drops shell-magazine						
DTL	Doesn't trip latch						
	Doesn't extract						
DXL	Doesn't extract live round						
	Extractor drops shell						
ESB	Ejector sticks back			1			
ESCR	Empty shell catches receiver						
	Extractor stems shell						
FA	Fires automatically						
	Follower binds						
	Fails to connect						
	Fore-end cracked or broken						
	Follows-down						
	Fails to fire		 				
	Fails to feed from magazine						
FFP	Flat firing pin						
	Fires on safe						
	Firing pin hits bbl						
	Firing pin hits inside rim						
FPO	Floor plate opens						
	Floor plate opens hard						
	Fires when safe is released						
	Follower tips						
	Gas cyl shot off						
	Guide ring shot off						
HBL	Heavy bolt lift			2			
HMSC	Heading mismatch-steps on case						
	High pressure ammo						
HUE	Hard under extractor						
HUR	Hard under rail						
	Int. latch out of position						
	Int. latch ret. Missing						
	Int. latch stud broken		 				
	Int. latch spring out of position						
	Jumps cartridge						
	Jumps latch						
	Jumps magazine						
	Jars off						
LB	Light blow						
L I	U						

МАН	Magazine assembles hard						
мсѕо	Magazine cap shot off						
MCW	Magazine capacity wrong						
MFA	Misfires (ammo)						
MFOP	Magazine follower out of position						
ML	Magazine loose						
MLH	Magazine loads hard						
MRH	Magazine removes hard						
ОН	Opens hard						
OR	Over-rides						
PH	Pulls hard						
PSI	Proof stamp illegible						
PSM	Proof stamp missing						
RBOC	Rings and bulges on case						
RDW	(Action) release doesn't work						
RIC	Rings in chamber			1			
RIS	Ring in sholder						
RS	Rim srem						
SBC	Stems bottom chambers						
SBE	Stems bbl extension						
SCB	Stock cracked or broken						
SCX	Shell catches						
SHI	Short indent						
SI	Stems incline						
SIC	Stems in chamber						
SL	shaves lead						
SLC	Stems left side of chamber						
SMOC	Stretch marks on case						
SOR	Stem over-ride						
SP	Stems port						
SR	Shoulder rough						
SRC	Stems right side of chamber						
SRIC	Specific rings in chamber						
SSC	shell stems carrier						
SSOC	Surface scratches on case						
STC	Stems top chamber						
SWE	Safety switch works too easily						
SWH	Safety switch works too hard						
SWW	Safety ewitxh won't work						
TD	Tips down						
TU	Tips up						
TWP	Trigger won't pull	 			 		ļ
	Trigger won't retract				 		ļ
UNCN-T	Uncoded						
XH	Extracts hard						ļ
ХНВ	Extractor hits bbl	 	 		 		
н	High						
<u>_ II</u>	Inian						I

	Low						
LO LEFT	Left						
	Right					 	
				E			
	Doesn't Group			5			
FSST	Front sight tipped						
	Rear sight tipped						
	Rear sight base raised						
	Front sight raised						
	Front sight loose						
	Rear sight loose						
MGPT-G	Missing parts at target						
UNCN-G	Uncoded nonconformity at target						
AI-P	Assembly incompleye at proof						
BBB	Barrel bracket cracked or broken at proof						
BC-P	Blows cases at proof						
BEB-P	Barrel extension broken at proof						
BLP-P	Blanked primer at proof						
BLSO-P	Barrel lug shot off at proof						
BP-P	Blown primer at proof						
	Barrel split at proof						
	Doesn't lock over shells at proof						
	Ejector sticks back at proof						
	Fore-end cracked at proof						
	Fore-end shot off at proof						
FF-P	Fails to fire at proof						
	Gas cylinder shot off at proof						
	Guide ring shot off at proof						
	Magazine cap shot off at proof						
	Magnaflux stamp illegible on bbl						
	Magnaflux stamp missing on bbl						
	Pierced primer at proof						
	Stock cracked or broken at proof						
	Uncoded proof malfunctions						

Summary		Proof Failures	22832								Month:	
		fotal Rejected: all Reject Rate:	4415 19.34									
		Shot:	9321	5037		Test 774arget	2308	1092	1226		I	
	Proof	Rejected:	22	40	52	0	37	2	2	0	0	0
	FIOOI	Percent:	0.2	0.8	1.2	0.0	1.6	0.2	0.2	U	Ū	Ŭ
		Shot:	10202	4733	3576	16	1429	1026	1352	343		
	Test	Rejected:	1297	918	646	64	409	191	19	85	0	0
		Percent:	12.7	19.4	18.1	400.0	28.6	18.6	1.4	24.8		
		Shot:	6627	4368	2046	767	958	35	13			
	Target	Rejected:	241	175	123	37	55	0	0	0	0	0
	-	Percent:	3.6	4.0	6.0	4.8	5.7	0.0	0.0			
CODE	MALFUNCTION		700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 M/L	
AB	Action binds		2					1	9			
ASFB	Action spring follower bind	ds										
BABS	Bulge at body shoulder		1			<u> </u>						
BAC	Burr at chamber		81	22	21	5	14					
BBMA	BBL-to-bolt misalignment		1	1	4		4					
BB BCOBS	Bolt binds/catches Bolt catches on bolt stop		43	15	75 1		4					
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch	n										
BLOP	Bar lock or disconnector of											
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magaz	ine	3									
BWCD	Bolt won't cam down		9	5	5		3					
BWCFM	Bolt won't close over full n		94	4	3		9					
CBS-F	Shells catch on bbl suppo	ort-feeding										
CBS-L	Shells catch on bbl suppo											
CC CD	Carrier catches on shells, Case dented	mag,receiver					5					
СН	Closes hard		144	28	26	2	16					
СНАВ	Carrier hits action bar		1-7-7	20	1		10					
	Can't laod magazine			1	i .	<u>├</u>	1			1	1	
со	Cut-off											
CR	Cuts rim											
CS	Cases swell											
CTOG	Chamber torn or gouged					8						
СТР	Creepy trigger pull											
CWSB	Cams wrong side of action	n bar			ļ					<u> </u>	ļ	
DBB	Doesn't blow back							1		<u> </u>		
DCS	Double click in safety swit	ch				└─── ↓				1		
	Double click in trigger					┝────┤						
	Doesn't close-up				10			24				
DE DEL	Doesn't eject Doesn't eject live round		22 39	9 164	10 12	┝────┼	3	21				
DEL DFB	Doesn't eject live round Doesn't feed back		59	104	12	├	Í					
DFB DFU	Doesn't feed up		2		<u> </u>	├				33		
DLO	Doesn't lock open (after la	ast shell)	<u> </u>		<u> </u>	├		1			<u> </u>	

DLU	Doesn't lock-up						55	1		I	
	Dead safe	2	1	1		4	- 55	I			
	Drops shell-magazine	2		bllon Dor	ormoneo	Donort					
	Doesn't trip latch		G	allery Per		Repon					
	Doesn't extract	9	3	Froot -	Test - Targe	3	78	1			
	Doesn't extract live round	5		5	2	1	10	1			
	Extractor drops shell	64	42	27	10	7			2		
	Ejector sticks back	4	10	5	10	1			2		
	Empty shell catches receiver	1	10			· ·					
	Extractor stems shell	•									
	Fires automatically										
	Follower binds								1		
	Fails to connect								2		
FCB	Fore-end cracked or broken								2		
	Follows-down	1									
	Fails to fire	4	4	4					1		
	Fails to feed from magazine			1					1		
	Flat firing pin		1								
	Fires on safe		I								
FPHB	Firing pin hits bbl										
	Firing pin hits inside rim						<u> </u>				
	Floor plate opens		2	24	11						
	Floor plate opens hard		<u> </u>	<u> </u>							
	Fires when safe is released		4								
	Follower tips	131	16	74		6					
GCSO	Gas cyl shot off	101	10	74							
GRSO	Guide ring shot off		1								
HBL	Heavy bolt lift	61	177	125		206					
	Heading mismatch-steps on case	01		12		200					
	High pressure ammo			12							
	Hard under extractor								10		
	Hard under rail	5		4							
	Int. latch out of position			9							
	Int. latch ret. Missing			Ű							
	Int. latch stud broken										
	Int. latch spring out of position										
	Jumps cartridge										
JL	Jumps latch										
JM	Jumps magazine	52	121	62		71					
JO	Jars off										
	Light blow					1			34	1	
	Magazine assembles hard			1		1	4		<u> </u>	1	
	Magazine cap shot off					1	i .			1	
	Magazine capacity wrong	1	3	2		1					
	Misfires (ammo)	· · · · · · · · · · · · · · · · · · ·		1		1	1				
	Magazine follower out of position			9		1	1			1	
	Magazine loose		1	1		İ					
	Magazine loads hard	1		1		1	1	4		1	
MRH	Magazine removes hard		5	12		İ		1			
	Opens hard	37	10	4		14					
	Over-rides	82	21	34	1	12	10				
	Pulls hard		7								
	Proof stamp illegible			1		1				1	
	Proof stamp missing			1		1	1			1	
	Rings and bulges on case					1				1	
	(Action) release doesn't work			1			1			1	
	Rings in chamber	308	196	41	24	21	1			1	
				1 11			I			I	

RIS	Ring in sholder	14								
RIS RS	Rim srem	14								
SBC	Stems bottom chambers	17	11 G	bllony Dor	ormance	Renart				
SBC SBE	Stems bbl extension			allery Perf		Tepon				
SCB	Stock cracked or broken			Proot -	Hest - Farge					
	Shell catches									
SHI	Short indent									
	Stems incline	34	3	11			2	2		
	Stems in chamber				1					
	shaves lead									
SLC	Stems left side of chamber			1						
SMOC	Stretch marks on case									
	Stem over-ride	1	10	1			17	1		
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber	8	1							
SRIC	Specific rings in chamber									
	shell stems carrier									
SSOC	Surface scratches on case									
STC	Stems top chamber		1							ļ]
SWE	Safety switch works too easily		1							
SWH	Safety switch works too hard									
	Safety ewitxh won't work									
	Tips down									
TU	Tips up									
	Trigger won't pull									
TWR	Trigger won't retract		10						 	l
	Uncoded	14	13	4		1				
	Extracts hard	4	4	7		4				
ЛПВ	Extractor hits bbl	I				1				
ні	High									
LO	Low									
	Left									
	Right									
	Doesn't Group	241	175	123	37	55				
	Front sight tipped	2		120						
	Rear sight tipped									
	Rear sight base raised									
	Front sight raised									
	Front sight loose									I
RSTL	Rear sight loose									I
MGPT-G	Missing parts at target									
	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
	Blows cases at proof									
	Barrel extension broken at proof									
	Blanked primer at proof									
	Barrel lug shot off at proof						1			ļ]
	Blown primer at proof						ļ			
	Barrel split at proof									ļ]
	Doesn't lock over shells at proof									ļ]
ESB-P	Ejector sticks back at proof							2		

FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof		1 G	allerv Per	formance	Report			
GCSO-P	Gas cylinder shot off at proof			,	Test - Targel		1		
GRSO-P	Guide ring shot off at proof			1 1001 -	rest - raige				
MCSO-P	Magazine cap shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl	2	1	1					
PP-P	Pierced primer at proof	14	23	35		33			
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions	6	15	15		4			

Summary	Total Test +	Proof Failures	23371								Month:	
		otal Rejected: Il Reject Rate:	3991 17.08									
		Shot:	10110	5214	338400f -	Test 447 arget	917	2011	636	30		
	Proof	Rejected:	97	34	76	0	17	0	0	0	0	0
	11001	Percent:	1.0	0.7	2.2	0.0	1.9	0.0	0.0	0.0		Ū
		Shot:	12620	3691	2249	377	835	2138	573	302	362	
	Test	Rejected:	1658	451	352	25	89	442	6	16	7	0
		Percent:	13.1	12.2	15.7	6.6	10.7	20.7	1.0	5.3	1.9	-
		Shot:	6863	3235	2202	380	833					
	Target	Rejected:	288	258	68	42	65	0	0	0	0	0
		Percent:	4.2	8.0	3.1	11.1	7.8					
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 M/L	
	A stisus binds		1		2							
AB ASFB	Action binds		1		2			5	4			
ASFB BABS	Action spring follower bind Bulge at body shoulder	15	10		2	<u>├</u>						
BABS	Burge at body shoulder Burr at chamber		210	167	59	6	4				<u> </u>	
BBMA	BBL-to-bolt misalignment		210	107	1		4					
BB	Bolt binds/catches		112	11	46	4	4					
BCOBS	Bolt catches on bolt stop					r i	r			1	1	
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases									3		
BHR	Bolt hits receiver					1						
BHS	Bolt plug hits safety switch	ו										
BLOP	Bar lock or disconnector o	out of position										
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazi	ine	1									
BWCD	Bolt won't cam down		8		1							
	Bolt won't close over full n		3	1	2	4						
CBS-F CBS-L	Shells catch on bbl suppo Shells catch on bbl suppo	rt-reeding										
CB3-L CC	Carrier catches on shells,											
CD	Case dented	inag,receiver										
СН	Closes hard		187	28	14	1	4					
СНАВ	Carrier hits action bar											
CLM	Can't laod magazine		1	2	1							
со	Cut-off											
CR	Cuts rim											
CS	Cases swell											
CTOG	Chamber torn or gouged		7		1							
CTP	Creepy trigger pull		1			ļļ		ļ				
CWSB	Cams wrong side of action	n bar				├		400				
DBB	Doesn't blow back	a.b.				┝─────		130				
DCS	Double click in safety swite	cn										
DCT DCU	Double click in trigger Doesn't close-up					├		33				
	Doesn't close-up Doesn't eject		19		2			<u> </u>		9		
DE DEL	Doesn't eject live round		2	4	2 3	├				+ ⁹		
DFB	Doesn't feed back		۷	+								
DFU	Doesn't feed up											
DLO	Doesn't lock open (after la	ast shell)							1			

	Decen't look up				1	1	157	1		1	
	Doesn't lock-up Dead safe	5	2			3	1				
	Drops shell-magazine	5			formonoo	Donart	· ·				
	Doesn't trip latch		G	allery Per		Repon					
	Doesn't extract	8	9	- ਸ ਾoof -	Test - Targe	t	25				
	Doesn't extract live round	0	2	1			25				
		134	6	7	1	4					
	Extractor drops shell		6								
	Ejector sticks back	32	6	2		3					
	Empty shell catches receiver										
	Extractor stems shell										
	Fires automatically										
	Follower binds										
	Fails to connect						3		1		
	Fore-end cracked or broken						-				
	Follows-down			4-			2			<u> </u>	
	Fails to fire	5	3	17		5	1			6	
	Fails to feed from magazine						1				
FFP	Flat firing pin										
FOS	Fires on safe										
	Firing pin hits bbl					l					
	Firing pin hits inside rim		15								
FPO	Floor plate opens	3	42	9							
FPOH	Floor plate opens hard		2								
	Fires when safe is released										
FT	Follower tips	206	11	8		7	1				
	Gas cyl shot off										
GRSO	Guide ring shot off										
	Heavy bolt lift	80	6	22		3					
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
	Hard under extractor										
	Hard under rail	19		12							
	Int. latch out of position										
	Int. latch ret. Missing										
ILSB	Int. latch stud broken										
ILSP	Int. latch spring out of position										
JCS	Jumps cartridge										
JL	Jumps latch										
JM	Jumps magazine	18	18	22			5				
	Jars off										
	Light blow								3		
MAH	Magazine assembles hard						35				
MCSO	Magazine cap shot off										
	Magazine capacity wrong		1	1							
MFA	Misfires (ammo)										
	Magazine follower out of position										
	Magazine loose					1					
	Magazine loads hard	1	1								
MRH	Magazine removes hard		1				2	1			
	Opens hard	55	18	19	1	2	1			1	
	Over-rides	138	11	3	1	<u> </u>	16			†	
	Pulls hard			† Ť	<u>'</u>	1	1 '			1	
	Proof stamp illegible						1				
	Proof stamp missing										<u> </u>
	Rings and bulges on case						1				
	(Action) release doesn't work	+									
	Rings in chamber	219	80	65	5	15				<u> </u>	
	ninge in chamber	213	00	1 00	1 5	1 15					

RIS	Ring in sholder	19				1			
RIS RS	Rim srem	10							
SBC	Stems bottom chambers	79	3 G	allery Perf	ormance	Renørt			
SBE	Stems bbl extension		- 0						
	Stock cracked or broken			+ Proot -	Hest - Harge				
	Shell catches								
SHI	Short indent								
	Stems incline	45	3	2	1	1			
SIC	Stems in chamber								
	shaves lead								
	Stems left side of chamber								
SMOC	Stretch marks on case								
	Stem over-ride	3	3				12		
SP	Stems port						1		
SR	Shoulder rough								
SRC	Stems right side of chamber	1							
SRIC	Specific rings in chamber								
	shell stems carrier								
SSOC	Surface scratches on case								
STC	Stems top chamber	4		4			7		
SWE	Safety switch works too easily								
SWH	Safety switch works too hard	7	2						
	Safety ewitxh won't work								
	Tips down								
TU	Tips up								
	Trigger won't pull								
	Trigger won't retract	2	4	14	1	2			
	Uncoded Extracts hard	2 10	<u>1</u> 6	11 12	1	2			
	Extractor hits bbl	10	0	12		/			
ні	High								
LO	Low	1	1						
	Left								
	Right								
	Doesn't Group	287	257	68	42	65			
	Front sight tipped								
	Rear sight tipped								
	Rear sight base raised								
FSTR	Front sight raised								
FSTL	Front sight loose								
RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof	1	1	1					
BBB	Barrel bracket cracked or broken at proof								
	Blows cases at proof								
	Barrel extension broken at proof								
	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
	Blown primer at proof								
	Barrel split at proof								
	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								

FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof		G	allerv Per	formance	Report			
GCSO-P	Gas cylinder shot off at proof			, ,	Test - Targel				
GRSO-P	Guide ring shot off at proof			11001-					
MCSO-P	Magazine cap shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl	1							
PP-P	Pierced primer at proof	36	28	69		14			
SCB-P	Stock cracked or broken at proof	1	1						
UNCM-P	Uncoded proof malfunctions	58	4	7		3			

Summary		Proof Failures	1026								Test Date:	11/27/2002
		otal Rejected: All Reject Rate:	120 11.70									
		Shot:	372	29	140		241	69				
	Proof	Rejected:	11	0	0	0	0	0	0	0	0	0
		Percent:	3.0	0.0	0.0		0.0	0.0				
		Shot:	468	50	91	27	328	51				
	Test	Rejected:	61	8	12	0	19	7	0	0	0	0
		Percent:	13.0	16.0	13.2	0.0	5.8	13.7				
		Shot:	123		73		123					
	Target	Rejected:	0	0	2	0	0	0	0	0	0	0
	rurget	Percent:	0.0		2.7		0.0					
CODE	MALFUNCTION	INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
AB	Action binds											
ASFB	Action spring follower bind	s										
BABS	Bulge at body shoulder											
BAC	Burr at chamber		1									
BBMA	BBL-to-bolt misalignment											
BB	Bolt binds/catches		5		2							
BCOBS	Bolt catches on bolt stop											
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS BLOP	Bolt plug hits safety switch Bar lock or disconnector o											
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magazi	ne										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full m	nagazine										
CBS-F	Shells catch on bbl suppor	rt-feeding										
CBS-L	Shells catch on bbl suppor	rt-loading										
CC	Carrier catches on shells,r											
CD	Case dented											
СН	Closes hard											
CHAB	Carrier hits action bar											
CLM	Can't laod magazine											
CO	Cut-off											
CR	Cuts rim											
CS	Cases swell											
CTOG	Chamber torn or gouged											
CTP	Creepy trigger pull											
CWSB	Cams wrong side of action	n bar										
DBB	Doesn't blow back											

DCTDouble closk in triggerIII	DCS	Double click in safety switch						
DCUDeent opent op	DCT							
DE Doesn'ejecti wound 1 2 1 Image: Construction of the construct								
DEL Desn't jest live round Image: state of the state	DE	Doesn't eject	1	2	1			
DFB Dest'test back Image: status in the sta	DEL	Doesn't eject live round						
DFU Doesn't lock open (after last shell) 6 DLO Doesn't lock vap 6 DLU Doesn't lock vap 6 DS Ded safe 1 6 DSM Drops shell-magazine 1 DXL Doesn't trip lach 1 1 DXL Doesn't trip lach 1 1 DXL Doesn't trip lach 1 1 DXL Doesn't trip lach 1 1 DXL Doesn't trip lach 1 1 DXL Doesn't trip lach 1 1 ESC Extractor flores band 1 1 ESC Extractor flores band 1 1 FG Fails to flore Fails to flore Fails to flore	DFB	Doesn't feed back						
D.O. Descrittock open (after last shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shell) Image: shell shel	DFU	Doesn't feed up						
DLU Desentiokup								
Ds Dead safe 1 Image: constraint of the second		Doesn't lock-up				6		
DSM Drops shell-magazine C I C I C I C I C I			1					
DTL Desent tig latch 21 1	DSM							
DX Desent extract live rund 1 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>								
DXL Doesn't act live round 1 Image: Constraint of the straint of th			21		1			
EDS Extractor drops shell 15 1 <td></td> <td></td> <td>1</td> <td></td> <td></td> <td></td> <td></td> <td></td>			1					
Espect Ejedor siteks back Image: Constraint of the section of the sectin of the section of the sectin of the sectin of the sectin			15		1			
ESCR Empty shell catches recover Image: constraint of the shell Image: constraint of the								
ESS Extractor stems shell Image: constraint of the saturation o	ESCR							
FA Fires automatically Image: connect in the second s		Extractor stems shell						
FB Follower binds Image: Constraint of the second	FA							
FC Fails to connect Image: connect constraint of the constraint	FB							
FCB Fore-end cracked or broken Image: Constraint of the second s	FC							
FD Follows-down Image: Constraint of the state of th		Fore-end cracked or broken						
FF Fails to free m	FD							
FFP Flat fining pin Image: constant of the second	FF	Fails to fire						
FFP Flat fining pin Image: constant of the second	FFM	Fails to feed from magazine						
FOS Fires on safe Image: constraint of the state of	FFP							
FPHB Firing pin hits bil Image: constraint of the spin of	FOS							
FPO Floor plate opens 8 8 1	FPHB	Firing pin hits bbl						
FPOH Floor plate opens hard Image: constraint opens Image: constraint opens hard								
FPOHFloor plate opens hardImage: constraint of the synthesis of the synthe		Floor plate opens		8				
FTFollower tips331111GCSOGas cyl shot off111111GRSOGuide ring shot off111111HBLHeavy bolt lift1111111HMSCHeading mismatch-steps on case1111111HPAHigh pressure ammo111111111HUEHard under extractor111	FPOH	Floor plate opens hard						
GCSOGas cyl shot offImage: constraint of the system		Fires when safe is released						
GRSOGuide ring shot offImage: shot offImage: shot offImage: shot offImage: shot offHBLHeavy bolt liftImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offHMSCHeading mismatch-steps on caseImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offHPAHigh pressure ammoImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offHVEHard under extractorImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offHURHard under railImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offHURHard under railImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offImage: shot offHURHard under railImage: shot offImage: shot off <td></td> <td>Follower tips</td> <td>3</td> <td></td> <td></td> <td></td> <td></td> <td></td>		Follower tips	3					
HBLHeavy bolt liftImage: constraint of the second se	GCSO	Gas cyl shot off						
HMSCHeading mismatch-steps on caseImage: constraint of the structureImage: constraint of the structure								
HPAHigh pressure ammoImage: constraint of the strate	HBL				1			
HUEHard under extractorImage: standard st	HMSC							
HURHard under railImage: constraint of positionImage: constraint	HPA							
HURHard under railImage: constraint of positionImage: constraint	HUE							
ILRMInt. latch ret. MissingImage: scale of the studie by the studi	HUR							
ILRMInt. latch ret. MissingImage: scale of the study brokenImage: scale of t	ILOP	Int. latch out of position						
ILSP Int. latch spring out of position Image: marked spring out of position Image:	ILRM	Int. latch ret. Missing						
JCS Jumps cartridge Image: Construction of the co								
JCS Jumps cartridge Image: Constraint of the stress of th		Int. latch spring out of position						
JL Jumps latch Image: Constraint of the state of the	JCS	Jumps cartridge						
JM Jumps magazine 2 1 JO Jars off	JL	Jumps latch						
JO Jars off	JM		2			1		
LB Light hlow	JO	Jars off						
	LB	Light blow						

MAH	Magazine assembles hard							
MCSO	Magazine cap shot off							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
ОН	Opens hard	1			1			
OR	Over-rides	4						
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber	2			2			
RIS	Ring in sholder							
RS	Rim srem							
SBC	Stems bottom chambers							
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
SCX	Shell catches							
SHI	Short indent							
SI	Stems incline							
SIC	Stems in chamber							
SL	shaves lead							
SLC	Stems left side of chamber	1						
SMOC	Stretch marks on case							
SOR	Stem over-ride	2	8		8			
SP	Stems port							
SR	Shoulder rough							
SRC	Stems right side of chamber							
SRIC	Specific rings in chamber							
SSC	shell stems carrier							
SSOC	Surface scratches on case							
STC	Stems top chamber							
SWE	Safety switch works too easily							
SWH	Safety switch works too hard							
SWW	Safety ewitxh won't work							
TD	Tips down							
TU	Tips up							
TWP	Trigger won't pull							
TWR	Trigger won't retract							
UNCN-T	Uncoded							
ХН	Extracts hard	1			4			
ХНВ	Extractor hits bbl							
н	High			 		 		

LO	Low						
	Left						
	Right						
	Doesn't Group		 2				
	Front sight tipped		 2				
	Rear sight tipped						
	Rear sight base raised				 		
	Front sight raised						
	Front sight loose						
	Rear sight loose				 		
MGPT-G	Missing parts at target				 	 	
UNCN-G	Uncoded nonconformity at target						
	Assembly incompleye at proof						
	Barrel bracket cracked or broken at proof						
	Blows cases at proof						
	Barrel extension broken at proof						
	Blanked primer at proof						
	Barrel lug shot off at proof						
BP-P	Blown primer at proof						
	Barrel split at proof						
DLOS-P	Doesn't lock over shells at proof						
ESB-P	Ejector sticks back at proof						
FCB-P	Fore-end cracked at proof						
	Fore-end shot off at proof						
	Fails to fire at proof						
	Gas cylinder shot off at proof						
	Guide ring shot off at proof						
	Magazine cap shot off at proof						
	Magnaflux stamp illegible on bbl						
	Magnaflux stamp missing on bbl						
	Pierced primer at proof	4					
	Stock cracked or broken at proof						
	Uncoded proof malfunctions	7					
	chooded proof manafielions	1					

Summary	Total Test +	Proof Failures	1094								Test Date:	10/31/2002
		Total Rejected: all Reject Rate:	113 10.33									
	0.01	Shot:	230	446	383	2	70	100	1			
	Proof	Rejected:	3	7	0	0	2	0	0	0	0	0
		Percent:	1.3	1.6	0.0	0.0	2.9	0.0	0.0			
		Shot:	234	507	211	26	15	89				
	Test	Rejected:	31	28	28	0	6	7	0	0	0	0
		Percent:	13.2	5.5	13.3	0.0	40.0	7.9				
		Shot:	135	49	193			4				
	Target	Rejected:	1	0	0	0	0	0	0	0	0	0
		Percent:	0.7	0.0	0.0			0.0				
CODE	MALFUNCTION	N INDEX	700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	7400 W/M
AB	Action binds											
ASFB	Action spring follower bin	ds										
BABS	Bulge at body shoulder											
BAC	Burr at chamber			1	5							
BBMA	BBL-to-bolt misalignment	[
BB BCOBS	Bolt binds/catches Bolt catches on bolt stop				4							
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switc	h										
BLOP	Bar lock or disconnector											
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magaz	zine										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full i		1									
CBS-F	Shells catch on bbl suppo	ort-feeding										
CBS-L	Shells catch on bbl suppo											
CC CD	Carrier catches on shells Case dented	,mag,receiver										
СН	Closes hard		1	4			2					
СНАВ	Carrier hits action bar		1	+			۷					
CLM	Can't laod magazine											
CO	Cut-off											
CR	Cuts rim											
CS	Cases swell											
CTOG	Chamber torn or gouged											
CTP	Creepy trigger pull											
CWSB	Cams wrong side of actio	on bar										
DBB	Doesn't blow back							1				

DCS	Double click in safety switch								
	Double click in trigger					1			
	Doesn't close-up								
	Doesn't eject					1			
DEL	Doesn't eject live round			2					
	Doesn't feed back			_					
	Doesn't feed up								
DLO	Doesn't lock open (after last shell)								
	Doesn't lock-up					2			
DS	Dead safe					_			
DSM	Drops shell-magazine								
	Doesn't trip latch								
DX	Doesn't extract	2	3			1			
	Doesn't extract live round								
EDS	Extractor drops shell	2	7	1		1	1		<u> </u>
ESB	Ejector sticks back	3	2	2	1	· · ·			<u> </u>
ESCR	Empty shell catches receiver	1 <u> </u>	-	-					
ESS	Extractor stems shell								
	Fires automatically								
	Follower binds								
	Fails to connect								
	Fore-end cracked or broken								
	Follows-down								
FF	Fails to fire								
FFM	Fails to feed from magazine								
FFP	Flat firing pin								
	Fires on safe								
FPHB	Firing pin hits bbl								
	Firing pin hits inside rim								
	Floor plate opens		2	1					
	Floor plate opens hard		2	1			1		
	Fires when safe is released								
	Follower tips		1						
GCSO	Gas cyl shot off		1						
GRSO	Guide ring shot off								
	Heavy bolt lift	10		6	4				
HMSC	Heading mismatch-steps on case	10		0	7				
HPA	High pressure ammo	+							╂────┤
	Hard under extractor	+							╂────┤
	Hard under rail	+							╂────┤
ILOP	Int. latch out of position	+							╂────┤
ILRM	Int. latch ret. Missing	+							╂────┤
ILSB	Int. latch stud broken	+							╂────┤
	Int. latch spring out of position	+						 	┨────┤
	Jumps cartridge	+							┨────┤
	Jumps latch	+							<u> </u>
JM	Jumps laten		1						<u> </u>
10 1M	Jars off								<u> </u>
LB	Light blow								

MAH	Magazine assembles hard							
MCSO	Magazine cap shot off							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position			5				
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
он	Opens hard							
OR	Over-rides	3	2					
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber							
RIS	Ring in sholder							
RS	Rim srem							
SBC	Stems bottom chambers	5						
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
SCX	Shell catches							
SHI	Short indent							
SI	Stems incline		2	1				
SIC	Stems in chamber							
SL	shaves lead							
SLC	Stems left side of chamber							
SMOC	Stretch marks on case							
SOR	Stem over-ride							
SP	Stems port							
SR	Shoulder rough							
SRC	Stems right side of chamber							
SRIC	Specific rings in chamber							
SSC	shell stems carrier							
SSOC	Surface scratches on case							
STC	Stems top chamber							
SWE	Safety switch works too easily							
SWH	Safety switch works too hard							
SWW	Safety ewitxh won't work							
TD	Tips down							
TU	Tips up							
TWP	Trigger won't pull							
TWR	Trigger won't retract							
UNCN-T	Uncoded							
ХН	Extracts hard	4	3	1				
ХНВ	Extractor hits bbl							
НІ	High					 		

	l ou							
	Low							
	Left					 	 	
	Right					 	 	
	Doesn't Group	1						
FSST	Front sight tipped							
	Rear sight tipped							
	Rear sight base raised							
	Front sight raised							
	Front sight loose							
	Rear sight loose							
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
	Assembly incompleye at proof							
	Barrel bracket cracked or broken at proof							
	Blows cases at proof							
	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
	Barrel split at proof							
	Doesn't lock over shells at proof							
	Ejector sticks back at proof							
	Fore-end cracked at proof							
	Fore-end shot off at proof							
	Fails to fire at proof							
	Gas cylinder shot off at proof							
	Guide ring shot off at proof							
	Magazine cap shot off at proof							
	Magnaflux stamp illegible on bbl							
	Magnaflux stamp missing on bbl							
	Pierced primer at proof		2	L				
	Stock cracked or broken at proof							
	Uncoded proof malfunctions	3	5		2			
		5						

Summary		Proof Failures	1155								Test Date:	9/30/2002
		Total Rejected:	236									
	Overa	all Reject Rate:	20.43									
		Shot:	341	198	36	3	461	28				
	Proof	Rejected:	3	3	1	0	0	0	0	0	0	0
		Percent:	0.9	1.5	2.8	0.0	0.0	0.0				
		Shot:	285	191	5		420	26		62	159	
	Test	Rejected:	60	34	2	0	110	2	0		6	0
	7631	Percent:	21.1	17.8	40.0		26.2	7.7		0.0	3.8	
		Shot:	198	115	68	26	169					
	Target	Rejected:	4	0	0	9	2	0	0	0	0	0
	Target	Percent:	2.0	0.0	0.0	34.6	1.2	-	-	-	-	-
CODE	MALFUNCTION		700 ADL	700 BDL	700 SS	700 Pol	Seven	7400	7600	Rimfire	700 ML	
CODL	MALI UNUTION			700 BDL	100 33	700101	Seven	7400	7000	TXIIIII C	700 ML	
AB	Action binds										<u> </u>	
ASFB	Action spring follower bind	ds									+ +	
BABS	Bulge at body shoulder											
BAC	Burr at chamber		4	2								
BBMA	BBL-to-bolt misalignment			1								
BB	Bolt binds/catches		2				6					
BCOBS	Bolt catches on bolt stop		_				-					
BCOE	Bolt catches on ejector											
BCOF	Bolt catches on follower											
BC	Blows cases											
BHR	Bolt hits receiver											
BHS	Bolt plug hits safety switch	n										
BLOP	Bar lock or disconnector of	out of position										
BLSO	Barrel lug shot off											
BPO	Bolt pulls out											
BSCO	Barrel support came out											
BSSM	Bolt stems shell in magaz	ine										
BWCD	Bolt won't cam down											
BWCFM	Bolt won't close over full n	nagazine	2									
CBS-F	Shells catch on bbl suppo	ort-feeding										
CBS-L	Shells catch on bbl suppo	ort-loading										
	Carrier catches on shells,	mag,receiver										
CD	Case dented											
СН	Closes hard		3	4			2				├	
CHAB	Carrier hits action bar						4				 -	
	Can't laod magazine						1				 -	
CO CR	Cut-off					I						
CR CS	Cuts rim Cases swell											
CS CTOG	Cases swell Chamber torn or gouged											
CTP												
CWSB	Creepy trigger pull Cams wrong side of action	n har										
DBB	Doesn't blow back	In Dal						1				
	LOGENT DIOW DACK							1				

DCS	Double click in safety switch							
	Double click in trigger							
	Doesn't close-up							
	Doesn't eject	8	4		 			
DEL	Doesn't eject live round	0	4		 		 	
	Doesn't feed back							
	Doesn't feed up							
DLO	Doesn't lock open (after last shell)							
DLU	Doesn't lock-up	_			 4			
	Dead safe				 1			
	Drops shell-magazine							
DTL	Doesn't trip latch							
	Doesn't extract	6	1		5	1		
DXL	Doesn't extract live round							
EDS	Extractor drops shell	20	2	1	7			
	Ejector sticks back	1			3			
ESCR	Empty shell catches receiver							
	Extractor stems shell							
	Fires automatically							
	Follower binds							
	Fails to connect							
	Fore-end cracked or broken							
	Follows-down							
	Fails to fire							
FFM	Fails to feed from magazine							
FFP	Flat firing pin							
	Fires on safe							
	Firing pin hits bbl							
	Firing pin hits inside rim							
	Floor plate opens				1			
	Floor plate opens hard							
	Fires when safe is released							
	Follower tips	3	1		1			
	Gas cyl shot off	-						
	Guide ring shot off							
	Heavy bolt lift	1			 57			
	Heading mismatch-steps on case							
	High pressure ammo							
	Hard under extractor							
HUR	Hard under rail	1			2			
	Int. latch out of position				<u> </u>			
	Int. latch ret. Missing							
	Int. latch stud broken							
	Int. latch spring out of position							
	lumps cartridge							
	Jumps cartridge	-						
	Jumps latch							┥
JM	Jumps magazine	2			 1			┥
	Jars off							┥
LB	Light blow							

MAH	Magazine assembles hard							
MCSO	Magazine cap shot off							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard							
ОН	Opens hard							
OR	Over-rides		11					
PH	Pulls hard							
PSI	Proof stamp illegible							
PSM	Proof stamp missing							
RBOC	Rings and bulges on case							
RDW	(Action) release doesn't work							
RIC	Rings in chamber	2						
RIS	Ring in sholder							
RS	Rim srem		2					
SBC	Stems bottom chambers							
SBE	Stems bbl extension							
SCB	Stock cracked or broken							
SCX	Shell catches							
SHI	Short indent							
SI	Stems incline				1			
SIC	Stems in chamber							
SL	shaves lead							
SLC	Stems left side of chamber							
SMOC	Stretch marks on case							
SOR	Stem over-ride		1		7			
SP	Stems port							
SR	Shoulder rough							
SRC	Stems right side of chamber							
SRIC	Specific rings in chamber							
SSC	shell stems carrier							
SSOC	Surface scratches on case							
STC	Stems top chamber							
SWE	Safety switch works too easily						1	
SWH	Safety switch works too hard							
SWW	Safety ewitxh won't work							
TD	Tips down							
TU	Tips up							
TWP	Trigger won't pull							
TWR	Trigger won't retract							
UNCN-T	Uncoded				L		5	
ХН	Extracts hard	5	5	1	15			
ХНВ	Extractor hits bbl							
НІ	High							

	1		1				1		1	
LO	Low									
LEFT	Left							 		
	Right							 		
DG	Doesn't Group	4			9	2				
FSST	Front sight tipped									
	Rear sight tipped									
	Rear sight base raised									
	Front sight raised									
FSTL	Front sight loose									
	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
	Barrel extension broken at proof									
	Blanked primer at proof									
	Barrel lug shot off at proof									
	Blown primer at proof									
	Barrel split at proof									
	Doesn't lock over shells at proof									
	Ejector sticks back at proof									
	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof		1							
GCSO-P	Gas cylinder shot off at proof									
	Guide ring shot off at proof									
	Magazine cap shot off at proof									
	Magnaflux stamp illegible on bbl									
	Magnaflux stamp missing on bbl			1						
	Pierced primer at proof									
	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions	3	2							
		5	<u> </u>							