Summary	Total Test + Pro		945								Test Date:					
_		al Rejected: Reject Rate:	115 12.17													totals
		Shot:	211	153	211		211	88	52			102				1028
	Proof	Rejected:	3	0	0	0	18	0	2	0	0	0	0	0	0	23
		Percent:	1.4	0.0	0.0	1	8.5	0.0	3.8			0.0	-	1		2.2
	Test	Shot: Rejected:	143 21	42 11	252 30	0	246 22	55 4	43	24 0	0	117 3	0	0	0	922 92
	rest	Percent:	14.7	26.2	11.9		8.9	7.3	2.3	0.0		2.6				10.0
		Shot:	48	4	21		26	6	4	2		12				123
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0	0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0	0 0.0
CODE						700 Delies			Model 7		7500		7400	7600	Dimfine	
CODE	MALFUNCTION IN	DEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Stainless	7400	7500	7600	Weathermaster	Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder				4											4
BAC	Burr at chamber															
BBMA	BBL-to-bolt misalignment															
BB	Bolt binds/catches			1	6			1	1							9
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
BC	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down						2									5
BWCFM	Bolt won't close over full mag	gazine	14				1									15
CD	Case dented															
сн	Closes hard			1	3		7									11
CLM	Can't laod magazine			1												1
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round			1												4

DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract	3			3					8
DXL	Doesn't extract live round	5			5					
EDS	Extractor drops shell			2	4					8
ESB	Ejector sticks back			1	4					1
ESCR	Empty shell catches receiver			1						;
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FD	Fails to connect									
FC	Fore-end cracked or broken									
FD	Follows-down					 				
FF	Fails to fire				 					
FF						 				
FOS	Flat firing pin									
	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens			3						3
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									
FT	Follower tips	1	1			 				5
GCSO	Gas cyl shot off						 			
HBL	Heavy bolt lift		1	1	2					4
HMSC	Heading mismatch-steps on case					 				
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine							3		3
JO	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
он	Opens hard									
OR	Over-rides	1		1						2
PH	Pulls hard									

PSI	Proof stamp illegible									
PSM	Proof stamp missing									
RBOC	Rings and bulges on case									
RDW	(Action) release doesn't work									I
RIC	Rings in chamber	2	1	9		1				13
RIS	Ring in sholder	2		0						
RS	Rim srem									
SBC	Stems bottom chambers									
SBE	Stems bbl extension									
SCB	Stock cracked or broken					1				1
SCX	Shell catches					1				,
SHI	Short indent									I
si	Stems incline				3					3
sic	Stems in chamber		2		5	1				3
SL	shaves lead		2			1				
SLC	Stems left side of chamber									
SMOC	Sterns left side of chamber Stretch marks on case									
SOR	Steren over-ride									
SP										 <u> </u>
	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									<u> </u>
SSOC	Surface scratches on case									<u> </u>
STC	Stems top chamber				 					<u> </u>
SWE	Safety switch works too easily									<u> </u>
SWH	Safety switch works too hard		1							1
sww	Safety ewitxh won't work				 					 ·
тр	Tips down									I
ти	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
ХН	Extracts hard		1							1
HI	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									

RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof			18					18
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions	3			2				õ

Summary	Total Test + Proof		429								Test Date:					
	Total F Overall Rej	Rejected: ect Rate:	40 9.32													totals
		Shot:	3	98	129		4			91					26	351
	Proof	Rejected:	0	0	5	0	0	0	0	0	0	0	0	0	0	5
		Percent:	0.0	0.0	3.9	1	0.0	<b></b>		0.0	1		1	I	0.0	1.4
	Test	Shot: Rejected:	5 0	161 27	132 0	0	2	0	0	98 8	0	0	0	0	26 0	424 35
	1051	Percent:	0.0	16.8	0.0	-	0.0	•	•	8.2	-	-	-	-	0.0	8.3
		Shot:		9	5					6						20
	Target	Rejected: Percent:	0	0 0.0	0 0.0	0	0	0	0	0 0.0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INDE	x	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ввма	BBL-to-bolt misalignment															
BB	Bolt binds/catches			2												2
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
внѕ	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of p	position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazi	ine		2												Z
СD	Case dented															
сн	Closes hard			2												5
СГМ	Can't laod magazine			1												1
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
DFB	Doesn't feed back			1											
DFU	Doesn't feed up								5						5
DLO	Doesn't lock open (after last shell)								2						2
DLU	Doesn't lock-up								1						1
DS	Dead safe		1												4
DX	Doesn't extract		1												1
DXL	Doesn't extract live round														
EDS	Extractor drops shell														
ESB	Ejector sticks back		1												1
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens		3												3
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
нмѕс	Heading mismatch-steps on case														
HPA	High pressure ammo														
HUR	Hard under rail														
JCS	Jumps cartridge														
JM	Jumps magazine		1												1
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard			1											
мсм	Magazine capacity wrong														
MFA	Misfires (ammo)			1											
MFOP	Magazine follower out of position			1											
мL	Magazine loose			1											
MLH	Magazine loads hard														
MRH	Magazine removes hard														
он	Opens hard														

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
OR	Over-rides		3												3
PH	Pulls hard														Í
PSI	Proof stamp illegible														Í
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber		9												9
RIS	Ring in sholder														Í
RS	Rim srem														Í
SBC	Stems bottom chambers														
SBE	Stems bbl extension														Í
SCB	Stock cracked or broken														Í
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														[]
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														[]
SOR	Stem over-ride														
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														(]
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety ewitxh won't work														[]
тр	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
хн	Extracts hard		1												1
ні	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
RSTT	Rear sight tipped														
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DLOS-P	Doesn't lock over shells at proof														
ESB-P	Ejector sticks back at proof														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof			5											õ
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Test + Proof		744								Test Date:					
	Total R Overall Reje	ejected: ect Rate:	64 8.60													totals
		Shot:		406	54	1	57			173	I			1		631
	Proof	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	0
		Percent:		0.0	0.0	0.0	0.0	1	1	0.0			1	1		0.0
	Test	Shot: Rejected:	1 0	543 56	1 0	0	28 2	0	0	171 6	0	0	0	0	0	744 64
	rest	Percent:	0.0	10.3	0.0		7.1			3.5						8.6
		Shot:		50			3			16						69
	Target	Rejected: Percent:	0	0 0.0	0	0	0 0.0	0	0	0 0.0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INDEX	(	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds									1						1
BABS	Bulge at body shoulder															
BAC	Burr at chamber			5												õ
ввма	BBL-to-bolt misalignment															
вв	Bolt binds/catches			19			2									21
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of po	osition														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazir	ne														
CD	Case dented															
сн	Closes hard															
СГМ	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															

DFB	Doesn't feed back							
DFU	Doesn't feed up							
DLO	Doesn't lock open (after last shell)				2			2
DLU	Doesn't lock-up				2			2
DS	Dead safe							
DX	Doesn't extract							
DXL	Doesn't extract live round							
EDS	Extractor drops shell	9						9
ESB	Ejector sticks back	9						9
ESCR	-	9						<u> </u>
ESS	Empty shell catches receiver Extractor stems shell			 	 			
FA	Fires automatically							
FB	Follower binds							
FD				 				
FC	Fails to connect							
	Fore-end cracked or broken							
FD	Follows-down							
FF	Fails to fire							
FFP	Flat firing pin				 	 		
FOS	Fires on safe							
FPHB	Firing pin hits bbl							
FPHI	Firing pin hits inside rim							
FPO	Floor plate opens	3						3
FPOH	Floor plate opens hard							
FSR	Fires when safe is released							
FT	Follower tips							
GCSO	Gas cyl shot off							
HBL	Heavy bolt lift	3						3
HMSC	Heading mismatch-steps on case							
НРА	High pressure ammo							
HUR	Hard under rail							
JCS	Jumps cartridge							
JM	Jumps magazine	2						2
JO	Jars off							
LB	Light blow							
МАН	Magazine assembles hard							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard				1			1
он	Opens hard							
OR	Over-rides							
РН	Pulls hard							

PSI	Proof stamp illegible								
	Proof stamp missing	<u> </u>							
	Rings and bulges on case	<u>                                     </u>	5						ō
	(Action) release doesn't work	<u> </u>	5						, ř
		łł							
	Rings in chamber								
	Ring in sholder	<u> </u>							
	Rim srem	<b>├</b> ───┤							il
	Stems bottom chambers	<b> </b>							i
	Stems bbl extension	ł – – – ł					 		
	Stock cracked or broken	<b> </b>				 	 	 	i
	Shell catches								
	Short indent								 i
	Stems incline								i
	Stems in chamber		1						1
	shaves lead								
SLC	Stems left side of chamber								<u> </u>
SMOC	Stretch marks on case								
SOR	Stem over-ride								1
SP	Stems port								i i
SR	Shoulder rough								
SRC	Stems right side of chamber								
SRIC	Specific rings in chamber								
SSOC	Surface scratches on case								
STC	Stems top chamber								
SWE	Safety switch works too easily								
SWH	Safety switch works too hard								
SWW	Safety ewitxh won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								[]
UNCN-T	Uncoded								í
ХН	Extracts hard								· · · · · · · · · · · · · · · · · · ·
ні	High	<u>├</u>							
LO	Low								
	Left								
	Right								
	Doesn't Group								
	Front sight tipped								
	Rear sight tipped	<u>├</u>							
	Rear sight base raised	<u>├</u>							·
	Front sight raised	├							·
	Front sight loose	├							
FOIL	r tonit signit loose								<u>.                                    </u>

RSTL	Rear sight loose							
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
AI-P	Assembly incompleye at proof							
BBB	Barrel bracket cracked or broken at proof							
BC-P	Blows cases at proof							
BEB-P	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DLOS-P	Doesn't lock over shells at proof							
ESB-P	Ejector sticks back at proof							
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof							
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions							

Summary	Total Test + Pre		1143								Test Date:					
		al Rejected: Reject Rate:	141 12.34													totals
	evenus,	Shot:	317	419	120	16		35	20			139			27	1033
	Proof	Rejected:	3	48	1	0	0	0	0	0	0	16	0	0	0	63
		Percent:	0.9	11.5	0.8	0.0		0.0	0.0			11.5	_		0.0	6.2
	<b>-</b> /	Shot:	416 42	387 10	100 6	23 0	0	19 0	0	0	0	103 9	0	0	27 6	1075 73
	Test	Rejected: Percent:	42	2.6	6.0	0.0	U	0.0	U	U	U	9 8.7	0	0	22.2	8.8
		Shot:	39	41	11	23		3				13		1		130
	Target	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	0
		Percent:	0.0	0.0	0.0	0.0		0.0				0.0				0.0
CODE	MALFUNCTION IN	DEX	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds											3				3
BABS	Bulge at body shoulder															1
BAC	Burr at chamber															ļļ
ввма	BBL-to-bolt misalignment															<b>├</b> ───┦
вв	Bolt binds/catches		2	2	1											\$
BCOBS	Bolt catches on bolt stop															<b>!</b>
BCOF	Bolt catches on follower															1
вс	Blows cases															<b>!</b>
BHR	Bolt hits receiver															<u> </u>
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														<u> </u>
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															1
BSSM	Bolt stems shell in magazine										1					1
BWCD	Bolt won't cam down															1
BWCFM	Bolt won't close over full mag	gazine														1
CD	Case dented															1
сн	Closes hard														1	1
CLM	Can't laod magazine				1											1
со	Cut-off															
CR	Cuts rim															
cs	Cases swell														1	1
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject											1				i
DEL	Doesn't eject live round															+

DFB	Doesn't feed back										
DFU	Doesn't feed up									3	3
DLO	Doesn't lock open (after last shell)									, , , , , , , , , , , , , , , , , , ,	×
DLU	Doesn't lock-up										
DS	Dead safe	10									10
DX	Doesn't extract	10									
DXL	Doesn't extract live round										
EDS	Extractor drops shell									1	1
ESB	Ejector sticks back									· ·	•
ESCR	Empty shell catches receiver										
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds										
FD	Fails to connect										
FC	Fore-end cracked or broken						 				
FD	Follows-down										
FF	Fails to fire										
FFP	Flat firing pin						 				
FOS	Fires on safe						 				
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens		3								3
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	19									13
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift	3		1							4
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUR	Hard under rail										
JCS	Jumps cartridge										
JM	Jumps magazine	1		1				1			3
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard							4			4
MCW	Magazine capacity wrong			1							1
MFA	Misfires (ammo)										
MFOP	Magazine follower out of position										
ML	Magazine loose										
MLH	Magazine loads hard										
MRH	Magazine removes hard										
он	Opens hard		1								1
OR	Over-rides		1								1
PH	Pulls hard										

PSI	Proof stamp illegible										
PSM	Proof stamp missing										
RBOC	Rings and bulges on case										
RDW	(Action) release doesn't work										
RIC	Rings in chamber	1	1	1							3
RIS	Ring in sholder	1	1	'							
RIS	Rim srem										I
SBC		3									3
	Stems bottom chambers	3			 						~~~
SBE	Stems bbl extension										<u> </u>
SCB	Stock cracked or broken										
SCX	Shell catches										<u> </u>
SHI	Short indent										<u> </u>
SI	Stems incline	2					 				Ž
SIC	Stems in chamber		1								1
SL	shaves lead										ļ
SLC	Stems left side of chamber										
SMOC	Stretch marks on case										
SOR	Stem over-ride										
SP	Stems port										ļ
SR	Shoulder rough										
SRC	Stems right side of chamber										
SRIC	Specific rings in chamber										
SSOC	Surface scratches on case										
STC	Stems top chamber										l
SWE	Safety switch works too easily		1								1
SWH	Safety switch works too hard										1
SWW	Safety ewitxh won't work										
TD	Tips down										
TU	Tips up										
TWP	Trigger won't pull										
TWR	Trigger won't retract										
UNCN-T	Uncoded										
хн	Extracts hard	1									1
н	High										
LO	Low										
LEFT	Left										
RIGHT	Right										
DG	Doesn't Group										
FSST	Front sight tipped										I
RSTT	Rear sight tipped										I
RSBR	Rear sight base raised										I
FSTR	Front sight raised										I
FSTL	Front sight loose					L					I
	r font signt loose										<u> </u>

RSTL	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DLOS-P	Doesn't lock over shells at proof									
ESB-P	Ejector sticks back at proof							14		14
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof	2	48					1		51
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions	1		1				1		3

Summary	Total Test + Proof Total F	Failures Rejected:	743 109								Test Date:					
	Overall Rej		14.67													tota/s
		Shot:	234	206	104	62		7		20		14			28	875
	Proof	Rejected: Percent:	0 0.0	0 0.0	36 34.6	0 0.0	0	0 0.0	0	0 0.0	0	0 0.0	0	0	0 0.0	36 5.3
		Shot:	355	151 10	89 10	27 5				41		16 0			28	707
	Test	Rejected: Percent:	35 9.9	6.6	11.2	18.5	0	0	0	2 4.9	0	0.0	0	0	11 39.3	10.3
	<b>-</b> .	Shot: Rejected:	35 0	17 0	31 0	22 0	0	0	0	4 0	0	2	0	0	0	111 0
	Target	Percent:	0.0	0.0	0.0	0.0	0	0	0	0.0	0	0.0	0	U	0	0.0
CODE	MALFUNCTION INDE	x	700 ADL	700 BDL	700 SS	700 Police	700 ML	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds														1	1
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ввма	BBL-to-bolt misalignment															
BB	Bolt binds/catches		13	4	2											13
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of p	position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazi	ine	8		1											9
CD	Case dented															
сн	Closes hard		6	1	2											9
CLM	Can't laod magazine				3											3
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject				1											ł
DEL	Doesn't eject live round															

DFB	Doesn't feed back							-			
DFU	Doesn't feed up						 			1	1
DLO	Doesn't lock open (after last shell)					 	 			· ·	· · · · · · · · · · · · · · · · · · ·
											1
	Doesn't lock-up						1				
DS	Dead safe	1									1
DX	Doesn't extract						 1				1
DXL	Doesn't extract live round								 		
EDS	Extractor drops shell	1								6	7
ESB	Ejector sticks back										ļ
ESCR	Empty shell catches receiver										
ESS	Extractor stems shell										I
FA	Fires automatically					 					
FB	Follower binds										
FC	Fails to connect										
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire										
FFP	Flat firing pin										l .
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens		1								1
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	3									3
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift			1							1
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUR	Hard under rail				5					3	8
JCS	Jumps cartridge										
JM	Jumps magazine		1								1
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
мсм	Magazine capacity wrong										
MFA	Misfires (ammo)										
MFOP	Magazine follower out of position										
ML	Magazine loose										I
MLH	Magazine loads hard										I
MRH	Magazine removes hard										I
он	Opens hard										I
OR	Over-rides		2				L		L		2
РН	Pulls hard		2								
	r uiis fidi u										

PSI	Proof stamp illegible			1					1	
	Proof stamp missing									i1
	Rings and bulges on case									<u> </u>
										íI
	(Action) release doesn't work Rings in chamber									<u> </u>
										ÍI
	Ring in sholder									í I
	Rim srem									í I
	Stems bottom chambers									<b> </b>
	Stems bbl extension									<b> </b>
	Stock cracked or broken					 	 			<b> </b>
	Shell catches									Í
L	Short indent									ļ
	Stems incline	3								3
	Stems in chamber									ļ
	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									ĺ
SP	Stems port									ĺ
SR	Shoulder rough									(
SRC	Stems right side of chamber									ĺ
SRIC	Specific rings in chamber									í l
SSOC	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety ewitxh won't work									
TD	Tips down									
ΤU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
хн	Extracts hard		1							1
н	High									
LO	Low									
	Left									
	Right									
	Doesn't Group									
	Front sight tipped									I
	Rear sight tipped									
	Rear sight base raised									<u>├</u> ┨ :
L										<u>├</u> ┨
	Front sight raised									<u>├</u> ┨
FSTL	Front sight loose									<u> </u>

RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof		19						19
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions		17						17

Summary	Total Test + Pro	oof Failures	1069								Test Date:					ſ
_	Tota	al Rejected: Reject Rate:	65 6.08													totals
	Overain	Shot:	317	44	19		122	8	2	75		2		3	48	640
	Proof	Rejected:	0	0	0	0	0	0	0	2	0	0	0	0	0	2
		Percent:	0.0	0.0	0.0		0.0	0.0	0.0	2.7		0.0		0.0	0.0	0.3
		Shot:	693	114 10			53		0	159	0	0	0		48	1067
	Test	Rejected: Percent:	42 6.1	10 8.8	0	0	3 5.7	0	0	7 4.4	0	0	0	0	1 2.1	63 5.9
		Shot:	44	12			6			16						78
	Target	Rejected: Percent:	0 0.0	0 0.0	0	0	0 0.0	0	0	0 0.0	0	0	0	0	0	0 0.0
		1 6/66/11.	0.0	0.0			0.0			0.0			1			
CODE	MALFUNCTION IN	DEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															<u> </u>
BABS	Bulge at body shoulder															
BAC	Burr at chamber		4													4
ввма	BBL-to-bolt misalignment															
вв	Bolt binds/catches		6													8
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine														
CD	Case dented															
сн	Closes hard		1													1
CLM	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged		2													2
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back									1						1
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round		1													1

DFB	Doesn't feed back										
DFU	Doesn't feed up										
DLO	Doesn't lock open (after last shell)										
DLU	Doesn't lock-up										
DS	Dead safe										
DX	Doesn't extract		1		1						2
DXL	Doesn't extract live round										
EDS	Extractor drops shell	1									1
ESB	Ejector sticks back	1	2								2
ESCR	Empty shell catches receiver		2								
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds										
FD	Fails to connect			 		 				1	1
FC	Fore-end cracked or broken									1	· · · · · · · · · · · · · · · · · · ·
FCB											
FD	Follows-down			 							
	Fails to fire		1								1
FFP	Flat firing pin					 					
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens		5		2						?
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	5									\$
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift	2									2
HMSC	Heading mismatch-steps on case										
НРА	High pressure ammo										
HUR	Hard under rail										
JCS	Jumps cartridge										
JM	Jumps magazine										
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
MCW	Magazine capacity wrong		1								1
MFA	Misfires (ammo)										
MFOP	Magazine follower out of position										
ML	Magazine loose										
MLH	Magazine loads hard										
MRH	Magazine removes hard										
он	Opens hard										
OR	Over-rides						5				ş
PH	Pulls hard										

PSI	Proof stamp illegible								1	
	Proof stamp missing									í1
	Rings and bulges on case									<u> </u> ]
-	(Action) release doesn't work									íI
	Rings in chamber									<u> </u>
										íI
	Ring in sholder									í I
	Rim srem									í I
	Stems bottom chambers									<b> </b> ]
	Stems bbl extension									<b> </b> ]
	Stock cracked or broken					 				<b> </b>
	Shell catches									ÍI
	Short indent									ļ
	Stems incline	20								20
	Stems in chamber									ļ
	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride					1				ŕ
SP	Stems port									ĺ
SR	Shoulder rough									(
SRC	Stems right side of chamber									Í
SRIC	Specific rings in chamber									í l
SSOC	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety ewitxh won't work									
TD	Tips down									
ΤU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
	Uncoded									
хн	Extracts hard									
н	High									
	Low									
	Left									
	Right									iI
	Doesn't Group									
	Front sight tipped									
	Rear sight tipped									1
	Rear sight base raised									I
	Front sight raised									
										┟────┨
	Front sight loose		1	1	1	1				<u>í                                    </u>

RSTL	Rear sight loose							
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
AI-P	Assembly incompleye at proof							
BBB	Barrel bracket cracked or broken at proof							
BC-P	Blows cases at proof							
BEB-P	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DLOS-P	Doesn't lock over shells at proof							
ESB-P	Ejector sticks back at proof				2			2
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof							
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions							

Summary	Total Test + Proo	f Failures	1114								Test Date:					
_	Total Overall Re	Rejected: iect Rate:	69 6.19													totals
	ereran rej	Shot:	170	236	139		170		84	22		113			21	985
	Proof	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	0
		Percent:	0.0	0.0	0.0		0.0		0.0	0.0		0.0	-		0.0	0.0
	<b>T</b> = = 4	Shot: Rejected:	405 23	311 <i>15</i>	177 15	0	0	0	0	25 5	0	175 <i>11</i>	0	0	21 0	1114 69
	Test	Percent:	5.7	4.8	8.5	0	0	0	U	20.0	0	6.3	0	U	0.0	8.2
		Shot:	52	31	17					3		20				123
	Target	Rejected:	0 0.0	0 0.0	0 0.0	0	0	0	0	0 0.0	0	0 0.0	0	0	0	0 0.0
		Percent:	0.0	0.0	0.0	1				0.0		0.0				5.0
CODE	MALFUNCTION INDE	≡x	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds											1				1
BABS	Bulge at body shoulder															
BAC	Burr at chamber				2											ž
ввма	BBL-to-bolt misalignment															
BB	Bolt binds/catches			1												9
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magaz	zine		8	1											435
CD	Case dented															
сн	Closes hard		10													10
CLM	Can't laod magazine			1	1											Ž
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
СТОС	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back									1						1
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject			1												ŕ
DEL	Doesn't eject live round															

DFB	Doesn't feed back									
DFU	Doesn't feed up									·1
DLO	Doesn't lock open (after last shell)						4			4
DLU	Doesn't lock-up									· · · · · · · · · · · · · · · · · · ·
DS	Dead safe									
DX	Doesn't extract									
DXL	Doesn't extract live round									
EDS	Extractor drops shell									
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FD	Fails to connect				 					
FC	Fore-end cracked or broken									
FCB FD										
FD	Follows-down				 	 				 
	Fails to fire									
FFP	Flat firing pin									<b></b>
FOS	Fires on safe				 					
FPHB	Firing pin hits bbl									ļ]
FPHI	Firing pin hits inside rim									·
FPO	Floor plate opens		3	6						9
FPOH	Floor plate opens hard									
FSR	Fires when safe is released					 				
FT	Follower tips	4								4
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift	1								1
HMSC	Heading mismatch-steps on case									
НРА	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine	2	1	1				1		5
JO	Jars off									
LB	Light blow									l .
МАН	Magazine assembles hard							4		4
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard							5		÷
он	Opens hard									[]
OR	Over-rides	3								3
РН	Pulls hard									[]

PSI	Proof stamp illegible								
PSM	Proof stamp missing								
RBOC	Rings and bulges on case								
RDW	(Action) release doesn't work								
RIC	Rings in chamber	3	3						6
RIS	Ring in sholder	5	5						L Š
RS	Rim srem								
SBC	Stems bottom chambers								
SBE	Stems bbl extension								
SCB									
SCK	Stock cracked or broken								l
	Shell catches								
SHI	Short indent								
SI	Stems incline								<b>├</b> ──── <b>│</b>
SIC	Stems in chamber								<b>├────</b> ┤
SL	shaves lead								<b>├</b> ──── <b>│</b>
SLC	Stems left side of chamber								<b>├────</b> ┤
SMOC	Stretch marks on case								<b> </b>
SOR	Stem over-ride								<b> </b>
SP	Stems port								
SR	Shoulder rough								
SRC	Stems right side of chamber								L
SRIC	Specific rings in chamber								
SSOC	Surface scratches on case								
STC	Stems top chamber								
SWE	Safety switch works too easily								
SWH	Safety switch works too hard								
SWW	Safety ewitxh won't work								
TD	Tips down								
тυ	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
UNCN-T	Uncoded								
ХН	Extracts hard		1						1
ні	High								
LO	Low								
LEFT	Left								
RIGHT	Right								
DG	Doesn't Group								
FSST	Front sight tipped								
RSTT	Rear sight tipped								
RSBR	Rear sight base raised								
FSTR	Front sight raised								
FSTL	Front sight loose								<b> </b>

RSTL	Rear sight loose							
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
AI-P	Assembly incompleye at proof							
BBB	Barrel bracket cracked or broken at proof							
BC-P	Blows cases at proof							
BEB-P	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DLOS-P	Doesn't lock over shells at proof							
ESB-P	Ejector sticks back at proof							
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof							
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions							

Summary	Total Test + Pre		1056								Test Date:					· · · · · · · · · · · · · · · · · · ·
		al Rejected: Reject Rate:	185 17.52													totals
	0.000	Shot:	323	92	83	41	134	125		156		2			35	991
	Proof	Rejected:	9	28	1	11	2	18	0	1	0	0	0	0	0	70
		Percent:	2.8	30.4	1.2	26.8	1.5	14.4		0.6		0.0	-		0.0	7.1
	74	Shot: Rejected:	422 37	79 3	65 6	7	165 7	63 12	0	150 43	0	0	0	0	35 0	986 115
	Test	Percent:	8.8	3.8	9.2	100.0	4.2	19.0	0	28.7	0	U	0	0	0.0	11.7
		Shot:	35	8	8		17	3		9						80
	Target	Rejected:	0 0.0	0 0.0	0 0.0	0	0 0.0	0 0.0	0	0	0	0	0	0	0	0 0.0
		Percent:	0.0	0.0	0.0		0.0	0.0		0.0	1	<b>1</b>				0.0 T
CODE	MALFUNCTION IN	DEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
BBMA	BBL-to-bolt misalignment															
вв	Bolt binds/catches		11	1			1	1								14
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine														
CD	Case dented															
сн	Closes hard		5		1		1									?
CLM	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
DFB	Doesn't feed back														
DFU	Doesn't feed up														Í
DLO	Doesn't lock open (after last shell)														Í
DLU	Doesn't lock-up								3						3
DS	Dead safe														ĺ
DX	Doesn't extract														Í
DXL	Doesn't extract live round														
EDS	Extractor drops shell					1									4
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell													(	Í
FA	Fires automatically														
FB	Follower binds													[	
FC	Fails to connect														
FCB	Fore-end cracked or broken								2					[]	2
FD	Follows-down														
FF	Fails to fire													(	
FFP	Flat firing pin														
FOS	Fires on safe													· · · · · ·	
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim													()	
FPO	Floor plate opens														
FPOH	Floor plate opens hard													[]	
FSR	Fires when safe is released														
FT	Follower tips													(	
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift	11												(	11
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo													()	
HUR	Hard under rail	3												[]	3
JCS	Jumps cartridge													[]	
JM	Jumps magazine		1	1			4								6
JO	Jars off													[]	
LB	Light blow														
МАН	Magazine assembles hard													· · · · · ·	
мсм	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard													[]	
он	Opens hard			3											3

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
OR	Over-rides	1				2									3
PH	Pulls hard														
PSI	Proof stamp illegible														ĺ
PSM	Proof stamp missing														Í
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														ĺ
RIC	Rings in chamber	1			7	1									9
RIS	Ring in sholder														
RS	Rim srem														Í
SBC	Stems bottom chambers	3		1					6						10
SBE	Stems bbl extension														Í
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline	2													2
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber		1				6		5						12
SMOC	Stretch marks on case														
SOR	Stem over-ride						1		21						22
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
ssoc	Surface scratches on case														
STC	Stems top chamber					1			6						7
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety ewitxh won't work														
тр	Tips down														
ΤU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
хн	Extracts hard														
н	High														
LO	Low														
LEFT	Left														
RIGHT	Right	1													
DG	Doesn't Group	1													
FSST	Front sight tipped														

CODE	MALFUNCTION INDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
RSTT	Rear sight tipped														
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DLOS-P	Doesn't lock over shells at proof														
ESB-P	Ejector sticks back at proof								1						1
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof		26				17								43
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions	9	2	1	11	2	1								26

Summary	Total Test + Pro		836								Test Date:					
		l Rejected: eject Rate:	117 14.00													totals
		Shot:	125	72	50		135	174		99						635
	Proof	Rejected:	11	0	1	0	0	7	0	0	0	0	0	0	0	19
		Percent:	8.8 260	0.0	2.0 68		0.0	4.0 223	1	0.0	T	1		1		2.9 817
	Test	Shot: Rejected:	36	8	19	0	0	12	0	23	0	0	0	0	0	817 98
	1050	Percent:	13.8	5.3	27.9			5.4		20.0						12.0
		Shot:	21	15	7		_	22		8			_			73
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0	0	0 0.0	0	0 0.0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION IN		700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7	7400	7500	7600	7400	7600	Rimfire	totals
			NOU ADE	NOU BBE	/00 00	7001 01100	AND ODE	Model /	Stainless	7400	/000	7000	Weathermaster	Weathermaster		WEIG
АВ	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
BBMA	BBL-to-bolt misalignment															
BB	Bolt binds/catches							2								2
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower		1													1
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out o	of position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	azine			3											3
CD	Case dented															
сн	Closes hard		27	1	2											30
CLM	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged							5								÷
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action ba	ır														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															

DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract			4			1			÷
DXL	Doesn't extract live round			4			1			<u> </u>
EDS	Extractor drops shell									iI
ESB						1				1
ESCR	Ejector sticks back									3
	Empty shell catches receiver Extractor stems shell									<b> </b>
ESS										<b> </b>
FA FB	Fires automatically									 
	Follower binds									
FC	Fails to connect						7			7
FCB	Fore-end cracked or broken						/			· · · ·
FD	Follows-down									<b> </b>
FF	Fails to fire									l
FFP	Flat firing pin								 	<b> </b>
FOS	Fires on safe									ļ
FPHB	Firing pin hits bbl									Í
FPHI	Firing pin hits inside rim									ļ
FPO	Floor plate opens									ļ
FPOH	Floor plate opens hard									ļ
FSR	Fires when safe is released									
FT	Follower tips	1					5			8
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift	3		7						10
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine	2	1				5			Š
JO	Jars off									1
LB	Light blow									1
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong									Í
MFA	Misfires (ammo)									Í
MFOP	Magazine follower out of position									Í
ML	Magazine loose									
MLH	Magazine loads hard						1			1
MRH	Magazine removes hard						1			1
он	Opens hard									
OR	Over-rides		6			2	1			9
РН	Pulls hard									

PSI	Proof stamp illegible								1	
						 				<u> </u> ]
	Proof stamp missing					 				<u> </u> ]
-	Rings and bulges on case									l
	(Action) release doesn't work									í
	Rings in chamber									<b> </b>
	Ring in sholder									<b> </b> ]
	Rim srem					 				<b> </b>
	Stems bottom chambers									Í
	Stems bbl extension									Í
	Stock cracked or broken									ļ]
	Shell catches									ļ]
SHI	Short indent									
SI	Stems incline									
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									ĺ
SMOC	Stretch marks on case									Í
SOR	Stem over-ride		3			1				4
SP	Stems port									Í
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber	2				1				3
SWE	Safety switch works too easily									
SWH	Safety switch works too hard				2					ž
sww	Safety ewitxh won't work									
тр	Tips down									
тυ	Tips up									
	Trigger won't pull									
	Trigger won't retract									
	Uncoded									
хн	Extracts hard									
н	High									
LO	Low									i1
	Left									i1
	Right									
	Doesn't Group									
	Front sight tipped									
	Rear sight tipped									
	Rear sight base raised									<u>├</u> ┨ :
										<u>├</u> ┨
	Front sight raised									<u>├</u> ┨
FSTL	Front sight loose									<u></u>

RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof	4	1		5				10
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions	7			2				53

Summary	Total Test + Pr	roof Failures	743								Test Date:					
_	Tot	tal Rejected: Reject Rate:	33 4.44													totals
		Shot:	2	577	84		39			5	52	2				761
	Proof	Rejected:	0	7	2	0	0	0	0	0	0	0	0	0	0	8
		Percent:	0.0	1.2	2.4		0.0			0.0	0.0	0.0	-			1.2
	Test	Shot: Rejected:	0	644 17	10 1	0	7 0	0	0	7 0	52 4	14 2	0	0	0	734 24
	Test	Percent:	Ŭ	2.6	10.0	Ŭ	0.0	0	Ũ	0.0	7.7	14.3	Ū	Ū	Ū	3.3
		Shot:		63	1						3					67
	Target	Rejected: Percent:	0	0 0.0	0 0.0	0	0	0	0	0	0 0.0	0	0	0	0	0 0.0
CODE	MALFUNCTION IN	NDEX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds										1					1
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ввма	BBL-to-bolt misalignment															
BB	Bolt binds/catches			2												2
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine	e														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full ma	igazine		2												2
CD	Case dented															
сн	Closes hard				1											4
CLM	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	bar														
DBB	Doesn't blow back										1					1
DCS	Double click in safety switch	1														
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															

DFB	Doesn't feed back							
DFU	Doesn't feed up							
DLO	Doesn't lock open (after last shell)							
DLU	Doesn't lock-up							
DS	Dead safe							
DX	Doesn't extract							
DXL	Doesn't extract live round							
EDS	Extractor drops shell	1						i
ESB	Ejector sticks back	1						1
ESCR	Empty shell catches receiver	I						
ESS	Extractor stems shell							
FA	Fires automatically							
FB	Follower binds							
FC	Fails to connect							
FC	Fore-end cracked or broken							
FCB FD	Follows-down							
FD								
	Fails to fire							
FFP	Flat firing pin							
FOS	Fires on safe							
FPHB	Firing pin hits bbl			 	 			 
FPHI	Firing pin hits inside rim							 
FPO	Floor plate opens	8						8
FPOH	Floor plate opens hard							
FSR	Fires when safe is released				 			
FT	Follower tips							
GCSO	Gas cyl shot off							
HBL	Heavy bolt lift	1						1
HMSC	Heading mismatch-steps on case							
НРА	High pressure ammo							
HUR	Hard under rail							
JCS	Jumps cartridge							
JM	Jumps magazine							
JO	Jars off							
LB	Light blow							
МАН	Magazine assembles hard							
MCW	Magazine capacity wrong							
MFA	Misfires (ammo)							
MFOP	Magazine follower out of position							
ML	Magazine loose							
MLH	Magazine loads hard							
MRH	Magazine removes hard					2		2
он	Opens hard							
OR	Over-rides							
РН	Pulls hard							

PSI	Proof stamp illegible									
	Proof stamp missing									
	Rings and bulges on case	<b>├</b> ───┤								I
		┨────┤					1			1
	(Action) release doesn't work	┨────┤				 				·'
	Rings in chamber									
	Ring in sholder									
	Rim srem	<b> </b>								il
	Stems bottom chambers	<b> </b>								i
	Stems bbl extension	<b> </b>				 				i
	Stock cracked or broken	<b> </b>				 				i
	Shell catches									
	Short indent									i
	Stems incline									
	Stems in chamber		2							2
	shaves lead									
SLC	Stems left side of chamber									<u> </u>
SMOC	Stretch marks on case									í
SOR	Stem over-ride						1			i
SP	Stems port									i i
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
SSOC	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
SWW	Safety ewitxh won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									[]
UNCN-T	Uncoded									í
ХН	Extracts hard									· · · · · · · · · · · · · · · · · · ·
ні	High	<b>├</b> ──┤								
LO	Low									
	Left									i
	Right									
	Doesn't Group	<u>├</u>								
	Front sight tipped									
	Rear sight tipped	<b>├</b> ───┤								
	Rear sight base raised	<b>├</b> ───┤								
	Front sight raised	├								·
	Front sight loose	<u>├</u> ───┤								
I JIL	I TOTIL SIGHT DOSE									<u>.                                    </u>

RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions	7	2						9

Summary	Total Test + Proo		200								Test Date:					
	Total Overall Re	Rejected: ject Rate:	49 24.50													totals
		Shot:	2	41	17	2	69	1		5		51				188
	Proof	Rejected:	0	2	0	0	4	0	0	4	0	20	0	0	0	30
		Percent:	0.0	4.9	0.0	0.0	5.8	0.0	4	80.0	1	39.2	-			16.0
	Test	Shot: Rejected:	2 0	43 2	26 4	5 2	60 <i>0</i>	1	1 0	0	0	31 10	0	0	0	170 19
	7631	Percent:	0.0	4.7	15.4	40.0	0.0	100.0	0.0	0.0		32.3				11.2
		Shot:		3			6	_		_		-				9
	Target	Rejected: Percent:	0	0 0.0	0	0	0 0.0	0	0	0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INDE	EX	700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
АВ	Action binds											4				4
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ввма	BBL-to-bolt misalignment															
BB	Bolt binds/catches															
BCOBS	Bolt catches on bolt stop				1											1
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magaz	zine														
СD	Case dented															
сн	Closes hard															
CLM	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back												1			
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round										1					

DFB	Doesn't feed back									
DFU	Doesn't feed up									í
DLO	Doesn't lock open (after last shell)									<u>├</u> ┨
DLU						 				í1
	Doesn't lock-up									<u> </u>
DS	Dead safe									<b> </b>
DX	Doesn't extract					 				<b> </b> ]
DXL	Doesn't extract live round									<b> </b>
EDS	Extractor drops shell									Í
ESB	Ejector sticks back									Í
ESCR	Empty shell catches receiver									ļ
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									1
FCB	Fore-end cracked or broken									
FD	Follows-down									ĺ
FF	Fails to fire									Í
FFP	Flat firing pin									Í
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens	1								4
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									
FT	Follower tips									
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift	1								i
нмѕс	Heading mismatch-steps on case									
НРА	High pressure ammo									
HUR	Hard under rail									1
JCS	Jumps cartridge									
ЈМ	Jumps magazine		1				6			7
JO	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong									1
MFA	Misfires (ammo)									i1
MFOP	Magazine follower out of position									<u> </u>
ML	Magazine loose									
MLH	Magazine loads hard									I
MRH	Magazine removes hard									I
ОН	Opens hard									<u>├</u> ┨
OR										<u>├</u> ┨
	Over-rides									<u> </u> ]
РН	Pulls hard									<u> </u>

PSI	Proof stamp illegible	1 1									1	
PSM	Proof stamp missing											i1
RBOC	Rings and bulges on case											<u> </u> ]
RDW	(Action) release doesn't work											íI
RIC	Rings in chamber		1									1
			I									,
RIS	Ring in sholder											í I
RS	Rim srem											í I
SBC	Stems bottom chambers											<b> </b> ]
SBE	Stems bbl extension											<b> </b> ]
SCB	Stock cracked or broken											<b> </b>
SCX	Shell catches											Í
SHI	Short indent											ļ
	Stems incline											ļ
SIC	Stems in chamber		1		1							2
SL	shaves lead											
SLC	Stems left side of chamber											
SMOC	Stretch marks on case											
SOR	Stem over-ride											
SP	Stems port											ĺ
SR	Shoulder rough											(
SRC	Stems right side of chamber											Í
SRIC	Specific rings in chamber											í l
SSOC	Surface scratches on case											
STC	Stems top chamber											
SWE	Safety switch works too easily											
SWH	Safety switch works too hard											
sww	Safety ewitxh won't work											
TD	Tips down											
ΤU	Tips up											
TWP	Trigger won't pull											
TWR	Trigger won't retract											
UNCN-T	Uncoded											
хн	Extracts hard			2								2
н	High											
LO	Low											
	Left											
	Right											iI
	Doesn't Group											/1
FSST	Front sight tipped											
	Rear sight tipped											1
RSBR	Rear sight base raised											I
FSTR	Front sight raised											
FSTL												┟────┨
	Front sight loose					1	1					(

			-		-		-		-	
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DLOS-P	Doesn't lock over shells at proof									
ESB-P	Ejector sticks back at proof							18		18
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof	2						2		4
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions			4		4				8

Summary	Total Test + Proof Fa		901								Test Date:					
	Total Rej Overall Reject		56 6.22													totals
		Shot:	51	319	153		385			166						1074
		ejected:	0	1	2	0	0	0	0	6	0	0	0	0	0	8
	F	Percent:	0.0	0.3	1.3	1	0.0	<b></b>	1	3.6			1	1		0.8
	<b>Test</b> Re	Shot: ejected:	26 1	536 34	33 2	0	245 5	0	0	52 5	0	0	0	0	0	892 47
		Percent:	3.8	6.3	6.1	Ŭ	2.0	Ŭ	Ŭ	9.6	Ū	0	Ū	Ũ	Ū	5.3
		Shot:	15	43	3		18			6						85
		ejected: Percent:	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0 0.0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INDEX		700 ADL	700 BDL	700 SS	700 Police	700 CDL	Model 7	Model 7 Stainless	7400	7500	7600	7400 Weathermaster	7600 Weathermaster	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber			2												ž
ввма	BBL-to-bolt misalignment															
BB	Bolt binds/catches			1			1									2
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
внѕ	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of posi	ition														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down			1												4
BWCFM	Bolt won't close over full magazine															
СD	Case dented															
сн	Closes hard															
СГМ	Can't laod magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стод	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back									1						1
DCS	Double click in safety switch															
рст	Double click in trigger															
DCU	Doesn't close-up									1						1
DE	Doesn't eject						1									ŕ
DEL	Doesn't eject live round			1												1

DFB	Doesn't feed back									
DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract		15		1	 				16
DXL	Doesn't extract live round		10							
EDS	Extractor drops shell		3		1					4
ESB	Ejector sticks back		0							
ESCR	Empty shell catches receiver									 
ESS	Extractor stems shell									
FA	Fires automatically									 
FB	Follower binds									 
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire						1			1
FFP	Flat firing pin						1			· · · · · · · · · · · · · · · · · · ·
FOS	Fires on safe									
F03 FPHB										
FPHB	Firing pin hits bbl					 				 
FPO	Firing pin hits inside rim									
FPO	Floor plate opens									
	Floor plate opens hard									
FSR FT	Fires when safe is released									·
	Follower tips									 
GCSO	Gas cyl shot off		4							
HBL	Heavy bolt lift		1							1
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge					 				
JM	Jumps magazine	1	4	1			1			7
JO	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
он	Opens hard									
OR	Over-rides		3				1			4
РН	Pulls hard									

PSI	Proof stamp illegible									
	Proof stamp missing	<u> </u>								]
	Rings and bulges on case	<b>├</b> ────┤								
	(Action) release doesn't work	<u> </u>								
	Rings in chamber	<u>├</u> }	2		1					3
	Ring in sholder	<b>├</b> ────┤	2		1					
	Ring in sholder Rim srem	┟────┤								i
		┟────┤		1						i
	Stems bottom chambers Stems bbl extension	┟────┤		1						· · · · · · · · · · · · · · · · · · ·
		<b>├</b> ────┤				 	 			
	Stock cracked or broken	┟────┼						 		
	Shell catches	<b>├</b> ────┤								iI
	Short indent	┟────┤								<u> </u>
	Stems incline	<b>├</b> ────┤	1							1
	Stems in chamber	<b>├</b> ────┤								i
	shaves lead	<b>↓</b>								i
	Stems left side of chamber	<b> </b>					 			i
	Stretch marks on case	<b> </b>								i
	Stem over-ride									ļ
	Stems port	$ \longrightarrow$								ļ
	Shoulder rough	$\vdash$								ļ
	Stems right side of chamber									ļ
SRIC	Specific rings in chamber									
SSOC	Surface scratches on case									
STC	Stems top chamber									i
SWE	Safety switch works too easily									l
SWH	Safety switch works too hard									i
SWW	Safety ewitxh won't work									
TD	Tips down									[
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
ХН	Extracts hard									
н	High									[]
	Low									
	Left									
	Right									
	Doesn't Group									·
	Front sight tipped									
	Rear sight tipped									i
	Rear sight base raised									
	Front sight raised									
	Front sight loose	├───┤								]
IOIL	i toni signi loose	L								į

RSTL	Rear sight loose								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof					1			7
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DLOS-P	Doesn't lock over shells at proof								
ESB-P	Ejector sticks back at proof								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof	1	2			5			ŝ
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions								