Summary	Total Test + Pro-	of Failures	1134								Test Date:					
		l Rejected:	93													
	Overall R	eject Rate:	8.20		_											totals
	Proof	Shot: [Rejected:	443 0	292 2	49 0	88 0	0	86 0	119 <i>0</i>	0	28 3	0	70 0	5 0	0	1183 5
	Proof	Percent:	0.0	0.7	0.0	0.0	0.0	0.0	0.0	U	10.7		0.0	0.0	U	0.4
		Shot:	486	240	14	143	8	84	129	0		0	25			1129
	Test	Rejected: Percent:	28 5.8	27 11.3	0 0.0	3 2.1	1 12.5	1 1.2	22 17.1	Ü	0	U	6 24.0	0	0	88 7.8
		Shot:	48	19	1	6	1	83	10		I	Ι		1		166
	Target	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	0
		Percent:	0.0	0.0	I	0.0		0.0	0.0				_			0.0
CODE	MALFUNCTION INC	DEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
AB	Action binds							+								
BABS	Bulge at body shoulder															
BAC	Burr at chamber		1													1
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches			3												3
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out o	f position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full maga	azine							1							1
CD	Case dented															
СН	Closes hard		5	2												7
CLM	Can't load magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action ba	r														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round		7	3												10
DFB	Doesn't feed back															1

				1	1			I	1	I			
DFU	Doesn't feed up												
DLO	Doesn't lock open (after last shell)												
DLU	Doesn't lock-up										1		1
DS	Dead safe		9					14					23
DX	Doesn't extract							1					1
DXL	Doesn't extract live round												
EDS	Extractor drops shell	7	1				1	1					10
ESB	Ejector sticks back		5		1	1							7
ESCR	Empty shell catches receiver												
ESS	Extractor stems shell												
FA	Fires automatically												
FB	Follower binds												
FC	Fails to connect												
FCB	Fore-end cracked or broken												
FD	Follows-down												
FF	Fails to fire										4		4
FFP	Flat firing pin												
FOS	Fires on safe												
FPHB	Firing pin hits bbl												
FPHI	Firing pin hits inside rim												
FPO	Floor plate opens												
FPOH	Floor plate opens hard												
FSR	Fires when safe is released												
FT	Follower tips												
gcso	Gas cyl shot off												
HBL	Heavy bolt lift												
HMSC	Heading mismatch-steps on case												
HPA	High pressure ammo												
HUR	Hard under rail	1											1
JCS	Jumps cartridge												
JM	Jumps magazine												
JO	Jars off												
LB	Light blow												
MAH	Magazine assembles hard												
MCW	Magazine capacity wrong												
MFA	Misfires (ammo)												
MFOP	Magazine follower out of position												
ML	Magazine loose												
MLH	Magazine loads hard												
MRH	Magazine removes hard										1		1
ОН	Opens hard												
OR	Over-rides				1								1
PH	Pulls hard												
PSI	Proof stamp illegible												
	•	•	•										

PSM	Proof stamp missing	l		I	l			I		1	
	Rings and bulges on case										
	(Action) release doesn't work										
	Rings in chamber										
	Ring in sholder										
	Rim srem										
	Stems bottom chambers	4					4				8
	Stems bbl extension										\vdash
	Stock cracked or broken										
	Shell catches										
	Short indent										
	Stems incline	3									3
	Stems in chamber		1								1
	shaves lead										
SLC	Stems left side of chamber										
SMOC	Stretch marks on case										
SOR	Stem over-ride		3								3
SP	Stems port										
SR	Shoulder rough										
SRC	Stems right side of chamber										
SRIC	Specific rings in chamber										
SSOC	Surface scratches on case										
STC	Stems top chamber										
SWE	Safety switch works too easily						1				1
SWH	Safety switch works too hard										
sww	Safety Switch won't work										
TD	Tips down										
TU	Tips up										
TWP	Trigger won't pull										
TWR	Trigger won't retract										
	Uncoded										
XH	Extracts hard				1						1
н	High										
	Low										
	Left										
	Right										
	Doesn't Group										
	Front sight tipped										
	Rear sight tipped										
	Rear sight base raised										
FSTR	Front sight raised										
	Front sight loose										
RSTL	Rear sight loose										<u> </u>

			_	T	1	 	1		ı	1	
MGPT-G	Missing parts at target										
UNCN-G	Uncoded nonconformity at target										
AI-P	Assembly incompleye at proof										
BBB	Barrel bracket cracked or broken at proof										
BC-P	Blows cases at proof										
BEB-P	Barrel extension broken at proof										
BLP-P	Blanked primer at proof										
BLSO-P	Barrel lug shot off at proof										
BP-P	Blown primer at proof										
BS-P	Barrel split at proof										
DBF-P	Damaged Bolt Face	2									2
DLOS-P	Doesn't lock over shells at proof										
ESBBP-P	Ejector sticks back -Blown Primer cup							3			3
ESBEC-P	Ejector sticks back - Ejector Cresent										
FCB-P	Fore-end cracked at proof										
FESO-P	Fore-end shot off at proof										
FF-P	Fails to fire at proof										
GCSO-P	Gas cylinder shot off at proof										
MSI-P	Magnaflux stamp illegible on bbl										
MSM-P	Magnaflux stamp missing on bbl										
PP-P	Pierced primer at proof										
SCB-P	Stock cracked or broken at proof										
UNCM-P	Uncoded proof malfunctions										

13737	, Q)	තා ල්	13318	076	good gree	1788	der Rept	6.7	
-------	---------	----------	-------	-----	-----------	------	-------------	-----	--

Summary	Total Test + Proc		561								Test Date:					
		Rejected: eject Rate:	55 9.80													totals
		Shot:	264	5	5	89	38	55		113		1				563
	Proof	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	g
		Percent:	0.0	0.0	0.0	0.0	0.0	0.0		0.0						0.0
	- ,	Shot: [Rejected:	454 49	0	0	40 4	12 0	0	0	55 <i>0</i>	0	0	0	0	0	561 53
	Test	Percent:	10.8	U	U	10.0	0.0	U	U	0.0	U	U	U	U	U	9.4
		Shot:	44			3	2			55						104
	Target	Rejected: Percent:	0 0.0	0	0	0 0.0	0 0.0	0	0	2 3.6	0	0	0	0	0	2 1.9
CODE	MALFUNCTION IND	EX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds					1										1
BABS	Bulge at body shoulder															
BAC	Burr at chamber							<u> </u>								
BBMA	BBL-to-bolt misalignment															
BB	Bolt binds/catches					1										1
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
ВС	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full maga	zine														
CD	Case dented															
СН	Closes hard															
CLM	Can't load magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action bar	r														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															

DFU	Doesn't feed up	I	I				I			
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract									
-										
DXL EDS	Doesn't extract live round									
ESB	Extractor drops shell	1		1						2
	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens	1								i
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									
FT	Follower tips									
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift	4		1						5
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine	2								3
JO	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong									
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard									
OR	Over-rides	6								6
	Pulls hard									
PSI	Proof stamp illegible									

	Proof stamp missing								<u> </u>
RBOC	Rings and bulges on case								<u> </u>
RDW	(Action) release doesn't work								
RIC	Rings in chamber								
RIS	Ring in sholder								
RS	Rim srem								
SBC	Stems bottom chambers	1							1
SBE	Stems bbl extension								
SCB	Stock cracked or broken								
SCX	Shell catches								
SHI	Short indent								
SI	Stems incline	32							32
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber								
SMOC	Stretch marks on case								
SOR	Stem over-ride								
SP	Stems port								
SR	Shoulder rough								
SRC	Stems right side of chamber								
SRIC	Specific rings in chamber								
ssoc	Surface scratches on case								
STC	Stems top chamber	1							1
SWE	Safety switch works too easily								
SWH	Safety switch works too hard								
sww	Safety Switch won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
UNCN-T	Uncoded								
XH	Extracts hard	1							1
н	High								
LO	Low								
LEFT	Left								
RIGHT	Right								
DG	Doesn't Group					2			2
FSST	Front sight tipped								
RSTT	Rear sight tipped								
RSBR	Rear sight base raised								
FSTR	Front sight raised								
FSTL	Front sight loose								
RSTL	Rear sight loose								
	-								

	1	1	 				T		
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DBF-P	Damaged Bolt Face								
DLOS-P	Doesn't lock over shells at proof								
ESBBP-P	Ejector sticks back -Blown Primer cup								
ESBEC-P	Ejector sticks back - Ejector Cresent								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions								

Total Reject.edus Proof	Test Date:	
Proof Proof Proof Proof 1-4 8-9 9-0 9-0 9-0 9-0 1-7 3-2 9-0 9-		fotals
Part		845
Test Repected 14		0 24 2.8
Fercent 7.5		735
Target Page Page		0 43 5.8
Target Rejected Percent 0.0		121
CODE MALFUNCTION INDEX 700 SPS 700 SPS 700 BDL & 700 SPS 8S 700 CDL 700 POLICE MODEL 7 XR-100 750 7500 7600 7615		0 14 11.8
AB		Rimfire totals
BABS Bulge at body shoulder	100 S	Tumino totalo
BAC Burr at chamber		
BBMA BBL-to-bolt misalignment BB Bolt binds/catches 2 4 4 4 5 5 5 5 5 5 5		
BB		
BCOBS Bolt catches on bolt stop		
BCOF Bolt catches on follower BC Blows cases BHR Bolt hits receiver BHS Bolt plug hits safety switch BLOP Bar lock or disconnector out of position BLSO Barrel lug shot off BPO Bolt pluls out BSSM Bolt stems shell in magazine BWCD Bolt won't cam down BWCFM Bolt won't close over full magazine 1 CD Case dented CH Closes hard CLM Can't laod magazine CCO Cut-off CR Cuts rim CSS Cases swell CSS CS	4	10
BC Blows cases		
BHR Both hits receiver		
BHS Bolt plug hits safety switch		
BLOP Bar lock or disconnector out of position		
BLSO Barrel lug shot off		
BPO Bolt pulls out		
BSSM Bolt stems shell in magazine		
BWCD Bolt won't cam down		
BWCFM Bolt won't close over full magazine 1		
CD Case dented		
CH Closes hard		1
CLM Can't laod magazine CO Cut-off CR Cuts rim CS Cases swell		
CO Cut-off CR Cuts rim CS Cases swell		
CR Cuts rim CS Cases swell		
CS Cases swell		
CLOG Chambel toll of gouged		
CTP Creepy trigger pull		
CTP Creepy trigger pull CWSB Cams wrong side of action bar		
DBB Doesn't blow back 7		7
DCS Double click in safety switch		
DCT Double click in trigger		
DCU Doesn't close-up		
DE Doesn't eject		
DEL Doesn't eject live round		
DFB Doesn't feed back		

DFU	Doesn't feed up				I	I			
DLO	Doesn't lock open (after last shell)								
DLU	Doesn't lock-up					3	2		5
DS	Dead safe					, ,	2		
DX	Doesn't extract	4				1			ş
DXL	Doesn't extract live round	4				'			
EDS									
ESB	Extractor drops shell								2
	Ejector sticks back	2							£
ESCR	Empty shell catches receiver								
ESS	Extractor stems shell	-							
FA	Fires automatically								
FB	Follower binds								
FC	Fails to connect								
FCB	Fore-end cracked or broken								
FD	Follows-down								
FF	Fails to fire								
FFP	Flat firing pin								
FOS	Fires on safe								
FPHB	Firing pin hits bbl								
FPHI	Firing pin hits inside rim								
FPO	Floor plate opens								
FPOH	Floor plate opens hard								
FSR	Fires when safe is released								
FT	Follower tips								
GCSO	Gas cyl shot off								
HBL	Heavy bolt lift	1							1
HMSC	Heading mismatch-steps on case								
НРА	High pressure ammo								
HUR	Hard under rail								
JCS	Jumps cartridge								
JM	Jumps magazine								
JO	Jars off								
LB	Light blow								
МАН	Magazine assembles hard								
	Magazine capacity wrong								
MFA	Misfires (ammo)								
MFOP	Magazine follower out of position								
ML	Magazine loose								
MLH	Magazine loads hard								
	Magazine removes hard								
ОН	Opens hard								
OR	Over-rides	2		1					3
	Pulls hard								
PSI	Proof stamp illegible								

PSM	Proof stamp missing									l	
	Rings and bulges on case										
	(Action) release doesn't work										
	Rings in chamber		6								- 6
	Ring in sholder										
	Rim srem										
	Stems bottom chambers										
SBE	Stems bbl extension										
SCB	Stock cracked or broken										
SCX	Shell catches										
SHI	Short indent										
SI	Stems incline										
SIC	Stems in chamber										
SL	shaves lead										
SLC	Stems left side of chamber										
SMOC	Stretch marks on case										
SOR	Stem over-ride				1						1
SP	Stems port										
	Shoulder rough										
	Stems right side of chamber	2									2
	Specific rings in chamber										
	Surface scratches on case										
	Stems top chamber										
	Safety switch works too easily										
-	Safety switch works too hard										
	Safety Switch won't work										
TD	Tips down										
—	Tips up										
-	Trigger won't pull										
TWR	Trigger won't retract										
	Uncoded										
	Extracts hard										
HI	High										
	Low										
	Left										
	Right										
						4.4					- 44
	Doesn't Group					14					14
	Front sight tipped										
	Rear sight tipped										
	Rear sight base raised										
	Front sight raised										
—	Front sight loose										
RSTL	Rear sight loose										į

				 	1					
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face	5	12							17
DLOS-P	Doesn't lock over shells at proof									
ESB-P	Ejector sticks back at proof						1	6		7
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof									
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

Summary	Total Test + Pro	oof Failures	837								Test Date:					
1		al Rejected:	41													
	Overall F	Reject Rate:	4.90		_											totals
	Proof	Shot: [Rejected:	229 1	293 0	0	96 <i>0</i>	68 0	0	2 0	0	103 <i>0</i>	0	0	0	33 0	837 1
	Proor	Percent:	0.4	0.0	0.0	0.0	0.0	0.0	0.0		0.0	0	0.0	U	0.0	Ø.1
		Shot:	56	297	206		146				98			_	33	836
	Test	Rejected: Percent:	0 0.0	7 2.4	9 4.4	0	11 7.5	0	0	0	13 13.3	0	0	0	0 0.0	40 4.8
		Shot:	5	27	19	1	I 11				10				1	72
	Target	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	0
		Percent:	0.0	0.0	0.0		0.0				0.0					0.0
CODE	MALFUNCTION IN	DEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber			1												1
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches			3	1		4	1								8
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine			5											5
CD	Case dented															
СН	Closes hard															
CLM	Can't laod magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action be	ar														
DBB	Doesn't blow back										10					10
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totais
DFU	Doesn't feed up									2					3
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe					1									1
DX	Doesn't extract					1									1
DXL	Doesn't extract live round														
EDS	Extractor drops shell														
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens		2			2									च
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips			1											1
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift		1			2									3
HMSC	Heading mismatch-steps on case														
HPA	High pressure ammo														
HUR	Hard under rail														
JCS	Jumps cartridge														
JM	Jumps magazine			1						1					Ž
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber			1		1									2
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
scx	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride														
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
НІ	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
вс-Р	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face														
DLOS-P	Doesn't lock over shells at proof														
ESB-P	Ejector sticks back at proof														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions	1													1

Summary	Total Test + Pro	of Failures	666								Test Date:					
	Tota	l Rejected:	34													
	Overall R	eject Rate:	5.11													totals
	Proof	Shot: [Rejected:	99 <i>0</i>	111 0	88 0	233 0	30 0	0	0	0	31 <i>0</i>	0	22 0	0	0	614 0
	Piooi	Percent:	0.0	0.0	0.0	0.0	0.0	U	U	U	0.0		0.0			0.0
		Shot: [10	161	117	250		56	0	0	20		52			668
	Test	Rejected: Percent:	1 10.0	4 2.5	3 2.6	23 9.2	0	0 0.0	Ü	U	3 15.0	0	0 0.0	0	0	34 5.1
		Shot:		15	6	7	I	56			2	Ι	6	1		92
	Target	Rejected: Percent:	0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0 0.0	0	0 0.0	0	0	0 0.0
CODE	MALFUNCTION INC		700 SPS	700 SPS	700 BDL &	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
0002	MAEI ONO HON INC		700 01 0	SS	ADL	700 00	700 002	700102	moble?	XIX-100	700	7000	7000	7010	TXIIII II C	171115
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber					3										3
ВВМА	BBL-to-bolt misalignment															
вв	Bolt binds/catches			1		5										8
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full maga	azine														
CD	Case dented															
СН	Closes hard															
CLM	Can't load magazine					1										1
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action ba	ır														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round					1										1
DFB	Doesn't feed back															

DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU	Doesn't lock-up						1			1
DS	Dead safe	1		3						4
DX	Doesn't extract			1						i
DXL	Doesn't extract live round									
EDS	Extractor drops shell			1						1
ESB	Ejector sticks back		1	1						2
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire			1						1
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens									
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									
FT	Follower tips		1							Ť
GCSO	Gas cyl shot off									
HBL	Heavy bolt lift									
HMSC	Heading mismatch-steps on case									
HPA	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine									
JO	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
MCW	Magazine capacity wrong			1						1
MFA	Misfires (ammo)									
MFOP	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard									
OR	Over-rides									
PH	Pulls hard									
PSI	Proof stamp illegible									

PSM	Proof stamp missing					1	I			
	Rings and bulges on case									
	(Action) release doesn't work									
	Rings in chamber		1	4						ő
	Ring in sholder									
	Rim srem									
	Stems bottom chambers									
	Stems bbl extension									
	Stock cracked or broken									
	Shell catches									
SHI	Short indent									
SI	Stems incline	3								3
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride						2			2
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
	Specific rings in chamber									
ssoc	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
	Uncoded									
XH	Extracts hard			1						1
н	High									
	Low									
	Left									
	Right									
	Doesn't Group									
	Front sight tipped									
	Rear sight tipped									
	Rear sight base raised									
	Front sight raised									
	Front sight loose									
	Rear sight loose									
NOIL	Iveal signi ioose					I	l			i

	1	1	 				T		
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DBF-P	Damaged Bolt Face								
DLOS-P	Doesn't lock over shells at proof								
ESBBP-P	Ejector sticks back -Blown Primer cup								
ESBEC-P	Ejector sticks back - Ejector Cresent								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions								

Summary	Total Test + Pro		881								Test Date:					
		al Rejected: Reject Rate:	60 6.81													totals
		Shot:	232	376	54	112					90				28	832
	Proof	Rejected:	1	0	1	5	0	0	0	0	0	0	0	0	0	7
		Percent:	0.4	0.0	1.9	4.5					0.0				0.0	0.8
	Test	Shot: Rejected:	217 6	401 42	64 0	122 0	0	12 0	2 0	0	14 4	0	15 0	0	27	874 63
	rest	Percent:	2.8	10.5	0.0	0.0	Ü	0.0	0.0	Ŭ	28.6	Ü	0.0	· ·	3.7	6.1
		Shot:	23	41	7	13		12					1			97
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0	0	0 0.0	0	0	0 0.0
CODE	MALFUNCTION IN	IDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
AB	Action binds															
BABS																
BAC	Bulge at body shoulder															
	Burr at chamber												-			
ВВМА	BBL-to-bolt misalignment							1								
BB	Bolt binds/catches		1	6				-					-			?
BCOBS BCOF	Bolt catches on bolt stop												+			
BC	Bolt catches on follower												-			
	Blows cases												1			
BHR	Bolt hits receiver												-			
BHS	Bolt plug hits safety switch												-			
BLOP	Bar lock or disconnector out	of position											-			
BLSO BPO	Barrel lug shot off						-									
BSSM	Bolt pulls out						-						-			
	Bolt stems shell in magazine)						-								
BWCD	Bolt won't cam down			1												1
BWCFM	Bolt won't close over full mag	gazine														
CD	Case dented															-
СН	Closes hard			7												7
CLM	Can't load magazine			4												4
CO	Cut-off													1		
CR	Cuts rim															
CS	Cases swell															
стос	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	par					-						-	<u> </u>		
DBB	Doesn't blow back										3					3
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject			16												16
DEL	Doesn't eject live round															
DFB	Doesn't feed back						1				I	1		I		I

				1					1		
DFU	Doesn't feed up									1	4
DLO	Doesn't lock open (after last shell)										
DLU	Doesn't lock-up										
DS	Dead safe	1									1
DX	Doesn't extract						1				1
DXL	Doesn't extract live round										
EDS	Extractor drops shell		1								4
ESB	Ejector sticks back		2								2
ESCR	Empty shell catches receiver										
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds										
FC	Fails to connect										
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire		2								2
FFP	Flat firing pin										
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens										
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	3									3
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift										
HMSC	Heading mismatch-steps on case										
НРА	High pressure ammo										
HUR	Hard under rail										
JCS	Jumps cartridge										
JM	Jumps magazine										
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
MCW	Magazine capacity wrong										
MFA	Misfires (ammo)										
MFOP	Magazine follower out of position										
ML	Magazine loose										
MLH	Magazine loads hard										
MRH	Magazine removes hard										
ОН	Opens hard		1								4
OR	Over-rides	1									1
PH	Pulls hard										
PSI	Proof stamp illegible										
								 i			

PSM	Proof stamp missing		I						
	Rings and bulges on case								
	(Action) release doesn't work								_
$\overline{}$	Rings in chamber	1							1
$\overline{}$	Ring in sholder								
	Rim srem								
	Stems bottom chambers								
SBE	Stems bbl extension								
SCB	Stock cracked or broken								
SCX	Shell catches								
SHI	Short indent								
SI	Stems incline								
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber								
SMOC	Stretch marks on case								
SOR	Stem over-ride	1							1
SP	Stems port								
	Shoulder rough								
	Stems right side of chamber								
	Specific rings in chamber								
	Surface scratches on case								
	Stems top chamber								
SWE	Safety switch works too easily								
-	Safety switch works too hard								
	Safety Switch won't work								
TD	Tips down								
	Tips up								
	Trigger won't pull								
TWR	Trigger won't retract								
	Uncoded								
	Extracts hard								
741	Extracto Hara								
н	High								
	Low								
	Left								
	Right								
	Doesn't Group								
	Front sight tipped								
	Rear sight tipped								
	Rear sight base raised								
	Front sight raised								
	Front sight loose								
RSTL	Rear sight loose								

									1
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DBF-P	Damaged Bolt Face	1		1					2
DLOS-P	Doesn't lock over shells at proof								
ESBBP-P	Ejector sticks back -Blown Primer cup								
ESBEC-P	Ejector sticks back - Ejector Cresent								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof			3					3
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions		1	1					2

Summary	Total Test + Pro		782								Test Date:					
		al Rejected: Reject Rate:	110 14.07													fotals
	Overani	Shot:	264	192	12	122	31	2	<u> </u>		164	1	28	49		864
	Proof	Rejected:	0	1	1	1	0	0	0	0	6	0	3	0	0	12
		Percent:	0.0	0.5	8.3	0.8	0.0	0.0			3.7		10.7	0.0		1.4
	Test	Shot: Rejected:	239 21	40 <i>0</i>	1	154 19	75 2	0	0	0	151 22	0	19 3	48 0	0	770 68
	rest	Percent:	8.8	0.0	2.3	12.3	2.7	· ·	Ü	Ŭ	14.6	O	15.8	0.0	Ü	a.\$
		Shot:	24	4	6	7	9				14			73		137
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0 0.0	0	0	30 41.1	0	30 21,9
CODE	MALFUNCTION IN		700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
AB	Action binds				1			-			1					i
BABS	Bulge at body shoulder															
BAC	Burr at chamber		4			1										5
BBMA	BBL-to-bolt misalignment		_		 			-								
ВВ	Bolt binds/catches		2		1	1		-								4
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower				1			-								
BC	Blows cases															
BHR	Bolt hits receiver				1											
BHS	Bolt plug hits safety switch				1			-								
BLOP	Bar lock or disconnector out	of position			1			-								
BLSO	Barrel lug shot off				+			-								
BPO	Bolt pulls out				1			-								<u> </u>
BSSM	Bolt stems shell in magazine	:			+			+								
BWCD	Bolt won't cam down				+		_	-								
BWCFM	Bolt won't close over full mag	gazine			+		2									2
CD	Case dented															
СН	Closes hard				+			1								
CLM	Can't load magazine				+			 								
CO	Cut-off				+			-								
CR	Cuts rim				-											
CS	Cases swell				1											
CTOG	Chamber torn or gouged				1	-						-		1		
CTP	Creepy trigger pull				1	-						-		1		
CWSB	Cams wrong side of action b	ar			+			-								
DBB	Doesn't blow back				+						2					2
DCS	Double click in safety switch				1											
DCT	Double click in trigger				1							-				
DCU	Doesn't close-up															
DE	Doesn't eject					2										2
DEL	Doesn't eject live round				1			1						-		
DFB	Doesn't feed back															

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totais
DFU	Doesn't feed up									1					1
DLO	Doesn't lock open (after last shell)									3					ટ
DLU	Doesn't lock-up									2					2
DS	Dead safe				2										2
DX	Doesn't extract									4					4
DXL	Doesn't extract live round														
EDS	Extractor drops shell	1													1
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect									1					1
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire									6					6
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips	1													1
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail				1										1
JCS	Jumps cartridge														
JM	Jumps magazine	1													1
JO	Jars off														
LB	Light blow														
MAH	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard									1		3			4
ОН	Opens hard														
OR	Over-rides									1					1

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totais
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case	1													1
RDW	(Action) release doesn't work														
RIC	Rings in chamber	2			9										11
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers	9			2										11
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride														
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard				1										1
НІ	High														
LO	Low												26		26
LEFT	Left												4		4
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face		1	1	1										3
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup									3					3
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof									1					1
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof									2		3			ş
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Test + Proo	f Eailuras	786								Test Date:					
Summary		Rejected:	92								rest Date.					
	Overall Re		11.70													totals
		Shot:	136	191	315	38	58				128			47		913
	Proof	Rejected: Percent:	0 0.0	1 0.5	6 1.9	0 0.0	0 0.0	0	0	0	0 0.0	0	0	0 0.0	0	7 0.8
		Shot:	115	45	368	136	57				58			0.0		779
	Test	Rejected:	23	43	30	4	6	0	0	0	14	0	0	2	0	83
	,	Percent:	20.0	8.9	8.2	2.9	10.5				24.1					10.7
	_	Shot:	12	3	37	13	5			0	3			34		107
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	0	0	U	0 0.0	0	0	2 5.9	0	2 1.9
				700 SPS	700 BDL &					VE 400	1			1		
CODE	MALFUNCTION INDE	EX	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
AB	Action binds										1					1
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches															
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magaz	zine														
CD	Case dented															
СН	Closes hard															
CLM	Can't load magazine				1											1
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стос	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back										1					1
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject													2		2
DEL	Doesn't eject live round		1			2										ર
DFB	Doesn't feed back															

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe			2		6									8
DX	Doesn't extract	3	1												4
DXL	Doesn't extract live round														
EDS	Extractor drops shell	5	1		1										7
ESB	Ejector sticks back			1	1										2
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down		2												Ž
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips	11		9											30
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail														
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides	3								1					4

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers			4											4
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
scx	Shell catches														
SHI	Short indent														
SI	Stems incline			13											13
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride									10					10
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber									1					1
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
HI	High														
LO	Low												2		2
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7500	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face		1	6											7
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Test + Pro	oof Failures al Rejected:	759 126								Test Date:					
		Reject Rate:	16.60													totals
		Shot:	111	366	75	116	6	118			205	7	2			1006
	Proof	Rejected:	0	9	1	5	1	0	0	0	3	0	0	0	0	18
		Percent:	0.0	2.5	1.3	4.3	16.7	0.0		,	1.5	0.0	0.0			1.9
	Test	Shot: Rejected:	12 3	284 33	54 2	99 9	5 0	95 9	0	0	191 45	0	0	0	0	740 101
	rest	Percent:	25.0	11.6	3.7	9.1	0.0	9.5	Ü	Ü	23.6	· ·	Ü	· ·	· ·	13.6
		Shot:	1	25	4	9		95			16					150
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0	6 6.3	0	0	0 0.0	0	0	0	0	6 4.0
				700 SPS	700 BDL &		<u> </u>	1	1	1		1	1	ı		1
CODE	MALFUNCTION IN	IDEX	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds															
BABS	+										-					
BAC	Bulge at body shoulder			1				+								1
BBMA	Burr at chamber BBL-to-bolt misalignment			-												,
BB			1	3				+								4
BCOBS	Bolt binds/catches Bolt catches on bolt stop		ı	٥				+								**
BCOF	Bolt catches on follower			1		2										3
BC	Blows cases			-				+								3
BHR	Bolt hits receiver							+								
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position						+								
BLSO	Barrel lug shot off	or position						+								
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine	,						+								
BWCD	Bolt won't cam down	,						+			1					1
BWCFM	Bolt won't close over full mag	nazine		1												1
CD	Case dented	gazine														<u> </u>
СН	Closes hard															
CLM	Can't load magazine															
CO	Cut-off						+			1		+				1
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged							1								
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back										11					11
DCS	Double click in safety switch							1			 					† · · ·
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject			1		1					1					3
DEL	Doesn't eject live round			•							<u> </u>					-
DFB	Doesn't feed back															
	1				1	I	I	1	1	l .	1	1	1	1	1	1

	I=					1					
	Doesn't feed up										
DLO	Doesn't lock open (after last shell)										
DLU	Doesn't lock-up							4			4
DS	Dead safe										
DX	Doesn't extract				1			1			2
DXL	Doesn't extract live round										<u> </u>
EDS	Extractor drops shell	2		1		7					10
ESB	Ejector sticks back				1						1
ESCR	Empty shell catches receiver										
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds										
FC	Fails to connect										
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire		1								1
FFP	Flat firing pin										
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens			1	2						3
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips										
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift										
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUR	Hard under rail										
JCS	Jumps cartridge										
JM	Jumps magazine		24					3			27
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
MCW	Magazine capacity wrong										
MFA	Misfires (ammo)										
MFOP	Magazine follower out of position										
ML	Magazine loose										
MLH	Magazine loads hard										
MRH	Magazine removes hard		1								1
ОН	Opens hard										
OR	Over-rides					2		1			3
PH	Pulls hard										
PSI	Proof stamp illegible										
	. · · ·			1			ı .	ı	1	1	

	T						1	1	
PSM	Proof stamp missing								
RBOC	Rings and bulges on case								
RDW	(Action) release doesn't work								
RIC	Rings in chamber		2						2
RIS	Ring in sholder								ı
RS	Rim srem								
SBC	Stems bottom chambers					11			11
SBE	Stems bbl extension								
SCB	Stock cracked or broken								
SCX	Shell catches								
SHI	Short indent								
SI	Stems incline								
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber					1			9
SMOC	Stretch marks on case								
SOR	Stem over-ride					9			9
SP	Stems port								
SR	Shoulder rough								
SRC	Stems right side of chamber					2			2
SRIC	Specific rings in chamber								
ssoc	Surface scratches on case								
STC	Stems top chamber								
SWE	Safety switch works too easily								
SWH	Safety switch works too hard								
sww	Safety Switch won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
UNCN-T	Uncoded								
хн	Extracts hard								
н	High								
LO	Low								
LEFT	Left								
RIGHT	Right								
DG	Doesn't Group			6					8
FSST	Front sight tipped								
RSTT	Rear sight tipped								
RSBR	Rear sight base raised								
FSTR	Front sight raised								
FSTL	Front sight loose								
RSTL	Rear sight loose								
	· · · · · · · · · · · · · · · · · · ·		·		1		1	1	

			1							
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face	2	1	1						4
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup						3			3
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof	7		4	1					12
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

Summary	Total Test + Proof F Total Re		909 166								Test Date:					
	Overall Rejec		18.26													totals
		Shot:	732	90	153	15		20	3		21					1034
		Rejected: Percent:	2 0.3	1 1.1	0 0.0	0 0.0	0	0 0.0	1 33.3	0	0 0.0	0	0	0	0	4 0,4
	_	Shot:	315	46	471	46		<u> </u>			27					908
		Rejected: Percent:	49 15.6	0 0.0	98 20.8	8 17.4	0	0	0	0	7 25.9	0	0	0	0	162 17.9
		Shot:	22	0	42 0	3		<u> </u>			0	<u> </u>		L		67
		Rejected: Percent:	0 0.0	U	0.0	0 0.0	0	0	0	0	U	0	0	0	0	0 0.0
CODE	MALFUNCTION INDEX		700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds	+														
BABS	Bulge at body shoulder															
BAC	Burr at chamber				8											8
BBMA	BBL-to-bolt misalignment				<u> </u>			1								
BB	Bolt binds/catches															
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower				1											1
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of po-	sition														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazine	e	28		40											68
CD	Case dented															
СН	Closes hard		2		29											31
CLM	Can't load magazine		2			1										3
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back							1								
DCS	Double click in safety switch															
DCT	Double click in trigger							1								
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round							1								
DFB	Doesn't feed back					1	1					1				1

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up									2					2
DS	Dead safe	4		1											5
DX	Doesn't extract				2										2
DXL	Doesn't extract live round														
EDS	Extractor drops shell	1		1	1										3
ESB	Ejector sticks back			1											1
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens	1													1
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips				2										3
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift				1										1
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail	2		1	1										4
JCS	Jumps cartridge														
JM	Jumps magazine	8		2											10
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides	1		1											2

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers			4											4
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride			8						5					13
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard			1											1
НІ	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face	1						1							2
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions	1	1												2

Summary	Total Test + Pro	of Failures	15529													
		l Rejected:	1445													4.4.6.6.
	Overali R	eject Rate: Shot:	9.31 3549	2360	393	1888	2673	666	1674	52	1170	558	164	50		totals 15197
	Proof	Rejected:	10	18	37	22	11	25	41	0	23	5	2	1	0	195
		Percent:	0.3	0.8	9.4	1.2	0.4	3.8	2.4	0.0	2.0	0.9	1.2	2.0		1.3
	-	Shot:	1327 173	1310 109	2933 169	2955 167	2582 103	733 25	1622 86	62	1229 354	509 50	30 0	42 5	0	15334 1247
	Test	Rejected: Percent:	173	8.3	5.8	5.7	4.0	25 3.4	5.3	6 9.7	28.8	9.8	0.0	11.9	U	8.1
		Shot:	110	93	231	231	225	642	148	33	30	25	4	35		1807
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	1 0.2	0 0.0	2 6.1	0 0.0	0 0.0	0 0.0	0 0.0	0	3 0.2
	T	reiceiit.	0.0			0.0	0.0	0.2	0.0	0.7	0.0	0.0	0.0	0.0	1	0.2
CODE	MALFUNCTION INC	DEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds			3	1						5	2		2		13
BABS	Bulge at body shoulder															
BAC	Burr at chamber		2	16	5	26	2	1	1							53
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		30	14	21	41	19		1							126
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower					4										4
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out o	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down		1		2	3	2	2								10
BWCFM	Bolt won't close over full mag	azine	49	6	9	19	3	1								87
CD	Case dented			^		^	4.4	<u> </u>					-			20
CH	Closes hard		2	3	8	3	14	2								30
CLM	Can't load magazine Cut-off		2	6	8	6	4									26
CR	Cuts rim										2		<u> </u>			2
CS	Cuts rim Cases swell							1								
стоб	Chamber torn or gouged										+					
СТР	Creepy trigger pull							1								
CWSB	Cams wrong side of action ba	ır														
DBB	Doesn't blow back										78	3				81
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up										8					8
DE	Doesn't eject			7	2	1	4			1	2			2		19
DEL	Doesn't eject live round		1				2		1							્ર
DFB	Doesn't feed back		18				1		20							39
DFU	Doesn't feed up										2					2
DLO	Doesn't lock open (after last s	hell)										1				1
DLU	Doesn't lock-up									1	52	6				59

Dead safe Doesn't extract	4		ADL				MODEL 7		750	7400	7600	7615	Rimfire	totals
		9	26	1	14		36	3						93
		3	4	3	3	1	4		14			1		33
oesn't extract live round														
xtractor drops shell		3	3	7	7	14	2	1						37
jector sticks back		2		3	1									6
mpty shell catches receiver							2							2
xtractor stems shell														
ires automatically														
ollower binds														
ails to connect														
ore-end cracked or broken														
ollows-down														
ails to fire	1		1											2
lat firing pin														
			1	1	2									4
			'											
														
	20		40	7	-	2	40							74
	36		12	/	5	2	10							
			-	40										- 00
		6	5	13	4	1								29
														
		1	1		1									3
														
umps magazine		1	4	13	3				7	1				2:3
ars off														
ight blow														
flagazine assembles hard														
lagazine capacity wrong														
flisfires (ammo)														
lagazine follower out of position														<u> </u>
lagazine loose														
agazine loads hard														
Magazine removes hard			1						6	1				8
pens hard														
over-rides	1	1	1						57	13				73
Pulls hard														
Proof stamp illegible														
Proof stamp missing														
		2												3
						1								1
		5	2	3	3		1							14
Extended to the control of the contr	ctractor stems shell res automatically sollower binds sitils to connect ore-end cracked or broken sollows-down sitils to fire at firing pin res on safe ring pin hits inside rim oor plate opens oor plate opens oor plate opens hard res when safe is released sollower tips as cyl shot off eavy bolt lift eading mismatch-steps on case gh pressure ammo and under rail imps cartridge imps magazine res off ght blow agazine assembles hard agazine capacity wrong sisfires (ammo) agazine loose agazine loads hard agazine removes hard ooens hard ver-rides sills hard oof stamp illegible	ctractor stems shell res automatically bllower binds itils to connect ore-end cracked or broken bllows-down itils to fire at firing pin res on safe ring pin hits bbl ring pin hits inside rim bor plate opens bor plate opens bor plate opens hard res when safe is released bllower tips as cyl shot off beavy bolt lift beading mismatch-steps on case gh pressure ammo and under rail imps cartridge imps magazine ris off ght blow agazine assembles hard agazine capacity wrong siffres (ammo) agazine loose agazine loose agazine removes hard beens hard coens	tractor stems shell res automatically pllower binds place automatically place automaticall	tractor stems shell res automatically res automatically res automatically research cracked or broken r	tractor stems shell res automatically liceve binds lils to connect res-end cracked or broken lils to fire at firing pin res on safe ring pin hits bibl ring pin hits inside rim oor plate opens or plate opens or plate opens as cyl shot off seading mismatch-steps on case gh pressure ammo ard under rail mps cartridge mps magazine res off ght blow agazine capacity wrong sfires (ammo) agazine loose agazine loose agazine loose agazine loose agazine loose agazine removes hard agazine sase my sising and so contacts and so contact	tractor stems shell res automatically sollower binds list to connect re-end cracked or broken list to fire at firing pin ses on safe ring pin hits inside rim or plate opens and series released lillower tips as cyl shot off seavy bolt lift and under rail mps cartridge mps magazine sr off ghit blow agazine capacity wrong siffers (amno) agazine follower out of position agazine removes hard sens hard sens hard seagung mismating siffers (amno) agazine shard seagung mismating siffers (amno) agazine loads hard agazine removes hard sens hard sens hard sens shard	tractor stems shell res automatically ses automatically sils to connect sils to connect see-end cracked or broken sils to free 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	tractor stems shell es autonatically list to connect list to fire l 1	tractor stems shell se automatically sea automatically list to connect list to fire list to	Company Comp	treator stems shell se automatically se automatically sits to commet rean of cracked or broken sits on the 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Transfer stems shell	Transport services should be a submarkfacily by the state of the state	Instants are wind in the common of the commo

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totais
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers	8	7	40	9	5		1							70
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline	7	8	5		1									21
SIC	Stems in chamber	3	1												4
SL	shaves lead														
SLC	Stems left side of chamber	8													8
SMOC	Stretch marks on case	0													- *
					4			6		110	22				470
SOR	Stem over-ride		1	3	4	2		6		119	23				158
SP	Stems port														
SR	Shoulder rough														
	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber									2					2
SWE	Safety switch works too easily		1												1
SWH	Safety switch works too hard														1
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded			3		1		1							5
XH	Extracts hard		3	1				-							4
74.				· ·											<u> </u>
Ы	High														
LO	Low														
LEFT	Left														
															
RIGHT	Right								_						
DG	Doesn't Group						1		2						3
FSST	Front sight tipped														
RSTT	Rear sight tipped														
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof				1					1					2
	Barrel bracket cracked or broken at proof					İ							1		

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof					1		1							2
DBF-P	Damaged Bolt Face	1	3	8	5		5	22							44
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup									2	1	1			4
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof	5			1		18			10	4	1			39
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl		4					1		3					8
PP-P	Pierced primer at proof			28	12	8		13		3			1		65
SCB-P	Stock cracked or broken at proof					1									1
UNCM-P	Uncoded proof malfunctions	4	11	1	3	1	2	4		4					30