Summary	Total Test + Pr	oof Failures	738								Test Date:					
	Tot	al Rejected: Reject Rate:	74 10.03													fotals
	Overall		77	150	T	67	303	1	87	I	1	I	ī	T		687
	Proof	Shot:   Rejected:	0	153	0	1	12	0	8	0	0	0	0	0	0	21
		Percent:	0.0	0.0		1.5	4.0		9.2							3.1
		Shot:	277	95		109	120	34	82							717
	Test	Rejected: Percent:	11 4.0	1 1.1	0	6 5.5	19 15.8	4 11.8	12 14.6	0	0	0	0	0	0	53 7.4
		Shot:	30	10		10	13	29	8							100
	Target	Rejected: Percent:	0 0.0	0 0.0	0	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0 0.0
				700 SPS	700 BDL &	1	1				700 REC					
CODE	MALFUNCTION IN	IDEX	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	ACTIONS				Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		1				7	4	10							22
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine	•														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full ma	gazine					5									5
CD	Case dented															
СН	Closes hard			1		1	1									3
CLM	Can't load magazine															
со	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	oar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															<u> </u>
DCT	Double click in trigger															<u> </u>
DCU	Doesn't close-up															<u> </u>
DE	Doesn't eject						1									1
DEL	Doesn't eject live round															<b></b>
DFB	Doesn't feed back					1	1									1

DFU	Doesn't feed up									
DLO	Doesn't lock open (after last shell)									
DLU										
	Doesn't lock-up									
DS	Dead safe									
DX	Doesn't extract	2								2
DXL	Doesn't extract live round									
EDS	Extractor drops shell	2								2
ESB	Ejector sticks back									
ESCR	Empty shell catches receiver									
ESS	Extractor stems shell									
FA	Fires automatically									
FB	Follower binds									
FC	Fails to connect									
FCB	Fore-end cracked or broken									
FD	Follows-down									
FF	Fails to fire									
FFP	Flat firing pin									
FOS	Fires on safe									
FPHB	Firing pin hits bbl									
FPHI	Firing pin hits inside rim									
FPO	Floor plate opens	3		5						8
FPOH	Floor plate opens hard									
FSR	Fires when safe is released									
FT	Follower tips									
GCSO	Gas cyl shot off					2				5
HBL	Heavy bolt lift									
HMSC	Heading mismatch-steps on case									
НРА	High pressure ammo									
HUR	Hard under rail									
JCS	Jumps cartridge									
JM	Jumps magazine									
JO	Jars off									
LB	Light blow									
МАН	Magazine assembles hard									
	Magazine capacity wrong									
MFA	Misfires (ammo)									
	Magazine follower out of position									
ML	Magazine loose									
MLH	Magazine loads hard									
MRH	Magazine removes hard									
ОН	Opens hard									
OR	Over-rides				4					4
PH	Pulls hard				*					
PSI	Proof stamp illegible									
	1 1001 Starrip megible	I								

PSM	Proof stamp missing	I	I					l	
	Rings and bulges on case								<del>                                     </del>
	(Action) release doesn't work								
	Rings in chamber								
	Ring in sholder								
	Rim srem								
	Stems bottom chambers	3							3
SBE	Stems bbl extension								
SCB	Stock cracked or broken								
SCX	Shell catches								
SHI	Short indent								
SI	Stems incline								
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber								
SMOC	Stretch marks on case								
SOR	Stem over-ride			1					1
SP	Stems port								
	Shoulder rough								
	Stems right side of chamber								
	Specific rings in chamber								
	Surface scratches on case								
	Stems top chamber								
SWE	Safety switch works too easily								
	Safety switch works too hard								
sww	Safety Switch won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
	Uncoded								
	Extracts hard								
Н	High								
$\overline{}$	Low								
	Left								
	Right								
	Doesn't Group								
	Front sight tipped								
	Rear sight tipped								
	Rear sight base raised								
	Front sight lease		-						
	Front sight loose								
RSTL	Rear sight loose	l	<u> </u>						į.

MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DBF-P	Damaged Bolt Face		1	4					ş
DLOS-P	Doesn't lock over shells at proof								
ESBBP-P	Ejector sticks back -Blown Primer cup								
ESBEC-P	Ejector sticks back - Ejector Cresent								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl				1				1
PP-P	Pierced primer at proof			3					3
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions			5	7				12

							Proof	f - Test - Targ	et							
Summary		Proof Failures Total Rejected: all Reject Rate:	29								Test Date:					fotals
		Shot:	275	75	79	62	2	20	1						T	514
	Proof	Rejected: Percent:	0 0.0	0 0.0	6 7.6	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	6 1.2
		Shot:	344		54	131		20	1							549
	Test	Rejected: Percent:	11 3.2	0	2 3.7	10 7.6	0	0 0.0	0	0	0	0	0	0	0	23 4.2
		Shot:	27		6	13		20								66
	Target	Rejected: Percent:	0 0.0	0	0 0.0	0 0.0	0	0 0.0	0	0	0	0	0	0	0	0 0.0
CODE	MALFUNCTIO	N INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															†
ВВМА	BBL-to-bolt misalignmen	t														
ВВ	Bolt binds/catches		7		1	7									1	15
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver						1							İ		

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe														
DX	Doesn't extract														
DXL	Doesn't extract live round														
EDS	Extractor drops shell	1													i
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens	1													1
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail	1													1
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides	1													1

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride														
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
HI	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face			6											6
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Test + Prod		410								Test Date:					
	Total Overall Re	Rejected:	54 13.17													fotals
		Shot:	75	112	56			1	96							333
	Proof	Rejected:	1	0	2	0	0	0	3	0	0	0	0	0	0	s
		Percent:	1.3	0.0	3.6				3.1							1.8
	T4	Shot: [ Rejected:	63 2	111 3	61	0	0	0	169 37	0	0	0	0	0	0	404 48
	Test	Percent:	3.2	2.7	9.8	U	Ü	U	21.9	U	U	O	U	U	U	11.9
		Shot:	5	11	5				17							38
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0	0	0	0 0.0	0	0	0	0	0	0	0 0.0
	I			700 SPS	700 BDL &			1		1			1			0.0
CODE	MALFUNCTION IND	EX	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
BBMA	BBL-to-bolt misalignment															
BB	Bolt binds/catches				1				1							2
BCOBS	Bolt catches on bolt stop															-
BCOF	Bolt catches on follower								1							1
ВС	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	position														
BLSO	Barrel lug shot off															
BPO	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down			1												1
BWCFM	Bolt won't close over full magaz	zine		2												2
CD	Case dented															
СН	Closes hard															
CLM	Can't load magazine															
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back			1	I		1	I			1	1	1			1

DFU	Doesn't feed up				I		l			1	
	Doesn't lock open (after last shell)										
	Doesn't lock open (after last shell)										$\vdash$
	· · · · · · · · · · · · · · · · · · ·										<del></del>
	Dead safe		-								<del></del>
	Doesn't extract	1									i
	Doesn't extract live round										
	Extractor drops shell										<b></b>
ESB	Ejector sticks back										
	Empty shell catches receiver										
	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds										
FC	Fails to connect										
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire										
FFP	Flat firing pin										
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens										
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips										
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift					1					1
HMSC	Heading mismatch-steps on case										
НРА	High pressure ammo										
HUR	Hard under rail		1			4					5
JCS	Jumps cartridge										
JM	Jumps magazine										
JO	Jars off										
LB	Light blow										
ман	Magazine assembles hard										1
	Magazine capacity wrong										
	Misfires (ammo)										
	Magazine follower out of position										
	Magazine loose										
	Magazine loads hard										
	Magazine removes hard										
	Opens hard					1					1
OR	Over-rides		1			16					17
	Pulls hard										
	Proof stamp illegible										
		l	1	l			l	l	l		

PSM	Proof stamp missing	I							
	Rings and bulges on case								
	(Action) release doesn't work								
	Rings in chamber								
	Ring in sholder								
	Rim srem								
	Stems bottom chambers	1	2		2				5
	Stems bbl extension								
	Stock cracked or broken								
	Shell catches								
SHI	Short indent								
SI	Stems incline				2				2
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber				2				3
SMOC	Stretch marks on case								
SOR	Stem over-ride								
SP	Stems port								
SR	Shoulder rough								
SRC	Stems right side of chamber		1		1				2
SRIC	Specific rings in chamber								
SSOC	Surface scratches on case								
STC	Stems top chamber				6				5
SWE	Safety switch works too easily								
SWH	Safety switch works too hard								
sww	Safety Switch won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
UNCN-T	Uncoded								
хн	Extracts hard								
н	High								
	Low								
	Left								
	Right								
	Doesn't Group								
	Front sight tipped								
	Rear sight tipped								
	Rear sight base raised								
	Front sight raised								
	Front sight loose								
IXOIL	Rear sight loose	I							

	1								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DBF-P	Damaged Bolt Face	1	2		3				6
DLOS-P	Doesn't lock over shells at proof								
ESBBP-P	Ejector sticks back -Blown Primer cup								
ESBEC-P	Ejector sticks back - Ejector Cresent								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions								

Summary	Total Test + Pro		718								Test Date:					
		al Rejected:	60 8.36													falala
	Overan r	Reject Rate:		70		222	- 40			ı	1					totals
	Proof	Shot: Rejected:	184 <i>0</i>	79 <i>0</i>	0	309 10	40	79 0	0	0	0	0	0	0	33 4	727
	77007	Percent:	0.0	0.0	0.0	3.2	5.0	0.0							12.1	1.7
		Shot:	257 15	29 15	70 3	292 6	0	25 0	0	0	0	0	0	0	29	702 40
	Test	Rejected: Percent:	5.8	51.7	4.3	2.1	U	0.0	U	U	U	U	U	U	0.0	5.7
		Shot:	47	3	7	28		25								110
	Target	Rejected: Percent:	5 10.6	0 0.0	0 0.0	0 0.0	0	0 0.0	0	0	0	0	0	0	0	9 0.0
CODE	MALFUNCTION IN	DEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	700 REC ACTIONS				Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment												<del>                                     </del>	<del>                                     </del>		<del> </del>
BB	Bolt binds/catches		1													1
BCOBS	Bolt catches on bolt stop		'													<u>'</u>
BCOF	Bolt catches on follower															
ВС	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full mag	gazine			3	6										9
CD	Case dented															
СН	Closes hard															
CLM	Can't load magazine															
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стос	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action b	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject			15												15
DEL	Doesn't eject live round															
DFB	Doesn't feed back				1						1	1		1		

Marchitect   Mar
Description
Description
Description
Decided   Deci
ESS
Sept
ESS   Extractor stems shell
ESS
Fig.   From submersionly   Fig.   Follower binds   Fig.   Follower binds   Fig.   Follower binds   Fig.   Follower binds   Fig.   Fig
FR
FCB
FOB   Follows-clown
FD
FF
FPP
FOS         Fires on safe         Image: Bring on hist bell         Image: Bring on hist bring on hist insider im         Image: Bring on hist insider in         Image: Bring on hist
FPHB         Firing pin hits bibl
FPHI         Firing pin hits inside rim         1
FPO
FPOH         Floor plate opens hard
FSR         Fires when safe is released         2           FT         Follower tips         2           GCSO         Gas cyl shot off         1           HBL         Heavy bolt lift         1           HHAC         Heading mismatch-steps on case         1           HPA         High pressure ammo         1           HUR         Hard under rail         1           JCS         Jumps cartridge         1           JM         Jumps magazine         1           JO         Jars off         1           LB         Light blow         1           MAH         Magazine capacity wrong         1           MFA         Misfires (ammo)         1           MFOP         Magazine follower out of position         1           ML         Magazine loads hard         1           MLH         Magazine loads hard         1
FT
GCSO   Gas eyl shot off
HBL         Heavy bolt lift         1
HMSC         Heading mismatch-steps on case
HPA         High pressure ammo
HUR         Hard under rail
JCS         Jumps cartridge
JM         Jumps magazine   <
JO         Jars off
LB         Light blow   .
MAH         Magazine assembles hard
MCW         Magazine capacity wrong
MFA         Misfires (ammo)
MFOP         Magazine follower out of position
ML         Magazine loose   <
MLH Magazine loads hard
MRH Magazine removes hard
OH         Opens hard
OR Over-rides
PH Pulls hard
I I I WAS TROOM

								ı	1	
	Proof stamp missing									<u> </u>
RBOC	Rings and bulges on case									<u>                                       </u>
RDW	(Action) release doesn't work									
RIC	Rings in chamber	1								1
RIS	Ring in sholder									
RS	Rim srem									
SBC	Stems bottom chambers	8								8
SBE	Stems bbl extension									
SCB	Stock cracked or broken									
scx	Shell catches									
SHI	Short indent									
SI	Stems incline									
SIC	Stems in chamber									
SL	shaves lead									
SLC	Stems left side of chamber									
SMOC	Stretch marks on case									
SOR	Stem over-ride									
SP	Stems port									
SR	Shoulder rough									
SRC	Stems right side of chamber									
SRIC	Specific rings in chamber									
SSOC	Surface scratches on case									
STC	Stems top chamber									
SWE	Safety switch works too easily									
SWH	Safety switch works too hard									
sww	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
UNCN-T	Uncoded									
XH	Extracts hard									
НІ	High									
LO	Low									
LEFT	Left									
RIGHT	Right									
DG	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
RSBR	Rear sight base raised									
FSTR	Front sight raised									
FSTL	Front sight loose									
RSTL	Rear sight loose									
				1		1	 			 

			1							
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
AI-P	Assembly incompleye at proof									
BBB	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
BP-P	Blown primer at proof									
BS-P	Barrel split at proof									
DBF-P	Damaged Bolt Face			9	2					11
DLOS-P	Doesn't lock over shells at proof									
ESBBP-P	Ejector sticks back -Blown Primer cup									
ESBEC-P	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MSM-P	Magnaflux stamp missing on bbl									
PP-P	Pierced primer at proof			1						1
SCB-P	Stock cracked or broken at proof									
UNCM-P	Uncoded proof malfunctions									

Summary	Total Test + Pr		330								Test Date:					
		tal Rejected: Reject Rate:	21 6.36													totals
		Shot:	166	8	40	1	153	13								381
	Proof	Rejected: Percent:	3 1.8	0 0.0	5 12.5	0 0.0	1 0.7	0 0.0	0	0	0	0	0	0	0	9 2.4
		Shot:	149		140	5	27									321
	Test	Rejected: Percent:	5 3.4	0	6 4.3	1 20.0	0 0.0	0	0	0	0	0	0	0	0	12 3.7
		Shot:	14		14	1	2									31
	Target	Rejected: Percent:	0 0.0	0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION IN	NDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber															
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches				2											2
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine	9														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full ma	gazine			4											4
CD	Case dented															
СН	Closes hard															
CLM	Can't load magazine													ļ		
co	Cut-off															
CR CS	Cuts rim															
стов	Cases swell															
CTP	Chamber torn or gouged Creepy trigger pull															
CWSB	Cams wrong side of action b	nar e														
DBB	Doesn't blow back	Jai														
DCS	Double click in safety switch															
DCT	Double click in trigger							+								
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															
	1			1	1		1		1		1	1	1	1	1	I .

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totais
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe														
DX	Doesn't extract	1			1										2
DXL	Doesn't extract live round														
EDS	Extractor drops shell	1													1
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips														
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift														
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail														
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides	3													3

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers														
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
SCX	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride														
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
HI	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face	2		4											6
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl	1		1		1									3
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

	tal Tested Rejected: ject Rate:  Shot: [ Rejected: Percent: Shot: [ Rejected: Percent: Shot: [ Percent: Percent: Rejected: Percent:	478 112 23.43 117 0 0.0 143 41 28.7 6	122 0 0.0 149 15 10.1	158 0 0.0	37 0 0.0	30 0 0.0		126		Test Date:		T			fotals
Overall Re Proof Test Target	Shot: Rejected: Percent: Shot: Rejected: Percent: Shot: Rejected: Percent: Shot: Rejected:	117 0 0.0 143 41 28.7	0 0.0 149 15	0 0.0 81	0 0.0	0		126				T			
Test Target	Rejected: Percent: Shot: [ Rejected: Percent: Shot: [ Rejected:	0 0.0 143 41 28.7	0 0.0 149 15	0 0.0 81	0 0.0	0	0	126							
Test Target	Percent: Shot: [ Rejected: Percent: Shot: [ Rejected:	0.0 143 41 28.7	0.0 149 15	0.0 81	0.0		0					l		27	617
Target	Rejected: Percent: Shot: Rejected:	41 28.7	15			0.0	•	4 3.2	0	0	0	0	0	0 0.0	4 0.6
Target	Percent: Shot: [ Rejected:	28.7			4	2		72		_				27	478
	Rejected:	6		29 35.8	2 50.0	0 0.0	0	10 13.9	0	0	0	0	0	11 40.7	108 22.6
			15	8				6							35
MALFUNCTION INDE		0 0.0	0 0.0	0 0.0	0	0	0	0 0.0	0	0	0	0	0	0	0 0.0
MALFUNCTION INDE	1		700 SPS	700 BDL &					VP 400					-: <i>::</i>	
	=X	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
tion binds															
ırr at chamber			10	1											11
BL-to-bolt misalignment															
olt binds/catches		11		7	1			1							20
lt catches on bolt stop															
lt catches on follower															
ows cases															
olt hits receiver															
olt plug hits safety switch															
r lock or disconnector out of	position														
rrel lug shot off															
olt pulls out															
olt stems shell in magazine															
olt won't cam down															
olt won't close over full magaz	rine	5	2	8											15
ase dented															
oses hard															
n't load magazine		8		5											13
ut-off															<del>                                     </del>
ıts rim															<del>                                     </del>
ases swell															<del> </del>
				-											
															<del>                                     </del>
				-											<del> </del>
															<del></del>
				-											<del>                                     </del>
															<del>                                     </del>
															<del>                                     </del>
ilgining in	ge at body shoulder r at chamberto-bolt misalignment t binds/catches c catches on bolt stop c catches on follower ws cases t hits receiver t plug hits safety switch lock or disconnector out of rel lug shot off t pulls out t stems shell in magazine t won't close over full magaz se dented ses hard off t load magazine -off s rim	ge at body shoulder r at chamberto-bolt misalignmentto-bolt safety switchto-bolt misalignmentto-bolt misalignment	ge at body shoulder r at chamberto-bolt misalignmentto-bolt mi	on binds ge at body shoulder r at chamber 10  -to-bolt misalignment t binds/catches 11 catches on bolt stop catches on follower ws cases thits receiver tiplug hits safety switch lock or disconnector out of position rel lug shot off tiplus hot off tiplus hot off tive lose over full magazine twon't close over full magazine the dented ses hard i't load magazine 8  -off s rim ses swell ms wrong side of action bar sen't blow back lible click in safety switch lible click in trigger sen't close-up sen't eject live round	on binds ge at body shoulder r at chamber 10 1to-bolt misalignment : binds/catches 11 7 : catches on bolt stop : catches on follower ws cases ! hits receiver : plug hits safety switch lock or disconnector out of position rel lug shot off : pulls out : stems shell in magazine : won't cam down ! won't close over full magazine 5 2 8 ie dented ses hard !'t load magazine 8 5 -off s rim ies swell imber torn or gouged epy trigger pull ms wrong side of action bar spin't blow back ible click in safety switch ible click in trigger spin't eject spin't eject live round	on binds ge at body shoulder r at chamber 10 1 1 1 2-to-bolt misalignment binds/catches 11 7 1 2 2 catches on bolt stop catches on follower ws cases thits receiver liplug hits safety switch lock or disconnector out of position rel lug shot off catches over full magazine twon't cam down twon't close over full magazine se dented ses hard off told magazine serial ses swell serial se	on binds ge at body shoulder r at chamber 10 1  -to-bolt misalignment 1 7 1  catches on bolt stop 1 catches on follower ws cases 1 hits receiver 1 plug hits safety switch 1 lock or disconnector out of position rel lug shot off 1 stems shell in magazine 1 won't cam down 1 won't close over full magazine 2 de dented 3 find 4 for sees hard 5 find 6 sees swell 6 sems swell 7 sen't plug hits of action bar 7 sen't blow back 8 defect 8 sin't eject 8 ser't eject 8 sen't a came on the safety switch 8 sen't eject tive round	see at body shoulder  are at chamber  are at c	age at body shoulder	se at body shoulder	se at body shoulder	See a body shoulder   See a body shoulder	in binds	See   See	on binds

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totais
DFU	Doesn't feed up													5	Ş
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up													3	3
DS	Dead safe														
DX	Doesn't extract														
DXL	Doesn't extract live round							2							2
EDS	Extractor drops shell	9	2	6				3							20
ESB	Ejector sticks back		1												1
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect													3	3
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens														
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips	1			1										2
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift	1													1
HMSC	Heading mismatch-steps on case														
НРА	High pressure ammo														
HUR	Hard under rail	4													4
JCS	Jumps cartridge														
JM	Jumps magazine														
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard														
ОН	Opens hard														
OR	Over-rides	1													1

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber	1													1
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers							2							2
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
scx	Shell catches														
SHI	Short indent														
SI	Stems incline							1							1
SIC	Stems in chamber														
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride							1							1
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard			2											2
н	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face														
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions							4							4

Summary	Total	Tested	877								Test Date:					
	Total Rej		91													
	Overall Rejec	t Rate:	10.38													totals
		Shot:	145	142	144	156	203								25	815
		ejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	1 0.5	0	0	0	0	0	0	0	0 0.0	î 0.1
	,	Shot:	248	157	128	87	232	1							25	877
	<b>Test</b> R	ejected:	10	16	14	3	37	0	0	0	0	0	0	0	10	90
		Percent: _	4.0	10.2	10.9	3.4	15.9								40.0	10.3
		Shot:	24	9	17	7	21									78
		lejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0 0.0
				700 SPS	700 BDL &		T .			V5 400		7.00	T	T	<b>5</b>	1
CODE	MALFUNCTION INDEX		700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	A _1: 1.:															
	Action binds						<b> </b>							-		<del> </del>
BABS BAC	Bulge at body shoulder						44									
	Burr at chamber				1		14				-	-	-	-		15
BBMA	BBL-to-bolt misalignment						ļ				-			1	-	<u> </u>
ВВ	Bolt binds/catches			1			4								-	5
BCOBS	Bolt catches on bolt stop						ļ									<b>_</b>
BCOF	Bolt catches on follower															<u> </u>
ВС	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of pos	sition														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full magazine	,	3	1	1		3									8
CD	Case dented															
СН	Closes hard		1		1		2									4
CLM	Can't load magazine			1	7	1										ş
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стов	Chamber torn or gouged						2									2
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action bar															
DBB	Doesn't blow back															
DCS	Double click in safety switch	ĺ														
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject			4			2								1	7
DEL	Doesn't eject live round															
DFB	Doesn't feed back						2						1			2

DFU	Doesn't feed up						I		I			
DLO	Doesn't lock open (after last shell)											
DLU												
	Doesn't lock-up											<u> </u>
DS	Dead safe											100
DX	Doesn't extract		4	2	2	1					8	17
DXL	Doesn't extract live round											
EDS	Extractor drops shell	3				3						6
ESB	Ejector sticks back											
ESCR	Empty shell catches receiver											
ESS	Extractor stems shell											
FA	Fires automatically											
FB	Follower binds										1	9
FC	Fails to connect											
FCB	Fore-end cracked or broken											
FD	Follows-down											j
FF	Fails to fire	1	2			1						4
FFP	Flat firing pin											
FOS	Fires on safe											
FPHB	Firing pin hits bbl											
FPHI	Firing pin hits inside rim											
FPO	Floor plate opens											
FPOH	Floor plate opens hard											
FSR	Fires when safe is released											
FT	Follower tips	1										1
GCSO	Gas cyl shot off											
HBL	Heavy bolt lift											
HMSC	Heading mismatch-steps on case											
НРА	High pressure ammo											
HUR	Hard under rail					3						3
JCS	Jumps cartridge											
JM	Jumps magazine											
JO	Jars off											
LB	Light blow											
МАН	Magazine assembles hard											
	Magazine capacity wrong											
MFA	Misfires (ammo)											
MFOP	Magazine follower out of position											
ML	Magazine loose											
MLH	Magazine loads hard											
MRH	Magazine removes hard											
ОН	Opens hard											
OR	Over-rides			2								Ž
PH	Pulls hard											
PSI	Proof stamp illegible											
শ্ভা	Proof stamp illegible								<u> </u>			

	1								
PSM	Proof stamp missing								
RBOC	Rings and bulges on case								
RDW	(Action) release doesn't work								
RIC	Rings in chamber		2						2
RIS	Ring in sholder								
RS	Rim srem								
SBC	Stems bottom chambers	1							1
SBE	Stems bbl extension								
SCB	Stock cracked or broken								
SCX	Shell catches								
SHI	Short indent								
SI	Stems incline								
SIC	Stems in chamber								
SL	shaves lead								
SLC	Stems left side of chamber								
SMOC	Stretch marks on case								
SOR	Stem over-ride								
SP	Stems port								
SR	Shoulder rough								
SRC	Stems right side of chamber								
SRIC	Specific rings in chamber								
SSOC	Surface scratches on case								
STC	Stems top chamber		1						1
SWE	Safety switch works too easily								
SWH	Safety switch works too hard								
sww	Safety Switch won't work								
TD	Tips down								
TU	Tips up								
TWP	Trigger won't pull								
TWR	Trigger won't retract								
UNCN-T	Uncoded								
XH	Extracts hard								
н	High								
LO	Low								
LEFT	Left								
RIGHT	Right								
DG	Doesn't Group								
FSST	Front sight tipped								
RSTT	Rear sight tipped								
RSBR	Dana sink kana asiana								
1	Rear sight base raised								
FSTR	Front sight raised								
FSTR	Front sight raised								

	I		1	1				
MGPT-G	Missing parts at target							
UNCN-G	Uncoded nonconformity at target							
AI-P	Assembly incompleye at proof							
BBB	Barrel bracket cracked or broken at proof							
BC-P	Blows cases at proof							
BEB-P	Barrel extension broken at proof							
BLP-P	Blanked primer at proof							
BLSO-P	Barrel lug shot off at proof							
BP-P	Blown primer at proof							
BS-P	Barrel split at proof							
DBF-P	Damaged Bolt Face		1					9
DLOS-P	Doesn't lock over shells at proof							
ESBBP-P	Ejector sticks back -Blown Primer cup							
ESBEC-P	Ejector sticks back - Ejector Cresent							
FCB-P	Fore-end cracked at proof							
FESO-P	Fore-end shot off at proof							
FF-P	Fails to fire at proof							
GCSO-P	Gas cylinder shot off at proof							
MSI-P	Magnaflux stamp illegible on bbl							
MSM-P	Magnaflux stamp missing on bbl							
PP-P	Pierced primer at proof							
SCB-P	Stock cracked or broken at proof							
UNCM-P	Uncoded proof malfunctions							

Summary	Total Test + Pr		780								Test Date:					
		tal Rejected: Reject Rate:	41 5.26													totals
		Shot:	242	177	54	142	18		37							670
	Proof	Rejected: Percent:	0 0.0	0 0.0	0 0.0	2 1.4	0 0.0	0	0 0.0	0	0	0	0	0	0	2 0.3
		Shot:	286	71	13	318	18		72							778
	Test	Rejected: Percent:	6 2.1	7 9.9	3 23.1	14 4.4	4 22.2	0	5 6.9	0	0	0	0	0	0	39 5.0
		Shot:	19	8	25.7	25	722.2	T	7		T	Ι	1	1	T	59
	Target	Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	9
		Percent:	0.0	0.0		0.0		_	0.0				_			0.0
CODE	MALFUNCTION IN	NDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	700 REC ACTIONS				Rimfire	totals
AB	Action binds															
BABS	Bulge at body shoulder															
BAC	Burr at chamber		1			1										2
ВВМА	BBL-to-bolt misalignment															
вв	Bolt binds/catches		1	2		9			1							13
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine	e														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full ma	gazine	2	3		2	1									8
CD	Case dented															
СН	Closes hard		2	1												3
CLM	Can't load magazine															
СО	Cut-off															
CR	Cuts rim															
cs	Cases swell															<b></b>
стов	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action b	oar														
DBB	Doesn't blow back															<u> </u>
DCS	Double click in safety switch	1														
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	700 REC ACTIONS		Rimfire	totals
DFU	Doesn't feed up												
DLO	Doesn't lock open (after last shell)												
DLU	Doesn't lock-up												
DS	Dead safe												
DX	Doesn't extract			1									1
DXL	Doesn't extract live round												
EDS	Extractor drops shell												
ESB	Ejector sticks back			1		1							2
ESCR	Empty shell catches receiver												
ESS	Extractor stems shell												
FA	Fires automatically												
FB	Follower binds												
FC	Fails to connect												
FCB	Fore-end cracked or broken												
FD	Follows-down												
FF	Fails to fire												
FFP	Flat firing pin												
FOS	Fires on safe												
FPHB	Firing pin hits bbl												
FPHI	Firing pin hits inside rim												
FPO	Floor plate opens												
FPOH	Floor plate opens hard												
FSR	Fires when safe is released												
FT	Follower tips												
GCSO	Gas cyl shot off												
HBL	Heavy bolt lift												
HMSC	Heading mismatch-steps on case												
НРА	High pressure ammo												
HUR	Hard under rail												
JCS	Jumps cartridge												
JM	Jumps magazine		1		1								Ž
JO	Jars off												
LB	Light blow												
МАН	Magazine assembles hard												
MCW	Magazine capacity wrong												
MFA	Misfires (ammo)												
MFOP	Magazine follower out of position												
ML	Magazine loose												
MLH	Magazine loads hard												
MRH	Magazine removes hard												
ОН	Opens hard												
OR	Over-rides							1					1

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	700 REC ACTIONS		Rimfire	totals
PH	Pulls hard												
PSI	Proof stamp illegible												
PSM	Proof stamp missing												
RBOC	Rings and bulges on case												
RDW	(Action) release doesn't work												
RIC	Rings in chamber												
RIS	Ring in sholder												
RS	Rim srem												
SBC	Stems bottom chambers												
SBE	Stems bbl extension												
SCB	Stock cracked or broken												
scx	Shell catches												
SHI	Short indent												
SI	Stems incline							3					3
SIC	Stems in chamber												
SL	shaves lead												
SLC	Stems left side of chamber												
SMOC	Stretch marks on case												
SOR	Stem over-ride				1								1
SP	Stems port												
SR	Shoulder rough												
SRC	Stems right side of chamber												
SRIC	Specific rings in chamber												
SSOC	Surface scratches on case												
STC	Stems top chamber												
SWE	Safety switch works too easily												
SWH	Safety switch works too hard												
sww	Safety Switch won't work			1		2							3
TD	Tips down												
TU	Tips up												
TWP	Trigger won't pull												
TWR	Trigger won't retract												
UNCN-T	Uncoded												
XH	Extracts hard												
НІ	High												
LO	Low												
LEFT	Left												
RIGHT	Right												
DG	Doesn't Group												
FSST	Front sight tipped												
RSTT	Rear sight tipped												

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	700 REC ACTIONS		Rimfire	totals
RSBR	Rear sight base raised												
FSTR	Front sight raised												
FSTL	Front sight loose												
RSTL	Rear sight loose												
MGPT-G	Missing parts at target												
UNCN-G	Uncoded nonconformity at target												
AI-P	Assembly incompleye at proof												
BBB	Barrel bracket cracked or broken at proof												
BC-P	Blows cases at proof												
BEB-P	Barrel extension broken at proof												
BLP-P	Blanked primer at proof												
BLSO-P	Barrel lug shot off at proof												
BP-P	Blown primer at proof												
BS-P	Barrel split at proof												
DBF-P	Damaged Bolt Face				1								1
DLOS-P	Doesn't lock over shells at proof												
ESBBP-P	Ejector sticks back -Blown Primer cup												
ESBEC-P	Ejector sticks back - Ejector Cresent												
FCB-P	Fore-end cracked at proof												
FESO-P	Fore-end shot off at proof												
FF-P	Fails to fire at proof												
GCSO-P	Gas cylinder shot off at proof												
MSI-P	Magnaflux stamp illegible on bbl												
MSM-P	Magnaflux stamp missing on bbl												
PP-P	Pierced primer at proof				1								1
SCB-P	Stock cracked or broken at proof												
UNCM-P	Uncoded proof malfunctions												

Summary		Total Tested	707								Test Date:					
		tal Rejected: Reject Rate:	97 13.72													totals
		Shot:	169	147	1 1	157	312	1				1				786
	Proof	Rejected: Percent:	14 8.3	4 2.7	0 0.0	4 2.5	0 0.0	0	0	0	0	0	0	0	0	22 2.8
		Shot:	160	230	24		293									707
	Test	Rejected:	11 6.9	25	3 12.5	3	33 11.3	0	0	0	0	0	0	0	0	75 10.6
		Percent:	12	10.9 22	12.5	<u> </u>	23					ı			_	59
	Target	Shot: [ Rejected:	0	0	0	0	0	0	0	0	0	0	0	0	0	ე ე
	rarger	Percent:	0.0	0.0	0.0		0.0									0.0
CODE	MALFUNCTION IN	IDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds			1												1
BABS	Bulge at body shoulder															·
BAC	Burr at chamber				+			+							<u> </u>	
ВВМА	BBL-to-bolt misalignment															
ВВ	Bolt binds/catches		1	2	1		4									7
BCOBS	Bolt catches on bolt stop		· ·													
BCOF	Bolt catches on follower															
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine	9														
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full ma	gazine	1	12			5									18
CD	Case dented															
СН	Closes hard						1									1
CLM	Can't load magazine															
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
CTOG	Chamber torn or gouged															
CTP	Creepy trigger pull															
CWSB	Cams wrong side of action b	oar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger															
DCU	Doesn't close-up															
DE	Doesn't eject															
DEL	Doesn't eject live round															
DFB	Doesn't feed back															

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
DFU	Doesn't feed up														
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe	1	1												2
DX	Doesn't extract	1	5			3									9
DXL	Doesn't extract live round		1												1
EDS	Extractor drops shell	1				2									3
ESB	Ejector sticks back														
ESCR	Empty shell catches receiver														
ESS	Extractor stems shell														
FA	Fires automatically														
FB	Follower binds														
FC	Fails to connect														
FCB	Fore-end cracked or broken														
FD	Follows-down														
FF	Fails to fire														
FFP	Flat firing pin														
FOS	Fires on safe														
FPHB	Firing pin hits bbl														
FPHI	Firing pin hits inside rim														
FPO	Floor plate opens		1												1
FPOH	Floor plate opens hard														
FSR	Fires when safe is released														
FT	Follower tips	3													3
GCSO	Gas cyl shot off														
HBL	Heavy bolt lift	1	1			1									3
HMSC	Heading mismatch-steps on case														
HPA	High pressure ammo														
HUR	Hard under rail		1			10									11
JCS	Jumps cartridge				3										3
JM	Jumps magazine					1									1
JO	Jars off														
LB	Light blow														
МАН	Magazine assembles hard														
MCW	Magazine capacity wrong														
MFA	Misfires (ammo)														
MFOP	Magazine follower out of position														
ML	Magazine loose														
MLH	Magazine loads hard														
MRH	Magazine removes hard					1									1
ОН	Opens hard					1									1
OR	Over-rides			3											3

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totais
PH	Pulls hard														
PSI	Proof stamp illegible														
PSM	Proof stamp missing														
RBOC	Rings and bulges on case														
RDW	(Action) release doesn't work														
RIC	Rings in chamber														
RIS	Ring in sholder														
RS	Rim srem														
SBC	Stems bottom chambers	1													1
SBE	Stems bbl extension														
SCB	Stock cracked or broken														
scx	Shell catches														
SHI	Short indent														
SI	Stems incline														
SIC	Stems in chamber	1													1
SL	shaves lead														
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride					1									1
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard					3									3
н	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
AI-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face	14	4		4										22
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
MSI-P	Magnaflux stamp illegible on bbl														
MSM-P	Magnaflux stamp missing on bbl														
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														

Summary	Total Test	ted 48	5							Test Date:					
Summary	Total Rejecte		22							resi Date.					
	Overall Reject Ra														totals
	Sh		186	87		30		0	0		0				530
	Proof Reject Perce	ent: 0.0	5 2.7	0.0	0	0 0.0									5 0.9
	Sh <b>Test</b> Reject		141 0	57 0	0	56 1	0	0	0	0	0	0	0	0	485 17
	Perce	ent: 7.6	0.0	0.0	0.0	1.8		,		,		· · · · · ·	· · · · · · · · · · · · · · · · · · ·		3.5
	Sh <b>Target</b> Reject		14 0	0	0	0	60 0	0	0	0	0	0	0	0	190 9
	Perce		0.0	0.0	0.0	0.0	0.0	-	-	-		-		-	0.0
CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
AB	Action binds														
BABS	Bulge at body shoulder														
BAC	Burr at chamber		+												
BBMA	BBL-to-bolt misalignment	<del> </del>													
BB	Bolt binds/catches	5	+				1			-				ļ	5
BCOAB	Bolt catches on anti-bind		+		-		1		-					-	
BCOBS	Bolt catches on bolt stop		+	+			1		-		-				
BCOF BC	Bolt catches on follower		+	+			1	-	-	-	-		-		
BHR	Blows cases		+	_			1								
SHK SHS	Bolt hits receiver		+				+								
BLOP	Bolt plug hits safety switch		+	+			1								
LSO	Bar lock or disconnector out of position  Barrel lug shot off		+	+			1								
PO	Bolt pulls out		+	+			1								
SSM	Bolt stems shell in magazine		+	+											
WCD	Bolt won't cam down		+												
WCFM	Bolt won't close over full magazine		+												
D	Case dented		+	+											
H	Closes hard	3	+	1		1									4
CLM	Can't load magazine	3	+				1								3
00	Cut-off		1				1								
CR	Cuts rim														
cs	Cases swell														
тос	Chamber torn or gouged														
TP	Creepy trigger pull														
CWSB	Cams wrong side of action bar														
OBB	Doesn't blow back														
cs	Double click in safety switch														
СТ	Double click in trigger														
CU	Doesn't close-up														
E	Doesn't eject														
EL	Doesn't eject live round														
FB	Doesn't feed back						ļ								
DFU	Doesn't feed up		$\perp$												
DLO	Doesn't lock open (after last shell)														
DLU	Doesn't lock-up														
DS	Dead safe						1								
DX	Doesn't extract		1				1								
OXL	Doesn't extract live round		-												
os	Extractor drops shell	1	1	1	1	1	1	1	1	1	1	I	1	I	

	1								
ESB	Ejector sticks back								<b></b>
ESCR	Empty shell catches receiver								
ESS	Extractor stems shell								
FA	Fires automatically								
FB	Follower binds								
FC	Fails to connect								i
FCB	Fore-end cracked or broken								i
FD	Follows-down								i
FF	Fails to fire								i
FFP	Flat firing pin								
FOS	Fires on safe								
FPHB	Firing pin hits bbl								1
FPHI	Firing pin hits inside rim								1
FPO	Floor plate opens								
FPOH	Floor plate opens hard								
FSR	Fires when safe is released								
FT	Follower tips	2							2
GCSO	Gas cyl shot off								
HBL	Heavy bolt lift								
HMSC	Heading mismatch-steps on case								
HPA	High pressure ammo								1
HUR	Hard under rail	2							2
JCS	Jumps cartridge								
JM	Jumps magazine								i
JO	Jars off								
LB	Light blow								
MAH	Magazine assembles hard								
MCW	Magazine capacity wrong								
MFA	Misfires (ammo)								
MFOP	Magazine follower out of position								
ML	Magazine loose								
MLH	Magazine loads hard								
MRH	Magazine removes hard								
ОН	Opens hard								
OR	Over-rides	1							3
PH	Pulls hard								
PSI	Proof stamp illegible								
PSM	Proof stamp missing								
RBOC	Rings and bulges on case								
RDW	(Action) release doesn't work	1	<b> </b>						
RIC	Rings in chamber		<b> </b>						
RIS	Ring in sholder								
RS	Rim srem								
SBC	Stems bottom chambers								
SBE	Stems bbl extension								
SCB	Stock cracked or broken								
SCX	Shell catches								
SHI	Short indent								
SI									
SIC	Stems in chamber								
SL	Stems in chamber shaves lead								
SLC									
SEC	Stems left side of chamber		l						

SMOC	Stratah marka an asas	I				I	I	ı	I	
	Stretch marks on case									
	Stem over-ride									
	Stems port									
	Shoulder rough									
-	Stems right side of chamber									
	Specific rings in chamber									
	Surface scratches on case									
	Stems top chamber									
SWE	Safety switch works too easily									
-	Safety switch works too hard									
SWW	Safety Switch won't work									
TD	Tips down									
TU	Tips up									
TWP	Trigger won't pull									
TWR	Trigger won't retract									
-	Uncoded									
XH	Extracts hard									
HI	High									
	Low									
	Left									
	Right									
	Doesn't Group									
FSST	Front sight tipped									
RSTT	Rear sight tipped									
	Rear sight base raised									
-	Front sight raised									
	Front sight loose									
RSTL	Rear sight loose									
MGPT-G	Missing parts at target									
UNCN-G	Uncoded nonconformity at target									
Al-P	Assembly incompleye at proof									
	Barrel bracket cracked or broken at proof									
BC-P	Blows cases at proof									
BEB-P	Barrel extension broken at proof									
BLP-P	Blanked primer at proof									
BLSO-P	Barrel lug shot off at proof									
	Blown primer at proof									
	Barrel split at proof									
DBF-P	Damaged Bolt Face		5							5
	Doesn't lock over shells at proof									
	Ejector sticks back -Blown Primer cup									
	Ejector sticks back - Ejector Cresent									
FCB-P	Fore-end cracked at proof									
FESO-P	Fore-end shot off at proof									
FF-P	Fails to fire at proof									
GCSO-P	Gas cylinder shot off at proof									
MSI-P	Magnaflux stamp illegible on bbl									
MOM D										
MSM-P	Magnaflux stamp missing on bbl									
MSM-P PP-P										

Summary	Total Teste Total Rejected									Test Date:					
l	Overall Reject Rate														totals
	Shot		30	179	73	41	26	I	l		1			1	677
	<b>Proof</b> Rejected Percen	f: 0	0 0.0	0 0.0	2 2.7	3 7.3	0 0.0	0	0	0	0	0	0	0	5 0.7
	Shot		26	244	101		26								640
	<b>Test</b> Rejected Percen		0 0.0	0 0.0	4 4.0	0	4 15.4	0	0	0	0	0	0	0	15 2.3
	Shot		3	24	4										48
	Target Rejected Percen		0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0	0 0.0
		1	700 SPS	700 BDL &		T	T	T	l		T		T	T	1
ODE	MALFUNCTION INDEX	700 SPS	SS	ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	tofals
ιB	Action binds														
BABS	Bulge at body shoulder														
AC	Burr at chamber														
BBMA	BBL-to-bolt misalignment										1				
В	Bolt binds/catches				1										1
COAB	Bolt catches on anti-bind														
COBS	Bolt catches on bolt stop														
COF	Bolt catches on follower														
0	Blows cases														
HR	Bolt hits receiver														
HS	Bolt plug hits safety switch														
_OP	Bar lock or disconnector out of position														
_SO	Barrel lug shot off														
oo.	Bolt pulls out														
SSM	Bolt stems shell in magazine														
WCD	Bolt won't cam down														
<b>NCFM</b>	Bolt won't close over full magazine														
כ	Case dented														
Н	Closes hard														
LM	Can't load magazine														
o	Cut-off	1													
CR	Cuts rim	1													
S	Cases swell						1								
TOG	Chamber torn or gouged			1			1								
TP	Creepy trigger pull	-					1								
WSB	Cams wrong side of action bar	-					1								
BB	Doesn't blow back	1					1			-		-			
ocs	Double click in safety switch						1								
CT	Double click in trigger	1		1			1				1				
CU	Doesn't close-up	-			<del> </del>		1								<u> </u>
E	Doesn't eject	-			1						-	-	-	-	1
EL	Doesn't eject live round														
FB	Doesn't feed back	1			-							-			
)FU	Doesn't feed up	1												-	
DLO	Doesn't lock open (after last shell)	1		-			1				1				
DLU	Doesn't lock-up	1	-	-			1				1				
DS	Dead safe	1													
DX	Doesn't extract	6					-							-	6
DXL EDS	Doesn't extract live round  Extractor drops shell	+		1			+	-			-		1	ļ	

jector sticks back mpty shell catches receiver xtractor stems shell ires automatically ollower binds ails to connect	1													
xtractor stems shell ires automatically ollower binds														1
ires automatically ollower binds														
ollower binds														
ails to connect														
alls to confinect														
ore-end cracked or broken														
ollows-down														
ails to fire														
lat firing pin														
ires on safe														
iring pin hits bbl														
iring pin hits inside rim														
loor plate opens														
loor plate opens hard														
ires when safe is released														
ollower tips														
as cyl shot off														
eavy bolt lift														
eading mismatch-steps on case														
igh pressure ammo														
ard under rail														
umps cartridge														
umps magazine														
ars off														
ight blow														
lagazine assembles hard														
lagazine capacity wrong														
lisfires (ammo)														
lagazine follower out of position														
fagazine loose														
lagazine loads hard														
lagazine removes hard														
pens hard														
Over-rides						4								4
ulls hard														
roof stamp illegible														
roof stamp missing														
lings and bulges on case														
Action) release doesn't work														
lings in chamber														
ling in sholder														
lim srem														
tems bottom chambers														
tems bbl extension														
tock cracked or broken														
hell catches														
hort indent														
tems incline														
haves lead														
iriilooloolooloolooloolooloolooloolooloolo	ing pin hits inside rim for plate opens for plate opens for plate opens hard es when safe is released flower tips s cyl shot off avy bolt lift ading mismatch-steps on case gh pressure ammo rd under rail mps cartridge mps magazine rs off hit blow flower discovered by the same of the same flower tips flower	ing pin hits inside rim for plate opens for plate opens hard ses when safe is released flower tips so cyl shot off avy bolt lift ading mismatch-steps on case gh pressure ammo rd under rail mps cartridge mps magazine rs off thit blow gazine assembles hard gazine capacity wrong sfires (ammo) gazine follower out of position gazine loads hard gazine removes hard ere-rides flish hard boof stamp illegible boof stamp missing gas and bulges on case cition) release doesn't work gas in chamber gas bottom chambers gas bottom chambers gas bottom chambers gens hard gens bottom chambers gens bottom chambers gens bottom chambers gens in chamber	ing pin hits inside rim for plate opens for plate opens hard ses when safe is released flower tips so scyl shot off avy bolt lift ading mismatch-steps on case gh pressure ammo rd under rail mps cartridge mps magazine rs off hit blow gazine assembles hard gazine capacity wrong sfires (ammo) gazine follower out of position gazine loose gazine nemoves hard gazine removes hard lish hard bloof stamp illegible boof stamp illegible boof stamp missing gas and bulges on case cition) release doesn't work gas bottom chambers gas bottom chambers gens bottom chambers gens in chamber	ing pin hits inside rim for plate opens for plate opens hard ses when safe is released flower tips so cyl shot off avy bolt lift ading mismatch-steps on case gin pressure ammo rd under rail mps cartridge mps magazine rs off hit blow gazine capacity wrong gazine capacity wrong gazine loose gazine loose gazine loose gazine loose gazine removes hard eens hard bord stamp missing gas and bulges on case cition) release doesn't work gas in chamber gens bolt extension book cracked or broken eens hard eens bott chambers gas bott chamber gens in chamber	Ing pin hits inside rim  Indicate opens  Indic	ing pin hits inside rim or plate opens or plate opens or plate opens hard es when safe is released llower tips s cyl shot off adding mismatch-steps on case pin pressure ammo rd under rail mps cartridge mps magazine rs off hit blow gazine assembles hard gazine rapacity wrong gazine loose gazine follower out of position gazine loose gazine loose gazine ramoves hard gazine ramoves hard gazine ramoves hard gazine ramoves hard gazine loose hard gazine ramoves hard en-rides llis hard of stamp illegible of stamp missing gas and bulges on case tichn) release doesn't work gas in chamber en sem ens bolt orthorhomes ens both or chambers ens both orthorhomes ens in chamber ens sin chamber ens sin chamber ens sin chamber ens sin chamber	ing pin hits inside rim or plate opens or plate opens and or plate opens hard or swhen safe is released llower tips s cyl shot off away bolt lift ading mismatch-steps on case the pressure ammo red under rail mps cartridge mps magazine mps	ing pin hits inside rim or plate opens or plate opens hard es when safe is released lower tips s ory shot off avy bolt lift ading mismatch-steps on case hip pressure amno rd under rail mps cartridge mps magazine s off int blow s off int blow gazine capacity wrong gazine capacity wrong gazine loose gazine loose gazine loose gazine removes hard er-rides lis hard of stamp illegible of stamp illegible of stamp missing gas and bulges on case light states mps mem mps missing mps magazine light shotder mps	or plate opens or plate opens hard so when safe is released lower tips so y shat off any built ift ading mismatch-steps on case in pressure ammo and under rail mps cartridge mps magazine so off so off so off so off so off so off spazine assembles hard gazine capacity wrong gazine loose gazine loose gazine removes hard gazine removes hard so of stamp missing gazine sholder mps missing gazine and shord site in the shord site in the shord site in the shord spazine shord spazin	or plate opens or plate opens or plate opens hard so when safe is released locare tips so cyl shot off didgn gismatch-steps on case if the pressure ammo did under tall mys cartridge mys magazine so off the tip town gazine assembles hard gazine assembles hard gazine assembles hard gazine daspelly wrong siffes (ammo) gazine follower ut of position gazine follower ut of	Ing pin his inside rim  or plate opens  or plate opens  or plate opens hard  or plate opens hard  or swhen safe is released  locar flips  so sy that off  any bolt lift  any bolt lift  in ressure ammo  did under rail  in ressure ammo  in under rail  in ressure ammo  in under rail  in ressure ammo  in under rail  in present ridge  present ridge  present ridge  present ridge  present ridge  in to locar  so off  in to locar  so o	Inspirit his midde from or plate opens is or pla	Insighin his mader mm	Ing pin his inside firm or plate deprish and or pla

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
SLC	Stems left side of chamber														
SMOC	Stretch marks on case														
SOR	Stem over-ride				2										2
SP	Stems port														
SR	Shoulder rough														
SRC	Stems right side of chamber														
SRIC	Specific rings in chamber														
SSOC	Surface scratches on case														
STC	Stems top chamber														
SWE	Safety switch works too easily														
SWH	Safety switch works too hard														
sww	Safety Switch won't work														
TD	Tips down														
TU	Tips up														
TWP	Trigger won't pull														
TWR	Trigger won't retract														
UNCN-T	Uncoded														
XH	Extracts hard														
HI	High														
LO	Low														
LEFT	Left														
RIGHT	Right														
DG	Doesn't Group														
FSST	Front sight tipped														
RSTT	Rear sight tipped														
RSBR	Rear sight base raised														
FSTR	Front sight raised														
FSTL	Front sight loose														
RSTL	Rear sight loose														
MGPT-G	Missing parts at target														
UNCN-G	Uncoded nonconformity at target														
Al-P	Assembly incompleye at proof														
BBB	Barrel bracket cracked or broken at proof														
BC-P	Blows cases at proof														
BEB-P	Barrel extension broken at proof														
BLP-P	Blanked primer at proof														
BLSO-P	Barrel lug shot off at proof														
BP-P	Blown primer at proof														
BS-P	Barrel split at proof														
DBF-P	Damaged Bolt Face				2	3									5
DLOS-P	Doesn't lock over shells at proof														
ESBBP-P	Ejector sticks back -Blown Primer cup														
ESBEC-P	Ejector sticks back - Ejector Cresent														
FCB-P	Fore-end cracked at proof														
FESO-P	Fore-end shot off at proof														
FF-P	Fails to fire at proof														
GCSO-P	Gas cylinder shot off at proof														
	Magnaflux stamp illegible on bbl														
MSI-P															

CODE	MALFUNCTION INDEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	intals
PP-P	Pierced primer at proof														
SCB-P	Stock cracked or broken at proof														
UNCM-P	Uncoded proof malfunctions														i

Summary	Total Test + Pro		669								Test Date:					
		al Rejected: Reject Rate:	66 9.87													totals
		Shot:	44	121	274	180	17									636
	Proof	Rejected: Percent:	0 0.0	0 0.0	1 0.4	0 0.0	0 0.0	0	0	0	0	0	0	0	0	1 0.2
		Shot:	162	75	240	105	85		1							868
	Test	Rejected: Percent:	12 7.4	4 5.3	34 14.2	10 9.5	5 5.9	0	0 0.0	0	0	0	0	0	0	66 9.7
	_	Shot:	2	7	17	14	8									48
	Target	Rejected: Percent:	0 0.0	0 0.0	0 0.0	0 0.0	0 0.0	0	0	0	0	0	0	0	0	0 0.0
CODE	MALFUNCTION INC	DEX	700 SPS	700 SPS SS	700 BDL & ADL	700 SS	700 CDL	700 POLICE	MODEL 7	XR-100	750	7400	7600	7615	Rimfire	totals
АВ	Action binds															
BABS	Bulge at body shoulder															
ВАС	Burr at chamber				1											1
ВВМА	BBL-to-bolt misalignment															
вв	Bolt binds/catches		8	2	22											32
BCOBS	Bolt catches on bolt stop															
BCOF	Bolt catches on follower				1											1
вс	Blows cases															
BHR	Bolt hits receiver															
BHS	Bolt plug hits safety switch															
BLOP	Bar lock or disconnector out of	of position														
BLSO	Barrel lug shot off															
вро	Bolt pulls out															
BSSM	Bolt stems shell in magazine															
BWCD	Bolt won't cam down															
BWCFM	Bolt won't close over full maga	azine				3										3
CD	Case dented															
СН	Closes hard					2										2
CLM	Can't load magazine				1											1
co	Cut-off															
CR	Cuts rim															
cs	Cases swell															
стоб	Chamber torn or gouged															
СТР	Creepy trigger pull															
CWSB	Cams wrong side of action ba	ar														
DBB	Doesn't blow back															
DCS	Double click in safety switch															
DCT	Double click in trigger									1				1		
DCU	Doesn't close-up										-					<u> </u>
DE	Doesn't eject			1												1
DEL	Doesn't eject live round															
DFB	Doesn't feed back								l		1		I	1		1

			1	ı				1	1	1	
DFU	Doesn't feed up										
DLO	Doesn't lock open (after last shell)										į
DLU	Doesn't lock-up										i
DS	Dead safe										
DX	Doesn't extract				3	1					幸
DXL	Doesn't extract live round										
EDS	Extractor drops shell										
ESB	Ejector sticks back										
ESCR	Empty shell catches receiver										
ESS	Extractor stems shell										
FA	Fires automatically										
FB	Follower binds			1							9
FC	Fails to connect										
FCB	Fore-end cracked or broken										
FD	Follows-down										
FF	Fails to fire										
FFP	Flat firing pin										
FOS	Fires on safe										
FPHB	Firing pin hits bbl										
FPHI	Firing pin hits inside rim										
FPO	Floor plate opens										
FPOH	Floor plate opens hard										
FSR	Fires when safe is released										
FT	Follower tips	4		1							ş
GCSO	Gas cyl shot off										
HBL	Heavy bolt lift			1							1
HMSC	Heading mismatch-steps on case										
HPA	High pressure ammo										
HUR	Hard under rail										
JCS	Jumps cartridge										
JM	Jumps magazine		1	1	2	2					8
JO	Jars off										
LB	Light blow										
МАН	Magazine assembles hard										
MCW	Magazine capacity wrong										
MFA	Misfires (ammo)										
MFOP	Magazine follower out of position										
ML	Magazine loose										
MLH	Magazine loads hard										
MRH	Magazine removes hard										
ОН	Opens hard					1					1
OR	Over-rides			1							1
PH	Pulls hard										
PSI	Proof stamp illegible										
			•	•		•		 			

PSM Proof stamp r RBOC Rings and bu RDW (Action) relea				l				
								<b>└</b>
RDW (Action) relea	oulges on case							
	ease doesn't work							
RIC Rings in char	amber		1					1
RIS Ring in sholds	lder							
RS Rim srem								
SBC Stems bottom	om chambers	1						1
SBE Stems bbl ext	extension							
SCB Stock cracked	ed or broken							
SCX Shell catches	es							
SHI Short indent	t							
SI Stems incline	ne							
SIC Stems in cha	namber							
SL shaves lead	d							
SLC Stems left sid	side of chamber							
SMOC Stretch marks	ks on case							
SOR Stem over-rid	ride							
SP Stems port								
SR Shoulder roug	ugh							
SRC Stems right s	side of chamber							
SRIC Specific rings	gs in chamber							
SSOC Surface scrat	atches on case							
STC Stems top ch	chamber							
SWE Safety switch	ch works too easily							
SWH Safety switch	ch works too hard							
SWW Safety Switch	ch won't work							
TD Tips down								
TU Tips up								
TWP Trigger won't	n't pull							
TWR Trigger won't	n't retract							
UNCN-T Uncoded								
XH Extracts hard	rd	3						3
HI High								
LO Low								
LEFT Left								
RIGHT Right								
DG Doesn't Grou	oup							
FSST Front sight tip	tipped							
RSTT Rear sight tip	ipped							
RSBR Rear sight ba	pase raised							
FSTR Front sight ra	raised							
FSTL Front sight loc	loose							
RSTL Rear sight loc	oose							

### Gallery Performance Report

Proof - Test - Target

MODEO	Adia dia ana ana ana ana ana ana ana ana ana a								
MGPT-G	Missing parts at target								
UNCN-G	Uncoded nonconformity at target								
AI-P	Assembly incompleye at proof								
BBB	Barrel bracket cracked or broken at proof								
BC-P	Blows cases at proof								
BEB-P	Barrel extension broken at proof								
BLP-P	Blanked primer at proof								
BLSO-P	Barrel lug shot off at proof								
BP-P	Blown primer at proof								
BS-P	Barrel split at proof								
DBF-P	Damaged Bolt Face		1						9
DLOS-P	Doesn't lock over shells at proof								
ESBBP-P	Ejector sticks back -Blown Primer cup								
ESBEC-P	Ejector sticks back - Ejector Cresent								
FCB-P	Fore-end cracked at proof								
FESO-P	Fore-end shot off at proof								
FF-P	Fails to fire at proof								
GCSO-P	Gas cylinder shot off at proof								
MSI-P	Magnaflux stamp illegible on bbl								
MSM-P	Magnaflux stamp missing on bbl								
PP-P	Pierced primer at proof								
SCB-P	Stock cracked or broken at proof								
UNCM-P	Uncoded proof malfunctions								