

MOST FREQUENTLY USED REMINGTON INTERCHANGEABLE PARTS

Part #	Part Name	Models Used In	Part #	Part Name	Models Used In
20616	Butt Plate	1100, 870, 11-48, 58, 878 all gauges	23805	Front Sight	740, 760, 721, 722, 870, 1100 RSS
17578	Butt Plate	550, 581, 582, 592, 514 reg.	15373	Front Sight	700, 660
14472	Butt Plate	742, 760, 700, 700	18749	Hammer	11-48 (all gauges), 870, 58 (12, 16, 20 ga), 878
18757	Carrier Dog	11-48, (28 & 410 Ga)	18339	Hammer	740, 742, 760
15480	Carrier Dog	11-87, 1100, 878, 870, 58 (all gauges), 11-48 (12, 16, 20 gauges)	15249	Hammer	1100 (12, 16, 20 ga), 11-87
17017	Ejector	700 (all calibers), 721, 722, 725, 660 (all calibers but 222 & 223)	14295	Hammer	1100 (28, 410, 20LW, L120), 870 (28, 410 ga)
17676	Ejector Pin	700, 721, 722, 725, 660, 600	22790	Inner Mag. Tube Assembly	552, 572
17019	Ejector Spring	700 (all calibers), 721, 722, 725, 660, 600, 760	26470	Inner Mag. Tube Assembly	Nylon 12, 512X
25431	Ejector	870, 58, 878 (12ga)	22325	Locking Block	878, 58, 870 (12, 16, 20 ga))
24446	Ejector	870, 58 (16ga)	29920	Locking Block	870 (28, 410 ga), 1100 (28, 410, 20LW)
24447	Ejector	870, 58 (20ga)	28653	Magazine Clip	7400, 740, 742 (30.06

16176	Extractor	1100, (12, 16, 20 & 20LW, LT 20), 870, 11-48, 58 (12, 16, 20), 878	28645	Magazine Clip	cal), 7400, 742, 740 (308 cal)
14441	Extractor	1100, 870 (28ga)	28651	Magazine Clip	7400, 742, 740 (280 cal)
14669	Extractor (riveted Style)	700 (all calibers but 222, 222 Rem Mag & 30.06), 788 (22.250, 308, 243 & 6mm)	28647	Magazine Clip	7400, 742, 740 (243 cal)
15850	Extractor	760 (222 cal), 700 (222, 222 Rem Mag, 223 cal), 788 (222 cal), 600, 660 (222 cal)	28652	Magazine Clip	7400, 742, 740 (270 cal)
15709	Extractor	700 (all mag calibers & 30.06), 600 & 660 (all mag calibers)	17034	Receiver Plug Screw	740, 742, 760, 700, 660, 721, 722, 600, 725
91816	Extractor (rivetless)	700, 7400, 7600 all cal. (except mags, 222, Rem mag 222 & 223	18551	Receiver Stud	742, 760, 870, 58, 878
17432	Extractor Plunger	11-87, 1100 (12, 16, 20, 20LW, & LT-20), 870 (12, 16, 20, 28), 58	25115	Safety Switch	11-87, 1100, 870, 11-48, 878, 58, 7400, 740, 742, 760, 572, 552,

		(12, 16, 20), 878, 11-48 all gauges)			7600
14742	Extractor Plunger	870, 1100 (410ga)	18750	Sear	11-87, 1100, 870, 11-48, 878, 58, 742, 760, 740, 572, 552, 7400, 7600
17433	Extractor Spring	11-87, 1100 (all gauges), 870 (12, 16, 20-28 ga), 58 (all gauges), 878	19993	Stock Bearing Plate	11-48, 1100, 870 (12, 16, 20 ga), 58, 878 (all gauges)
14806	Extractor Spring	870 (410ga)	19621	Stock Bearing Plate	11-48 (28, 41 ga), 740, 742, 760, 7400, 7600
17436	Firing Pin	11-87, 1100, 870, 11-48, 58, 878 (all gauges)	20601	Trigger Plate Pin Front	870, 1100, 58, 11-48 (12, 16, 20 ga), 878, 11-87
18623	Firing Pin Retaining Pin	11-87, 1100, 870, 58 (12, 16, 20 ga), 878, 11-48 (all gauges)	20606	Trigger Plate Pin Rear	870, 1100, 58, 11-48 (12, 16, 20 ga), 878, 11-878, 11-87
14297	Firing Pin Retaining Pin	1100 (28, 410, 20 LW & LT-2), 870 (28, 41 ga)	20602	Trigger Plate Pin Front	11 (28, 410, 20LW, LT-20), 870, 11-48 928, 410 ga), 740, 742, 760
93505	Firing Pin Return Spring	11-87, 1100, 870, 11-48, 58, 878	20607	Trigger Plate Pin Rear	1100 (28, 410, 20LW, LT-20), 870, 11-48 (28, 410 ga), 740, 742, 760, 552, 572