

I bought a new mountain rifle about 11 years ago. This was my first remington...

Discussion Thread

Response (Laura)

8/22/2002 10:30:30 AM

Dear Darrick,

Thank you for your inquiry. We have had 2 different style safeties on the Model 700. On pre 1982 models, it was called the bolt lock safety and when the firearm is on "S" safe, the bolt handle cannot be lifted. On post 1982 rifles, the bolt handle can be lifted when the firearm is in the "s" safe position. You can read more information regarding this as well as our important Safety Message through the front page of our website at www.remington.com.

Customer (darrick ganster)

8/20/2002 8:08:40 AM

I bought a new mountain rifle about 11 years ago. This was my first remington. My question is concerning the safty and the bolt. When the gun is on "safty" could you be able to open the bolt? I can. I just picked up a similar gun about a week ago and you could not. The safty works in regards to firing the rifle, but the bolt is never locked in place. Which rifle is correct or did the other rifle have work done to it to lock the bolt when on "safty".

thx

Darrick