configuration and safety

Discussion Thread

Response (Jessica) Dear Saint,

2/8/2005 2:37:01 PM

Thank you for your inquiry. The sear and trigger configuration is set at the factory using an optical comparator and specification layouts. Once the proper engagement, trigger pull, and over-travel have been set the adjustment screws are sealed. Properly set the sear and trigger configuration provide a safe firearm.

Customer (saint rhl) 2/6/2005 11:28:22 AM I want to know the configuration of the sear and trigger in remington700 model rifle, and also want to know how this configuration can be safe.

