Process Header

| | _ | | | |
|-----------------------------------|-----------------------|----------------|---------------|---------------------------|
| | Proces | s Header | | ************************* |
| Document ID: Safety XP1 | 0.0 | | Remington A | rme Company |
| Part Name: Safety XP1 | | | W Kemindcon V | LMS COMPANY; |
| Product Line: C/F Rifle | | Effective D | ate: 03-Nov-1 | 992-09:00:00 |
| Engineering Group: Rifle | • | Orig | ination Date: | 10-Oct-1992 |
| | | | | |
| | • | | | |
| Process Revision Reasons | 5 | | | |
| Data. | D | - Di-i | | 7 |
| Date: | Reason ro | r Revision: | | Eng Log #: |
| 10-Oct-1992 Retype Entir | re Process from | 289412 - Repla | ces Old Paper | GLC 293123 |
| Process | | | | |
| | | | | |
| 23-Oct-1992 Add Materia | ls List | | | GLC 293200 |
| | | | | |
| • | | | | |
| Process Approval List | | | | |
| Tropic in Francisco | | | | • |
| Approved By: | Badge #: | Date: | Desig | nation: |
| JacksoRA | | | | |
| įJacksoka | | | | |
| | | | | |
| | | | | |
| Process General Notes | | | | |
| • | Not | 004 | | |
| | NOC | es: | | |
| | | | | ····· |
| | | | | |
| | | | | |
| | | | | |
| Process Material | | | | |
| Process Material | | | | |
| Process Material Part Number Quty | | Descripti | .on | |
| Part Number Qnty | | Descripti | on | |
| Part Number Qnty | afety - XP100 | Descripti | on. | |
| Part Number Qnty | | Descripti | on | |
| Part Number Qnty | afety - XF100 lank | Descripti | on | |
| Part Number Qnty | | Descripti | on | |

Document Number: Safety XP100 Rev:

VAXcamps V2.1 Hardcopy Utility Page: 1 OF 7

Process Routing

| | pt | Oper | Operation Description | Part Numbers |
|-----|-----|------------|----------------------------------------------------------------------|--------------|
| 200 | 551 | | Degrease, Carbo-Nitride Harden (Micro Carb), Oil Quench, Degrease | 91494 |
| 26 | 551 | 3 3 | Lindberg Draw | 91494 |
| 8 | 257 | 8 | Inspect for Rockwell Hardness | 91494 |
| 38 | 579 | 3 3 | Sweco Vibrate | 91494 |
| 8 | 579 | 60 | Black Oxide Color | 91494 |
| | | | To MRP Crib #29 | 91494 |

Operation Step Detail Operation: 45

Step

Operation / Step Description

Tooling Description

Degrease, Carbo-Nitride Harden (Micro Carb), Oil Quench, Degrease

Operation Tool Detail

Operation: 45

Tool Number

Micro-Carb Furnace

Basket

Document Number: Safety XP100 Rev:

VAXcamps V2.1 Hardcopy Utility Page: 2 OF 7

Operation Procedure Notes Operation: 45

Description

PROCESS RECORD - HEAT TREAT SPECIFICATION

MATERIAL & SPECIFICATION: 1020

TEMPERATURE: 1700 Degrees F - .75 Carbon

MAXINUM LOAD: 2,500-1,250 Pcs. per Basket - 2 Baskets Max.

TIME: 2 Hours @ Temp.

QUENCH: Oil

REMARKS: .005/.010 Case

INSPECT FOR: File Hard

HEAT TREAT INSPECTION:

STANDARD PRACTICE NO:

HARDNESS LIMITS:

APPEARANCE OF PARTS: Clean and Free of Oil

eration Step Detail Operation: 50

Step

Operation / Step Description

Lindberg Draw

Operation Tool Detail Operation: 50

Tool Number

Tooling Description

Std

Lindberg Draw Furnace

Document Number: Safety XP100 Rev:

VAXcamps V2.1 Hardcopy Utility Page: 3

7

Operation Procedure Notes Operation: 50

Description

PROCESS RECORD - HEAT TREAT SPECIFICATION

MATERIAL & SPECIFICATION: 1020

TEMPERATURE: 350 Degrees F

MAXIMUM LOAD:

TIME: 30 Min. @ Temp.

QUENCH:

REMARKS:

INSPECT FOR:

HEAT TREAT INSPECTION:

STANDARD PRACTICE NO:

HARDNESS LIMITS:

APPEARANCE OF PARTS:

Operation Step Detail Operation: 55

Step

Operation / Step Description

Inspect for Rockwell Hardness

Operation Tool Detail Operation: 55

Tool Number

Tooling Description

Sťď

Rockwell Hardness Tester

Document Number: Safety XP100

Rev:

VAXcamps V2.1 Hardcopy Utility

Page: 4 OF

Operation Procedure Notes Operation: 55

Description

PROCESS RECORD - HEAT TREAT SPECIFICATION

MATERIAL & SPECIFICATION: 1020

TEMPERATURE:

MAXIMUM LOAD:

TIME:

QUENCH:

REMARKS:

INSPECT FOR:

HEAT TREAT INSPECTION:

STANDARD PRACTICE NO:

HARDNESS LIMITS: R 15N 88-92

APPEARANCE OF PARTS:

eration Step Detail

Operation: 57

Step

Operation / Step Description

Sweco Vibrate

Operation Tool Detail

Operation: 57

Tool Number

Tooling Description

#3-1/2 Bonded

Chip

150/200 Lbs.

Amount of Chips

Number of Pcs. per Load

Document Number: Safety XP100

Rev:

VAXcamps V2.1 Hardcopy Utility Page: 5 OF 7

Operation Procedure Notes Operation: 57

Description

Process:

- 1. Thouroughly Wet Chips with Drain Open
- 2. Close Drain When Water is Drained Off
- 3. Add About 2 Quarts of Water
- 4. Add 1-1/2 Lbs #19 D
- 5. Add 1 Oz. 202 Compound On Chips
- 6. Add Parts
- 7. Vibrate 1 Hour
- 8. Flush Clean with Water
- 9. Drain
- 10. SEPARATE FROM CHIPS AND OIL PARTS

Operation Step Detail

Operation: 60

Step

Operation / Step Description

Black Oxide Color

Document Number: Safety XP100

Rev: 7

VAXcamps V2.1 Hardcopy Utility Page: 6 OF

Operation Procedure Notes Operation: 60

Description

SMALL PARTS BLACK OXIDE COLOR

BLACK OXIDE RACK/FIXTURE:

LOAD SIZE:

| STEP | PROCESS SEQUENCE | TEMPERATURE | CONCENTRATION | IMERSION TIME | | | | | | |
|-----------------------------------------|------------------|-------------|-----------------|---------------|--|--|--|--|--|--|
| ======================================= | | | | | | | | | | |
| 1 | Alkaline Clean | 212 F | 7-9% | 3-5 Minutes | | | | | | |
| 2 | Cold Water Rinse | Ambient | | 1 Minute | | | | | | |
| 3 | Muriatic Acid | Ambient | 15-17% | 10-15 Seconds | | | | | | |
| 4 | Cold Water Rinse | Ambient | | 1 Minute | | | | | | |
| 5 | Black Oxide #1 | 290 F | 6.5-6.8 lbs/gal | 30 Minutes | | | | | | |
| 6 | Cold Water Rinse | Ambient | | 1 Minute | | | | | | |
| 7 | Black Oxide #2 | 300 F | 7.0-7.3 lbs/gal | 30 Minutes | | | | | | |
| 8 | Hot Water Rinse | 212 F | | 1 Minute | | | | | | |
| 9 | Braze Color | 185 F | 1.0-1.3 lbs/gal | 30 Minutes | | | | | | |
| 10 | Hot Water Rinse | 212 F | | 1 Minute | | | | | | |
| 11 | Steelgard | Ambient | 15-20% | 30 Seconds | | | | | | |

NOTE FOR POWDER METAL AND M.I.M. PARTS

Document Number: Safety XP100 Rev:

VAXcamps V2.1 Hardcopy Utility Page: 7 OF

^{*} Increase immersion time on step #3 to 30-45 seconds. * Increase immersion time on step #8 to 30 minutes.