

CONFIDENTIAL

Remington Arms Company Inc.
RESEARCH & DEVELOPMENT TECHNICAL CENTER
315 WEST RING ROAD
ELIZABETHTOWN, KY 42701

TLW00100 - Weight of Bolt Assembly:

The bolt assembly, disassembled from the rifle, will be weighed. The test samples will be weighed on the Mettler Toledo digital balance (PB8000) located in the Metrology Lab. The rifle's bolt assembly will be weighed once each.

Method:

- Check to be sure that the bolt is correctly tagged with the last four digits of its rifle's serial number. This bolt assembly must be returned to its original rifle or the headspace may change.
- Clean the platen of the digital balance, if necessary.
- If the balance is not already on and has been turned on at least 30 minutes for warm-up, turn the balance on and wait 30 minutes for the balance circuitry to stabilize.
- Run the balance calibration routine if necessary.
- Make sure the units are set to "lb."
- Carefully place the bolt assembly with the bolt assembly's approximate front to rear balance point directly over the center of the balance platen.
- When the scale settles down, record the weight in lb. to the nearest 0.1 lb. (Note that the scale has three decimal points displayed.)
- Re-assemble the bolt on its corresponding barreled action.

Data Required:

- Rifle serial number
- Weight to the nearest 0.1 lb.
- Serial number of the Mettler PB8000 balance (it should be SN 2114475246)

J.R. Snedeker

Page 23 of 62

03/31/00

Remington Confidential

Revision #2

Subject to Protective Order - Williams v. Remington

BARBER - 5.30.06R0003288

ETE00003287