

Safety

S&W uses a two position safety that blocks the trigger. The safety button is located to the right of the receiver tang like our M/700. This safety does not lock the bolt in either the safe or fire position. The safety detent is provided by a spring and plunger that fit into one of two recessed holes in the safety lever. This plunger is located in the right side of the trigger housing and in front of the trigger. In the safe position, the plunger is pushed into the housing and blocks the trigger by the shallower hole in the safety lever. When the safety lever is rotated to the fire position, the plunger lines up with the deeper hole. This allows the plunger to move out of the triggers way and permit firing. (Photo #9)

