

The bolt body has three large gas vents, one circular and two elongated. These vents are directed down into the magazine when the bolt is closed. (See Photo #6) A bolt rotational stop is fitted in the left side of the bolt body. This stops the bolt from rotating when the two locking lugs are lined up with the rail cuts in either side of the receiver. (See Photo #7) The two lugs serve as bolt guides in the receiver. There is no anti-bind slot cut in either lug.

