

DON'T SAY IT—WRITE IT

TO GEORGE MARTINSAFETY MALFUNCTIONS
GALLERYDATE 5-2-75FROM GENE BULLIS

MODEL	MALFUNCTIONS												TOTAL SAFETY MALFUNCTION BY MODEL			
	FSR			JO			FD			FOS				SWW		
	10	11	12	13	14	15	16	17	18	19	20	21		22	23	
40							4									4
CP 100							3									3
540																
541								2	1							3
580													1			1
581							3	2	1							6
582																
600	1						10	74	55							140
700	9						7	19	10	1				1		47
788	4						3	9	3	2	9	4	14	95	53	196
EARLY MALF. TOTALS	14						30	106	70	3	9	4	14	97	53	400
TOTAL SAFETY MALFUNCTIONS																

TOTAL SAFETY MAL.

MALFUNCTION MEANINGS:

FSR - FIRES WHEN SAFE IS RELEASED - SELF EXPL.

JO - JARS OFF (HAMMER FAILS TO STAY ENGAGED WITH SEAR AND FALLS
DOWN WHEN GUN IS JARRED.)FD - FOLLOWS DOWN (COCKING PIECE FAILS TO PROPERLY ENGAGE WITH SEAR AND FOLLOWS
THE COCKING CAM SURFACE OF THE BOLT TO THE FIRED POSITION).

FOS - FIRES ON SAFE (GUN FIRES WITH SAFE IN "ON" POSITION WHEN TRIGGER IS PULLED).

SWW - SAFETY WON'T WORK - SELF EXPL.

* - 1975 DATA FROM DEC. 20, AM TO APRIL 29, 1975 ONLY.