

Safety

Ruger's safety is also of the trigger block type and is very similar to Brownings. The safety has two positions and the safety button is located on the receiver tang. The bolt is locked with the safe on and unlocked with it off. The detent is again provided by a helical torsion spring that is cammed over its center. The trigger is blocked by a large diameter safety pin that is connected to the bell crank and goes through the receiver/ trigger housing in front of the trigger. This pin has a cut out section that does not block the trigger when the safe is in the fire position. (Photo #10)

