

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
1															
2			Nominal	+	-	1	2	3	4	5	6	7	8	9	10
3	A	Free Length	0.2500	Min		0.2731	0.2662	0.2755	0.2712	0.2666	0.2642	0.2744	0.2743	0.2681	0.2674
4	B	OD	0.1200	Max		0.1125	0.1123	0.1124	0.1121	0.1124	0.1123	0.1120	0.1122	0.1121	0.1127
5	C	Wind	LH			OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
6	D	Ends	CEG			OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
7	E	Wire Diameter	0.0200	0.0010	0.0010	0.0194	0.0193	0.0196	0.0195	0.0194	0.0194	0.0194	0.0195	0.0194	0.0194
8	F	L1@.220	2.00	0.25	0.25	1.8500	1.7350	2.2900	1.7300	1.6800	1.7450	1.8950	1.9150	1.8400	1.6200
9	G	L2@.185	4.00	0.40	0.40	3.3600	3.4300	3.9100	3.4100	3.3450	3.4400	3.5000	3.7200	3.5250	3.3050

	P	Q	R	S	T	U	V	W	X	Y	Z	AA	AB	AC	AD
1															
2	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25
3	0.2673	0.2712	0.2681	0.2722	0.2726	0.2687	0.2695	0.2746	0.2697	0.2728	0.2766	0.2740	0.2672	0.2774	0.2692
4	0.1124	0.1121	0.1120	0.1122	0.1121	0.1124	0.1122	0.1122	0.1121	0.1123	0.1122	0.1122	0.1125	0.1122	0.1121
5	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
6	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
7	0.0193	0.0195	0.0193	0.0194	0.0193	0.0193	0.0194	0.0193	0.0193	0.0193	0.0193	0.0193	0.0195	0.0193	0.0193
8	1.6800	1.7650	1.8750	1.8850	1.6750	1.7100	1.6100	1.8300	1.7700	1.9200	1.8150	1.9100	1.6650	1.8850	1.7550
9	3.3500	3.4350	3.4550	3.4450	3.3600	3.3700	3.2300	3.4850	3.4400	3.4450	3.4400	3.4300	3.2800	3.5200	3.4350

	AE	AF	AG	AH	AI	AJ
1						
2	26	Avg	SD	MAX	MIN	Range
3	0.2695	0.2708	0.0035	0.2774	0.2642	0.0132
4	0.1121	0.1122	0.0002	0.1127	0.1120	0.0007
5	OK					
6	OK					
7	0.0192	0.0194	0.0001	0.0196	0.0192	0.0004
8	1.7550	1.8002	0.1374	2.2900	1.6100	0.6800
9	3.4450	3.4427	0.1331	3.9100	3.2300	0.6800

Cell: B8

Comment: Jim Ronkainen:

Loads are typically running low, most likely due to the wire size running smaller than nominal. Since an adjustment screw is used to set trigger pull force, parts can be used as-is.

Cell: B9

Comment: Jim Ronkainen:

Loads are typically running low, most likely due to the wire size running smaller than nominal. Since an adjustment screw is used to set trigger pull force, parts can be used as-is.

	B	C
2		
3		
4	PDF Microsoft Word E:\241460 40X Replacement Progra	
5		
6		
7		
8		