

CONFIDENTIAL

Remington Arms Company Inc.
RESEARCH & DEVELOPMENT TECHNICAL CENTER
315 WEST RING ROAD
ELIZABETHTOWN, KY 42701

TLW0010N - Weight of Barrel Assembly:

The barreled action, disassembled from the stock, will be weighed. Remove the bolt assembly from the barreled action. The test samples will be weighed on the Mettler Toledo digital balance (PB8000) located in the Metrology Lab. The rifle's barreled actions will be weighed once each.

Method:

- Tag the bolt so that it is labeled with the last four digits of its rifle's serial number. This bolt assembly must be returned to its original rifle or the headspace may change.
- Clean the platen of the digital balance, if necessary.
- If the balance is not already on and has been turned on at least 30 minutes for warm-up, turn the balance on and wait 30 minutes for the balance circuitry to stabilize.
- Run the balance calibration routine if necessary.
- Make sure the units are set to "lb."
- Carefully place the barreled action on its left side with the barreled action's approximate front to rear balance point directly over the center of the balance platen.
- When the scale settles down, record the weight in lb. to the nearest 0.1 lb. (Note that the scale has three decimal points displayed.)
- Re-assemble the stock on its corresponding barreled action.

Data Required:

- Rifle serial number
- Weight to the nearest 0.1 lb.
- Serial number of the Mettler PB8000 balance (it should be SN 2114475246)

J.R. Snedeker

Page 22 of 62

03/31/00

Remington Confidential

Revision #2

Subject to Protective Order - Williams v. Remington

BARBER - 5.30.06R0003287

ETE00003286