## SAFE "OFF - ON" FORCES

## 1 B. <u>Procedure</u> - continued

.

- Push the Safety Selector Switch, with the push pull gauge, from the "ready to fire" position, to the "safe" position.
- Record the force, measured in pounds, in the safe "On" column of the Test Procedure Sheet.
- Since the Test Procedure Sheet calls for three readings of the Safe "Off" force and three readings of the Safe "On" force, repeat Steps No. 4 through No. 6 for the other readings.
  - Model 3200 Safety Selector Switch forces must be taken for each barrel position. Follow Steps No. 4 through No. 7 for one barrel position, then repeat for the other.
- 8. Put the safety selector switch in the "Safe" position, open the action, and re-check to be sure the firearm is empty.
- 9. Return the firearm to the desired location, return the gauges to the proper cabinet, put the Test Procedure Sheet in the test folder, and clean the work area.

-9-