

TRACKING # TLW 1530S
DATE 8/3/04

#	1	PLACE GUN A-5 AND 100 ROUNDS AMMO IN PRE-HEATED CHAMBER FOR 15 HOURS AT 120 DEGREE F.
#	2	TOOK GUN A-5 AND 20 ROUNDS OF AMMO OUT OF PRE-HEATED CHAMBER TO SHOOTING ROOM AND SHOT 20 ROUNDS. LOADING ONE ROUND IN CHAMBER AND FOUR ROUNDS IN THE MAGAZINE. CYCLED SAFETY EVERY FIFTH ROUND. PUT GUN A-5 BACK IN PRE-HEATED CHAMBER FOR 2 HOURS.
#	3	AFTER 2 HOURS TOOK GUN A-5 AND 20 ROUNDS AMMO OUT OF PRE-HEATED CHAMBER TO SHOOTING ROOM AND SHOT 20 ROUNDS. LOADING ONE ROUND IN CHAMBER AND FOUR ROUNDS IN THE MAGAZINE. CYCLED SAFETY EVERY FIFTH ROUND. PUT GUN A-5 BACK IN PRE-HEATED CHAMBER FOR 2 HOURS.
#	4	AFTER 2 HOURS TOOK GUN A-5 AND 20 ROUNDS AMMO OUT OF PRE-HEATED CHAMBER TO SHOOTING ROOM AND SHOT 20 ROUNDS. LOADING ONE ROUND IN CHAMBER AND FOUR ROUNDS IN THE MAGAZINE. CYCLED SAFETY EVERY FIFTH ROUND. PUT GUN A-5 BACK IN PRE-HEATED CHAMBER FOR 2 HOURS.
#	5	AFTER 2 HOURS TOOK GUN A-5 AND 20 ROUNDS AMMO OUT OF PRE-HEATED CHAMBER TO SHOOTING ROOM AND SHOT 20 ROUNDS. LOADING ONE ROUND IN CHAMBER AND FOUR ROUNDS IN THE MAGAZINE. CYCLED SAFETY EVERY FIFTH ROUND. PUT GUN A-5 BACK IN PRE-HEATED CHAMBER FOR 2 HOURS.
#	6	AFTER 2 HOURS TOOK GUN A-5 AND 20 ROUNDS AMMO OUT OF PRE-HEATED CHAMBER TO SHOOTING ROOM AND SHOT 20 ROUNDS. LOADING ONE ROUND IN CHAMBER AND FOUR ROUNDS IN THE MAGAZINE. CYCLED SAFETY EVERY FIFTH ROUND.
		CLEANED AND INSPECTED (EVERYTHING OK)
		MALFUNCTIONS
		0