Test Lab Request Form Instructions

 The TLW request form can be found on the second worksheet (tabs at bottom of the screen) of this file. BARBER -

RE 0004278

- Please fill in all required fields as noted in red. Please fill in all other fields if applicable / possible. Instructions for each field will appear when you click on the field. The procedure field is an embedded MS Word object which will allow you to use formatting features not possible in Excel (i.e. paragraphs, bullets, numbering, etc).
- If possible, create your desired data table and/or graph formats in the additional worksheets of this file. This is preferred over extensive written procedures.
- If the request is for High Speed Video, specify any desired parameters (i.e. frame rate, resolution, etc.) in the "HSV Setup" tab. If not specified, the videographer will document the parameters that they chose to use.
- Once the form is completed, save this file on your personal computer using the following format:

TLW#### - Brief Description

Try to keep the description as concise as possible. Your name in the filename is no longer necessary.

Email the file to Phillip Reesor (primary) and Mark Hammond (secondary).
 Phillip will return your email with the assigned number and the assignee

Test Lab Work Request Form

BARBER - RE 0004279

1 est Lab Work Request Form	
Engineer: Vince Norto	n Project #: 241493
Date Submitted:	11/14/2008
Test De scription:	Assemble new receiver insert assemblies in a Model 770 action and measure safety on/off forces
Test Procedure:	Assemble a new receiver insert assembly into a Model 770 action With the bolt closed measure safety on and off forces. Take 3 measurements and record each one. Cycle the safety on and off 10 times and then record forces again 4. Cycle the safety on and off 10 more times and then record forces 5. Repeat this on 6 assemblies.
	3. Repeat this on o assembles.
TLW Form <autofile></autofile>	Page 2 of 11

Test Lab Work Request Form

TLW #: 11/18/2008

a new receiver insert assembly into a Model 770 action, olt closed measure safety on and off forces. Take 3 ents and record each one.

safety on and off 10 times and then record forces again. safety on and off 10 more times and then record forces again. s on 6 assemblies.


TLW Form

<autofile> Page 3 of 11

Test Lab Work Request Fo	orm
Special Requirements:	
Supplies Availability:	
Results Required:	
*****This section to be completed by Test Lab Manager****	
Assigned To:	Start Date:
Assigned Date:	Completion Date:
Comments:	

BARBER - RE 0004283


TLW Form <a utofile Page 6 of 11



Data Only
Formal Report

TLW Form <autofile> Page 7 of 11

Test Lab Work Request Form



Page 8 of 11

BARBER - RE 0004285

Page 9 of 11

equest Form

<autofile>

Cont'd Procedure

RCHIVE:								
								TLW
							Camera Ope	rator
							File Na	ames:
							Conve	ntion:
ourpose of Te	st:							
Camera:	⊕ Al	PX-RS					□ 1024PC	
						Resolu	ution (WxH, p	ixels):
ens:								
quipment He	ight (in	. above or t	elow s		entry = in-plane v	vith sul	bject)	
				Equipment				
amera								
.1 1000W .2 1000W								
.Z 1000VV								

BARBER - RE 0004287

⊂ Canon 20D

	c	ALL	FIL	ES	•						î representative fileiş)		NO ARCHIVE			
										File Name:	e:					
									- -		Date: Project No.:					
	TLWNo Desc	cription.avi i.e. [TLV	/2162 Shot 1 18in	n bbi GB.avi],	[TLW2162 S	Shot 2 18in b	bl GB. avi	1								
I PCI	⊂ Canon 20D								Shutter Speed: Frame Rate (fps):							
	Type (C or F): Focal Length (mm):									op used:			1			
							Focal Len	gth (mm)):		zoom use	ed (mm):				
	Position								Target	Symbol	Equipn	nent	Position		Symb	
							· · · · · · · · · · · · · · · · · · ·									
										\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\						
										/12/						

BARBER - RE 0004288