TLW <u>0010AR</u>

Project No. <u>241095</u>

S.A.A.M.I. JAR-OFF, DROP & ROTATION TEST

| | · · · · · · · · · · · · · · · · · · · | | | | |
|---|---------------------------------------|-----------------------------------|--|-----------|--|
| Gun # Do | | | | | |
| No. 5-26 Fireco | ntrol Type: | Standard | Date | : 9/10/00 | |
| Dry Cycles/Rounds Completed: Stock Type Sym Engagement at Start , o 2 10 | | | | | |
| Model No. 710 Serial No 7/00/025 Engagement at End 10/93 | | | | | |
| Trigger Pull at Start of Test (1) 4.0 (2) 4.0 (3) 3.75 (4) 4.0 (5) 4.0 (6) 4.0 | | | | | |
| Average Trigger Pull at Start of Test: 3, 96 Std. Dev. of Trigger Pull at Start of Test: Trigger Pull at End of Test (1) 3.75 (2) 3.75 (3) 4.0 (4) 4.0 (5) 4.0 (6) 4.0 | | | | | |
| Average Trigger Pull at End of Test: 3,92 Std. Dev. of Trigger Pull at End of Test: | | | | | |
| Average ringger run at End of Test: Std. Dev. of ringger run at End of Test: | | | | | |
| | | Tes | ter Initials:S | $M/2M^4$ | |
| Additional Notes and Comments | | | | | |
| Gun with open sights | | | | | |
| | | | 50 50 50 50 50 50 50 50 50 50 50 50 50 5 | 3 33 | |
| | | | | | |
| | | | | - 1 | |
| | | - 177 177 - 178 - 1885 178 179 | | -98 | |
| For additional details on the proper | procedures to | be used for this | Test Procedure | refer to: | |
| ANSI /\\$AAMI Z299.5-1990 | | | | | |
| SAAMI Specifications for Standard Jar-Off Test: | | | | | |
| | | | | | |
| Jar-Off Test: 12-inch drop- onto 1" thick 85 durameter (Shore A) Rubber Matt | | | | | |
| Firearm ready to fire Safe in "Fire" position, Fresh Primed Case in | | | | | |
| Chamber, Magazine loaded to capacity with Dummy Rounds. | | | | | |
| After each drop, fire Primed Case to verify firearm will still function. | | | | | |
| 12 inch drop (safety in ' | 'Fire" position | i) - one drop per o | rientation. | | |
| Note for Firearms with the ISS system installed – The ISS will be set in the unlocked | | | | | |
| position for all six orientations of the Jar-Off Test | | | | | |
| \$ Ô₩-,, «#₹5° | | s of the Jar-Off 1 | <u>esi</u> | | |
| O <u>rientation</u> ISS Unlo | _ | | nments | | |
| Barrel Vertical, Muzzle Up: Pass _ Barrel Vertical, Muzzle Down: Pass _ | ✓ Fail | Magaz | in - can | - loose | |
| Barrel Vertical, Muzzle Down: Pass_ | ✓ Fail | | | | |
| Barrel Horizontal, Left side of Stock Up: Pass | | | | | |
| Barrel Horizontal, Right side of Stock Up: Pass Barrel Horizontal, Bottom of Stock Up: Pass Barrel Horizontal, Bottom of Stock Down: Pass | Fail | _ Mngazi | na enh | e loose | |
| Barrel Horizontal, Bottom of Stock Up: Pass | Fail | | | | |
| Barrel Horizontal, Bottom of Stock Down: Pass | ✓ Fail | _ Fired | Primed | Case | |
| | | | | | |
| | | | | | |
| | | | | | |

Page 1 of 2 Z101\DROPTEST_REV3.DOC

TLW DOIDAG

B-26

Project No. 241095

S.A.A.M.I. JAR-OFF, DROP & ROTATION TEST

SAAMI Specifications for Standard Drop Test:

Drop Test:

48-inch drop - onto 1" thick 85 durameter (Shore A) Rubber Matt Firearm not ready to fire, Safe in "Safe" position, Fresh Primed Case in Chamber, Magazine loaded to capacity with Dummy Rounds. After each drop Fire Primed Case to verify firearm will still function.

48 inch drop (safety in "Safe" position) - one drop per orientation.

Note: for Firearms with the ISS system installed - The Firearms will be set with the

ISS system in the unlocked position for all six orientations of the Drop Test

| Orientation | ISS Unlocked | Comments | | | |
|---|--|--|--|--|--|
| Barrel Vertical, Muzzle Up: | Pass Fail | 83 | | | |
| Barrel Vertical, Muzzle Down: | Pass Fail | | | | |
| Barrel Horizontal, Left side of Stock | up: Pass / Fail | | | | |
| Barrel Horizontal, Right side of Stoo | ck Up: Pass V Fail | | | | |
| Barrel Horizontal, Bottom of Stock | Up: Pass / Fail | | | | |
| Barrel Horizontal, Bottom of Stock | Down: Pass Fail | Fired Primed Case | | | |
| SAAMI Specifications j | for Standard Rotation Test: | TLW 0010 AS | | | |
| Rotation Test: Rest Firearm on the Buttend and allow Firearm to fall Deop onto 1" thick 85 durameter (Shore A) Rubber Matt | | | | | |
| Fired in On After "Rotation Tes <u>Note: for Firearms</u> | irm not ready to fire, Safe in namber, Magazine loaded to each drop Fire Primed Cas st" (safety in "Safe" position with the ISS system installed | "Safe" position, Fresh Primed Case capacity with Dummy Rounds. e to verify firearm will still function. n) - one drop per orientation. d - The Firearms will be set with the prientations of the Rotation Test. | | | |
| Orientation | ISS Unlocked | Comments | | | |
| Firearm Vertical, Drop so left side of | f Stock is Up: Pass V F | Fail | | | |
| Firearm Vertical, Drop so right side of | of Stock is Up: Pass Fa | il Fired Primed Case | | | |
| Notes: (continue on back of sheet if necess | sary) | Tester's Initials SWJW | | | |
| | | Page 2 of 2 Z101\DROPTEST_REV3.DOC | | | |

ET07208