#### PROCEDURE FOR MEASURING FIRING PIN INDENT AND TRIGGER FULL

ON

## BREAK OPEN FIREARMS

#### I. METHOD: CRUSHER HOLDER WITH COPPER CRUSHER CYLINDER

- A. Equipment Needed (Fig.#I)
  - o Copper Crusher Cylinders (annealed)
  - o A pedestal mounted dial indicator, graduated in .005" of an inch.
  - o Deburring Plate
  - o The crusher holder for the gauge or caliber of the firearm.
  - o Trigger Pull Scale
  - o Test Procedure Sheet

### Fig. No. I

# B. Procedure

- I. Throughly clean the chamber (or chambers if a double barrel), of all residue or lubrication. Use a felt cloth and a cleaning rod to do this.
- 2. Place the firearm into the gun saddle and put the safety selector to the "S" position.
- Take a copper crusher and vigorously rub one end on the deburring plate until a bright copper color appears. When this occurs, the crusher is deburred. (Fig.#2)

### Fig. No. 2

BREAK-OPEN SHOTGUNS